



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
000300-1539	NS	SOCKET RELAY
001-312-2	NS	BLADE NOTCHED
0-25-3SS	NS	BALL
00016-0001-001	NS	SUPPORT BLOCK
00110420002	NS	PIN, MALE
005-0669-000	NE	ADHESIVE
005-1154-490	NE	ENAMEL, AMBER
005-2030-030	NE	EPOXY
005-2030-030	NE	EPOXY
006-1-0	NS	ADAPTER
006-1-0	NS	ADAPTER
006-4004	NS	JACK
006-4004	NS	JACK
010110-1	NE	TEMPERATURE RECORDER
010110-1	NS	TEMPERATURE RECORDER
010110-2	NS	TEMPERATURE RECORDER
0134-PL	NS	DB-37-HOOD
015-2027-000	NS	BRUSHES
0164-13	NS	LOCK WASHER
019-07246-000	NS	TRANSFORMER
01F965	NS	TRANSFORMER
01F384	NS	TRANSFORMER
020885	NS	CAPACITOR
020886	NS	CAPACITOR
020887	NS	CAPACITOR
025-1155-001	NS	DUST CAP
030-2259-000	NS	PIN (MALE)
030-2409-001	NS	PINS
030-2409-001	NS	PINS
030-2409-003	NS	CONTACT
030-2409-003	NS	CONTACT
030-2491-001	NS	SOCKETS
030-2491-001	NS	SOCKETS
031-9074-002	NS	PIN
031-9134-001	NS	PINS
031-9134-004	NS	SOCKET
031-9206-004	NS	SOCKET
033108-001	NS	DIODE
03335	NS	DIAL
035149	NS	SCREW
0363-RG	NS	REGULATOR
036629-718	NS	DIODE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
039-0187	NS	PIN
03F604	NS	TRANSFORMER
03F6610	NS	TRIMMER
04-1061-00	NS	LCD DISPLAY
043P103	NS	TRIMMR RESISTOR
043P203	NS	TRIMMR RESISTOR
043P502	NS	TRIMMER
043P503	NS	TRIMMER
04410809	NS	TAP
04420808	NS	TAP
0450-7	NS	PIN
0453-128	NS	SCREW
0453-220	NS	SCREW
0468.500	NS	FUSE
05F1432	NS	TRANSFORMER
05F301	NS	TRANSFORMER
060R0050U	NS	RESETTABLE PTC
06F664	NS	DISPLAY
07187-603999	NS	TRANSFORMER
07187-603999	NS	TRANSFORMER
0770-3	NS	WASHER
08F6425	NS	SEMICONDUCTOR
08F700	NS	POTENTIOMETER
08F715	NS	POTENTIOMETER
08SM260-6	NS	SERVO MOTOR
08YY23955D	NS	SWITCH ROTARY
0A2WA	NS	VACUM TUBE
0B2WA	NS	VACUM TUBE
1.5KE11	NS	DIODE
10-60479-115	NS	CONNECTOR
10-60479-116	NS	CONNECTOR
10-78-2592	NS	RESISTOR
1000364	NS	TERMINAL
1000364	NS	TERMINAL
10022335-101	NS	POINTER ASSY
10022348-102	NS	INSTRUCTION PLATE
100224-01-01	NS	PCB ASSY, DRIVR
10023325-101	NS	DIAL
10023327-101	NS	DIAL
10023329-101	NS	DIAL
1002760	NS	ID PLATE
1002761	NS	ID PLATE
10030152-101	NS	DIAL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
10032660-103	NS	GEAR
10033071-101	NS	CLUTCH
10033705-101	NS	LAMP
10E01-6	NS	LENS
100KOHM10TURN	NS	POTENTIOMETER
100OHM10TURN	NS	POTENTIOMETER
1010-2	NS	SHIM STOCK
1010B	NS	VARIAC
101123	NS	COUPLING ASSY
101124A	NS	SWITCH
101124B	NS	SWITCH
101125A	NS	SWITCH
101172	NS	RESISTOR
1077-1-159	NS	ACTUATOR
108-0007-EVX	NS	SWITCH, TOGGLE
108-0029-EVX	NS	SWITCH, MIN
108-0302-001	NS	BANANA PLUG
108-0303-001	NS	BANANA PLUG
736913	NS	SLIP RING ASSY
1H5GT	NS	VACUUME, TUBE
100-19	NS	POTENTIOMETER
500OHM1TURN	NS	POTENTIOMETER
5987	NS	VACUUME, TUBE
609-8072-001	NS	POWER SUPPLY
280195	NS	BRUSHES
8107305ADP5	NS	BRUSHES
8107305	NS	BRUSHES
6841008625	NS	POTENTIOMETER
000300-1539	NE	SOCKET RELAY
001-312-2	NS	BLADE NOTCHED
005-0569-000	NE	ADHESIVE
019-07246-0000	NS	TRANSFOMER
030-9081-000	NS	PIN CONTACT
07187-603999	NS	TRANSFORMER
0A2WA	NE	TUBE
0B2WA	NE	TUBE
1-040-0003	SV	VIBRATION MONITOR
10-61800-1504	SV	LIGHTPLATE
1000364	NE	TERMINAL
10022335-101	SV	POINTER ASSY
10024188-101	SV	DIAL SCALE
10033071-101	NE	CLUTCH
10060-7	SV	GLOBAL NAV



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1023K71P001	NE	ADAPTER
1025700-13	SV	CIRCUIT CARD
10400	SV	REGULATOR
10400-13	SV	DILUTER
1045-109B	NS	KNOB
1045-387B	NS	KNOB
10M-101-B-1	SV	SERVO MOTOR
1229752-1	NE	TRANSFORMER
1231438-1	NE	TRANSFORMER
1235750-1	SV	TRANSFORMER
1239751-1	NE	TRANSFORMER
124-836	OH	WATTMETER
124.514-1	OH	IND
124.514-1	OH	IND
124.514-1	OH	EGT INDICATOR
124.832	OH	IND
124.833	OH	IND
124.833	OH	IND
124.833	OH	DC VOLTMETER
124.834	OH	IND
124.834	OH	IND
124.834	OH	DC AMMETER
124.836	OH	IND
124.836	OH	IND
124.837	OH	IND
124.837	OH	IND
124.837	OH	AC AMMETER
1244259-3	NE	RELAY
1252699-15	NE	THERMAL RELAY
1255097-1	NE	COVER
1267753-1	NS	RELAY
1278401-1	NE	ROTOR
1293564-1	NS	BRACKET
13504-001	SV	MATRIX SWITCH
136224-001	NS	WINDOW
1426-29D-B17	SV	AIRSPD INDICATOR
1426-47J-B17	SV	AIRSPD INDICATOR
147BDL2	OH	TEMPERATURE IND
147BL701	SV	TEMP INDICATOR
147BL702	SV	AIR TEMP INDICATOR
147D2	OH	OIL TEMP RISE IND
148231-01	NS	VARIABLE RESISTOR
149150-01-01	OH	ATTITUDE DIRECT IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
149150-01-02	OH	ATTITUDE DIRECT IND
149155-01-01	OH	IND
149155-01-01	OH	IND
149270-05-01	OH	TAT/EPR LIMIT IND
149270-05-01	OH	TAT/EPR LIMIT IND
149270-05-01	OH	TAT/EPR LIMIT IND
152BL702	OH	E.G.T. INDICATOR
152BL702	SV	EGT INDICATOR
152BL702D	OH	INDICATOR
152BL702E	OH	IND
152BL702E	OH	IND
152BL702E	OH	E.G.T. INDICATOR
152BL705A	OH	IND
152BL705A	OH	IND
152BL705A	OH	EGT INDICATOR
152BL705H	OH	IND
152BL705H	OH	IND
152BL705H	OH	EGT INDICATOR
152BL705L	OH	IND
152BL705L	OH	IND
152BL705L	OH	EGT INDICATOR
152C4E	SV	EXH TEMP
154BL702E	OH	EGT INDICATOR
157405-02-01	OH	TAT-ENG N1 LIMIT IND
157405-02-01	OH	TAT-ENG N1 LIMIT IND
157-887V1	OH	BOARD
160015-5	SV	WATER PUMP ASSY.
162BCL10	OH	IND
162BCL10	OH	IND
162BCL10	OH	OIL TEMPERATURE IND
162BCL11	SV	CABIN TEMP INDICATOR
162BL704C	OH	IND
162BL704C	OH	IND
162BL704C	OH	OIL TEMP. INDICATOR
162C23B	SV	ENG. TEMP INDICATOR
1636-6A-B1	SV	VERTICAL SPEED IND.
165-73-1001X	NS	CONNECTOR
1701115	NE	GASKET
1724T024S	NE	MOTOR
175-26W603	NS	PLATE
1755606	NE	BLOCK
1755606	NS	BLOCK
1776365-924	OH	HORIZON IND.



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1776366-601	OH	PICTORIAL DEV.IND
1778686-655	OH	IND
1778686-655	OH	IND
1778686-655	OH	GYROSYN COMPASS IND
1783867-1	OH	AMPLIFIER
1783867-1	OH	AMPLIFIER
1783867-1	OH	SERVO AMPLIFIER
1784460-355	OH	IND
1784460-355	OH	INDICATOR
1784460-355	OH	IND
1784460-355	OH	GYROSYN COMPASS IND
1784460-656	OH	IND
1784460-656	OH	GYROSYN COMPASS IND
1784460-656	OH	GYROSYN COMPASS IND
1784460-656	SV	GYROSYN COMPASS IND
1784460-656	SV	GYROSYN COMPASS IND
1784460-656	SV	GYROSYN COMPASS IND
18-1299-3	OH	IND
18-1299-3	OH	IND
18-1299-3	OH	FLAP POSITION IND
1877874-1	NE	FLAG ASSY
1889366-3	SV	LENS
192-2004-010	SV	GLASS
192-2010-001	SV	WEDGE LIGHTING
19200-1	SV	PERCENT SPEED IND
19200-3	SV	PERCENT SPEED IND
193333-904	SV	FLAG
1986462-1	SV	DIAL
1988990-1	SV	DIAL
1988991-1	SV	DIAL
1988992-1	SV	DIAL
1988993-1	SV	DIAL
19GE331	NS	GEAR
1BA60	NS	ASSY
1U320-001-11	SV	TACH INDICATOR
1U320-001-11	SV	TACHOMETER IND
200-001-003W	OH	IND
200-002-001	OH	IND
200-002-001	OH	TAG '09 /18 MNTH WTY
200-002-001	OH	IND
200-002-001	OH	FUEL QTY IND
200-007-005	OH	HYD FLUID QTY IND
200-007-005	OH	HYD FLUID QTY IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
200-007-005	OH	HYD FLUID QTY IND
2000075-1	SV	DIAL
202-1A5A5K	SV	TEMPERATURE IND
203054-L	NS	BEARING
203221	NS	CONTACT SLEEVE
2057-01-1	OH	ALTITUDE IND
206-001-003W	OH	INDICATOR
206-001-003W	OH	IND
206-001-003W	OH	FUEL QTY IND
2061-13-1	SV	FLAP POSITION IND
2067635-0701	OH	IND
2067635-0701	OH	IND
2068860-0001	SV	RELAY
2070-03-1	OH	IND
2070-03-1	OH	IND
2070-03-1	OH	VERTICAL SPEED IND
2083-11-1	OH	INDICATOR
2083-11-1	OH	INDICATOR
2083-11-1	OH	INDICATOR
2092-01-1	OH	RPM INDICATOR
2092-02-1	OH	RPM INDICATOR
21607A-CY-04/D430	SV	MOTOR, DC
21607A-CY-04/D539	SV	MOTOR, DC
21607ACY04D576	SV	MOTOR, DC
21607ACY04D593	SV	MOTOR, DC
217-03221	OH	TORQUE PRESS IND
2187K10G700	SV	CASE ASSY, LOWER
22-995-06-1	SV	AIR TEMP IND
225010-035	SV	METER MOVEMENT
225010-039	SV	METER MOVEMENT
229-2050-010	SV	MOTOR-TACH GEN
229-3044-010	SV	SYNCHRO TRANSMITTER
229-6026-020	SV	SYNCHRO
230967	NS	ANVIL
241235	NS	LATCH
24128-1	SV	DIAL
243005-103	OH	METER
243005-103	OH	METER
243005-103	SV	IND KW
248640	NS	RIVET
248697	OH	LOADMETER
248697	OH	LOADMETER
248697	OH	DUAL LOADMETER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
248992	SV	SPEED FLAG
25-0037-1	NS	LENS FILTER
2500150-33	OH	CAPACITOR
2500276-102	NE	TERMINAL BOARD
2500276-105	NE	TERMINAL BOARD ASSY
2500277-27	NE	CONNECTOR
2500391	NS	I.C.
2501444-4	NE	LAMP
2501592-1	SV	SYNCHRO
2501597-1	SV	TRANSOLVER
2501599-1	SV	SYNCHRO
2575929-910	SV	F/D CONTROL PANEL
2579272	NS	SWITCH
2579442-1	NS	STUD
2579765-1	NS	GEAR
2582922	NE	LEAD ASSEMBLY
2582978-1	NE	PRINTED CABLE ASSY
2582978-2	NE	PRINTED CABLE ASSY
2582978-3	NE	PRINTED CABLE ASSY
2585703	OH	SLAVING AMPLIFIER
2586894	NE	FRAME
2588369-902	OH	IND
2588369-902	OH	IND
2588371-901	OH	IND
2588371-901	OH	IND
2588371-901	OH	RADIO DIRECTION IND
2588381-901	OH	IND
2588381-901	OH	IND
2588381-901	OH	GYROSAN CMPASS IND
2589112-905	OH	IND
2589112-905	OH	IND
2589112-905	OH	HORIZ FLT DIRECT IND
2589150-904	SV	CAPACITOR CARD
2589804-904	SV	AMPLIFIER CARD
259-9670-030	NE	SWITCH
2591149	NE	GUIDE
2591439-901	SV	MODE SELECT PANEL
2591439-903	SV	COURSE MODULE ASSY
2591464	SV	A/T MOD CONTROL
2591485	SV	MODE SELECT PANEL
2591603-901	SV	SOLENOID DRIVER MODU
2591603-903	NS	SOLENOID MODULE ASSY
2591780-902	SV	V/S MODULE ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2591852	SV	HEADING MODULE ASSY
2592668	NS	BRUSH BLOCK
2592668	SV	BRUSH BLOCK
2592838-901	OH	PICT. DIVIAT. IND.
2593200-951	OH	COMP
2593200-951	OH	COMP
2593200-951	OH	AIR DATA COMPUTER
2593368	SV	A/P COMMAND MODULE
2593842-901	SV	CONTROL MODULE ASSY
2594620-905	OH	IND
2594620-905	OH	IND
2594625-901	SV	RADIO DIGITAL DISTAN
2594943-901	SV	SP-COMM MODULE ASSY
2594964-901	SV	PITCH F/D SUMP AMP M
260909	OH	IND
260909	OH	IND
260909	OH	VALVE POSITION IND
262-0441-010	SV	DISPLAY MODULE
266-0140-000	SV	ADAPTER
266-7112-060	NS	LENS
266-7142-050	SV	SWITCH PUSHBUTTON
266-7566-010	SV	PUSH SWITCH
267004-024	SV	MOTER MOVENT
26V08RT4B-02	SV	SYNCHRO TRANSMITER
27ET29-T	SV	SWITCH, TOGGLE
281-0661-070	NE	KNOB
281-0661-210	NE	KNOB
281-0661-220	NE	KNOB
281-0661-430	NE	KNOB
281-0670-020	NE	KNOB
281-0670-0301	NE	KNOB
285T00017-104	OH	POWER SUPPLY MOD ASY
285T0017-103	OH	POWER SUPPLY MODULE
285T0017-103	OH	MODULE
285T0017-103	OH	MODULE
285T1201-1	SV	PANEL
2965007	SV	STATOR
309-1953-020	SV	BEARING BALL
310933-01	SV	TRANSFORMER
3132W73P001	SV	SCALE PLATE
3133W11P001	SV	SCALE PLATE
3133W62P001	SV	SCALE PLATE
321-0409-000	SV	SCREW MATCH SST



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
321070	NS	CAP
328-0368-000	SV	SET SCREW
328-0371-000	SV	SETSCREW
330813	NS	COVER ACCESS
3310-00001	SV	RPM INDICATOR
334-0287-000	SV	NUT
335-0005-000	SV	SET SCREW
335-0133-000	SV	SET SCREW
335-101	SV	PANEL, PILOT CALL
3382W23G702	SV	BOARD ASSY
3382W25G702	SV	BOARD ASSY
33K5	NS	BEARING
340-0112-000	SV	RING RETAINER
340-0113-000	SV	RING RETAINER
350-0093-010	NE	IC
350-0095-010	NS	DIFF. SENSOR
350-0103-010	SV	ERROX AMPLIFIER
350-0116-010	SV	IC AMP
350-9056-010	SV	IC NET.VLT
350-9060-010	SV	IC ERROR MONITOR
3511-180-41662	SV	TAPE
3511-180-42122	SV	TAPE, ALTITUDE
35AV1350A2	NS	RELAY
36135-1S-19-B1	SV	RADIO MAG IND
367-1009-01	NE	'O' RING
37-3-2125	NS	NUT
3759028-6	OH	PANEL
3759028-6	OH	PANEL
3759028-6	OH	PITCH CONTROL PANEL
3759082-6	OH	CONTROL PANEL, PITCH
3759082-6	SV	CONTROL PANEL, PITCH
3798055-1	SV	RATE GYRO
383056-06835	SV	OIL QTY
3830K75P001	NE	GASKET
3830K75P003	NS	GASKET
383156	NS	CONNECTOR
383177	NS	GEAR ASSY
383269	NS	GEAR ASSY
3881K78G701	SV	GEAR ANS SHAFT ASSY
3894W13P004	SV	GEAR
3894W15P004	SV	GEAR
3899W22P006	SV	GEAR
3899W22P007	SV	GEAR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
393004-099	SV	FUEL QUANTITY IND.
393004-63421	OH	FUEL QUANTITY IND
393020-01789	OH	IND
393020-01789	SV	INDICATOR
393020-01789	SV	IND
393020-01789	SV	OIL QTY IND
393020-01789	SV	OIL QTY IND
393024-03842	SV	ENG OIL IND
393026-03236	SV	IND
393026-03236	SV	FUEL QUANTITY IND
393026-03236	SV	FUEL QUANTITY IND
393026-03508	SV	FRESH TAG/18 MNTH WTY
393026-03508	OH	FUEL QTY INDICATOR
393026-03508	OH	FUEL QUANTITY IND
393020-01789	OH	OIL QTY IND
393020-01789	OH	OIL QTY IND
393024-03842	OH	ENG OIL IND
393026-03236	OH	IND
393026-03236	OH	FUEL QUANTITY IND
393026-03236	OH	FUEL QUANTITY IND
393026-03508	SV	FRESH TAG/18 MNTH WTY
393026-03508	OH	FUEL QTY INDICATOR
393026-03508	OH	FUEL QUANTITY IND
393026-042	OH	IND
393026-042	OH	IND
393026-042	SV	FUEL QTY IND
393026-042	SV	FUEL QUANTITY IND
10-60520-50	SV	FUEL QTY IND
10-60520-50	OH	FUEL QUANTITY IND
393026-079	OH	IND
393026-079	OH	IND
393026-079	OH	PERCAL FUEL QTY IND
393026-079	OH	FUEL QUANTITY IND
393026-080	OH	IND
393026-080	OH	IND
393026-080	OH	PERCAL FUEL QTY IND
393026-080	OH	FUEL QUANTITY IND
393028-10645	OH	HYD QTY IND
393080-104	OH	TOTAL FUEL /V-REF IN
393080-104	SV	TOTAL FUEL/R REF IND
10-61371-4	OH	TOTAL FUEL /V-REF IN
10-61371-4	SV	TOTAL FUEL/R REF IND
393081-103	OH	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
393081-103	OH	IND
393081-103	OH	FUEL QTY TOTALIZ IND
393081-103	OH	FUEL QTY TOTALIZ IND
393081-105	OH	IND
393081-105	OH	IND
393081-105	OH	FUEL QTY TOTALIZ IND
393081-105	OH	FUEL QTY TOTALIZ IND
393090-103	OH	PRIMARY FUEL QTY IND
393090-103	SV	PRIMARY FULE ATI IND
393090-105	OH	IND
393090-105	OH	IND
393090-105	OH	PRIMARY FUEL QTY IND
393090-107	OH	IND
393090-107	OH	IND
393090-107	OH	PRIMARY FULE QTY IND
393090-107	OH	PRIMARY FUEL QTY IND
393103-107	OH	TAT/RATED EPR IND.
393103-109	OH	IND
393103-109	OH	IND
393103-109	OH	EPR INDICATOR
396-100P1-D1	OH	OIL PRESSURE IND
3S2791G200R11	NE	RELAY
3SM	NE	BULB ASSY
40-300-1	OH	STATIC AIR TEMP IND
40-300-1	OH	IND
40-300-1	OH	IND
40-300-1	OH	STATIC AIR TEMP IND
40-302-101	SV	LIGHT ASSY
40-302-4	OH	TOTAL AIR TEMP IND
40-309-1	OH	TRUE AIRSPEED IND
40-309-1	OH	TRUE AIRSPEED IND
40-309-1	OH	TRUE AIRSPEED IND
40-652-2162	NS	IC
4000052-1	NS	PANEL SMOKE DETCTR
4000136	NE	TRANSFORMER
4003434-902	SV	MODULE ASSY
4004028	SV	GLASS
4004744-1	SV	TRANSOLVER
4004744-2	SV	TRANSOLVER
4005123-901	OH	ALTIMETER
4005123-901	OH	ALTIMETER
4005123-901	OH	ALTIMETER
4012663-904	SV	DETECTOR AMPLIFIER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4015991-901	NE	POWER SUPPLY
4016461-1	SV	SYNCHRO
4031660-2	SV	WEDGE
4039572-1	SV	RESOLVER
4039838-1	SV	MOTOR, DC
4039892-906	OH	BAROMETRIC ALTIMETER
4039892-906	OH	BAROMETRIC
4039892-908	OH	ALTIMETER
4039892-908	OH	ALTIMETER
4039892-908	OH	BAROMETRIC ALTIMETER
4039892-909	OH	BAROMETRIC ALTIMETER
4039892-909	OH	BAROMETRIC ALTIMETER
4039892-911	OH	BAROMETRIC ALTIMETER
4039893-90	OH	VERTICAL SPEED IND
4039893-902	OH	VERTICAL SPEED IND
4039893-902	OH	VERTICAL SPEED IND
4039893-902	OH	IND
4039893-903	OH	IND
4039893-903	OH	IND
4039893-903	OH	VERTICAL SPEED IND
4039893-903	OH	VERTICAL SPEED IND
4043124-903	SV	ANALOG OUTPUT CARD
4043126-901	SV	CIRCUIT CARD
4043128-901	SV	BOARD ASSY
4043128-902	SV	MEMORY I/O CARD
4043132-901	SV	BOARD ASSY
4043134-903	SV	BOARD ASSY
4043142-901	NE	DIAL
4043173-903	SV	BEZEL
4043194	SV	SHAFT
4043495-1	SV	CASE
4043517-902	SV	INDICATOR
4045190-403	SV	PROGRAM IC
4045190-404	SV	PROGRAM IC
4045190-405	SV	PROGRAM IC
4045190-406	SV	PROGRAM IC
405876	OH	CONTROL PANEL
405876	SV	CONTROL PANEL
406809	SV	MOTOR
407-312-0023	SV	WINDOW
407857	OH	IND CONTROL PANEL
407857	OH	IND
407857	OH	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
407857	OH	CONT PANEL IND
408-1159-020	NS	RELAY
4145811P008	NS	CONNECTOR/RECEPTICLE
4136822G004	NS	CONNECTOR ASSY
41470	NE	JEWELL ASSY
4149899G004	SV	JEWEL HOLDER ASSY
417237	NS	TERMINAL
42-27-04-011	NE	DUMMY CASING
42-27-11-011	NE	CAM 5 DEG.
42-89-13-48	NE	DRUM
421503T1	SV	DIAL
433-673-1004-4060	SV	SWITCH LIGHTED PUSH
4381W10P001	NE	HUB
44456	OH	HEIGHT INDICATOR
445604-3	NE	TRANSFORMER
448769	NS	SEALING RING
451778	NE	REACTOR
452525	NS	PIN
455354	NS	DIAL
456764-3	NS	SHAFT ASSY
456764-31	NE	SHAFT
456764-9	NE	SHAFT
458992	NE	BEARING PLATE
46-982-1	NS	CONNECTOR
463404-01235	SV	LIGHTING ASSY
463404-02237	NE	MOD KIT W/O TRANS.
463405-042	SV	DIAL
463405-047	SV	DIAL SCALE
463405-052	SV	DIAL, SCALE
463694	SV	TRANSFORMER
463694	SV	TRANSFORMER
463695	SV	TRASNFORMER
463704	SV	PC BOARD
463738-052	SV	GEAR ASSY
463750	SV	WASHER
463750	SV	WASHER SEALING
463751	SV	POST
463751	SV	POST
463790	SV	PC BOARD ASSY
463790	SV	PC BOARD ASSY
463803-047	SV	TRANSFORMER
463803-047	SV	TRANSFORMER
463935	SV	COVER END PLATE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
463935	SV	COVER, END PLATE
463939	SV	COUNTER
463939	SV	COUNTER
463946	SV	POTENTIOMETER
46463102	SV	SHIELD
46463394	SV	LAMP ASSY
47-003-0067	SV	SWITCH ROTARY
48-1012R-12P7	SV	CONNECTOR
48-60V5M1	OH	ADI
48-60V5M1	OH	ADI
48-60V5M1	OH	ADU
48-60V5M1	OH	ATTITUDE DIRECTOR IN
482-5068-010	SV	FLAG ASSY.
482-5086-010	SV	METER MOVEMENT
2033833-0001	NS	FREQUENCY TAPE
2504524-1	NS	METER
482-5057-010	SV	GS FLAG
482-5053-010	NS	LOC FLAG
482-5087-010	NS	NAV FLAG
482-5087-010	SV	METER MOVEMENT
482-5088-010	NS	SOLENOID
482-5096-010	SV	METER MOVEMENT
482-5098-010	SV	GLIDESLOPE POINTER
482-5101-030	SV	METER FLAG
482-5102-010	SV	GLIDESLOPE FLAG
482-5107-010	NS	METER MOVEMENT
482-5111-010	SV	DATA SOURCE ACTUATOR
482-5114-050	SV	SPEED FLAG
482-5121-010	NE	FLAG ASSY.
482-5142-010	SV	R/T FLAG
482-5144-010	SV	GS FLAG
482-5144-040	SV	GS FLAG
482-5152-010	SV	GYRO FLAG
482-5164-010	NE	METER MOVE
482-5165-010	NE	FLAG ASSY.
482-5170-010	NE	FLAG ASSY,
482-5174-020	NS	SOLENOID FLAG
482-5174-030	NS	SOLENOID FLAG
4864K72P001	NE	LAMP
495013	NS	ASSY
500980-002	SV	WEDGE
50233-4	SV	RUD HYD PRESSURE IND
508-064-001	NE	RESISTOR ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
520-3117-303	OH	RADIO MAGNETIC IND
520-3117-303	OH	IND
520-3117-303	OH	IND
520-3117-303	OH	RADIO MAGNETIC IND
520-3117-303	SV	RADIO MAGNETIC IND
520-3117-303	SV	IND
520-3117-303	SV	IND
520-3117-303	SV	RADIO MAGNETIC IND
520010	SV	NAV FLAG
520063	SV	GLIDESLOPE POINTER
520775	OH	ENGINE VIBRATION IND
521142	OH	IND
521142	OH	IND
521142	OH	APU TACHOMETER IND
522-2782-004	SV	COURSE INDICATOR
522-2782-004	OH	COURSE IND
522-2782-004	OH	COURSE INDICATOR
522-3120-004	OH	INSTRUMENT AMPLIFIER
522-3120-004	OH	INSTRUMENT AMPLIFIER
522-3122-000	OH	IND
522-3122-000	OH	IND
522-3122-000	OH	FLIGHT DIRECTOR IND
522-3122-000	OH	FLIGHT DIRECTOR IND
522-3122-012	OH	IND
522-3122-012	OH	IND
522-3122-012	OH	FLIGHT DIRECTOR IND
522-3122-012	OH	FLIGHT DIRECTOR IND
522-3122-013	OH	IND
522-3122-013	OH	IND
522-3122-013	OH	FLIGHT DIRECTOR IND
522-3122-013	OH	FLIGHT DIRECTOR IND
522-3138-007	OH	IND
522-3138-007	OH	IND
522-3138-007	OH	COURSE IND
522-3138-007	OH	COURSE INDICATOR
522-3343-012	OH	IND
522-3343-012	SV	IND
522-3343-012	OH	DISTANCE INDICATOR
522-3343-012	OH	DISTANCE INDICATOR
522-3874-005	OH	AMPLIFIER
522-3874-005	OH	AMPLIFIER
522-3874-005	OH	INSTRUMENT AMPLIFIER
522-3877-001	OH	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
522-3877-001	OH	IND
522-3877-001	OH	FLIGHT DIRECTOR IND
522-4114-003	OH	RADIO ALTITUDE IND
522-4114-003	OH	IND
522-4430-001	OH	IND
522-4430-001	OH	IND
522-4430-001	OH	FLIGHT DIRECTOR IND
522-4430-002	OH	F. DIR
522-4430-005	OH	FLT DIRECTOR IND
522-4430-005	OH	IND
522-4430-005	OH	IND
522-4430-005	OH	FLIGHT DIRECTOR IND
522-4825-005	OH	RADIO ALTITUDE IND
522-4825-005	OH	RADIO ALTITUDE IND
522-4825-005	OH	RADIO ALTITUDE IND
522-4825-005	OH	IND
522-4825-005	OH	RADIO ALTITUDE IND
522-4825-005	OH	RADIO ALT. IND.
522-4825-005	OH	RADIO ALTITUDE IND
522200	OH	IND
522200	OH	IND
522200	OH	FLOW INDICATOR
532060-001	NE	WEDGE
540-9006-003	SV	POST
541-1232-003	NS	WASHER
541-3617-002	SV	SPRING
544-3521-002	SV	COLLAR
544-3521-003	SV	COLLAR
544-8953-004	SV	GEAR
546-1828-005	SV	COUNTER COURSE
5472811G006	NE	SVS ASSY.
5478299G002	NE	DIFFUSER
548-4941-004	SV	SCALE PITCH
5484200P001	NE	DIAL
554-8965-003	SV	BRACKEET
554-8985-002	SV	GEAR
5601-01	NS	PALLET
5709K81G701	NE	PLT POST ASSY.
5709K81G701	SV	PLATE
5709K81G702	SV	PLATE
57234-900-1	NE	PACKING
5772	NE	POTENTIOMETER
5785K76G715	SV	POINTER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
5910-172	NE	SOLENOID
591976	OH	STATIC AIR TEMP IND
593-1-000	OH	TONE GENERATOR
593-1-000	SV	TONE GENERATOR ASSY
59500000-	OH	DUAL DME INDICATOR
59500000-1	OH	DUAL DME INDICATOR
5987	NS	TUBE
609-3189-002	SV	SCALE SPEED
609-8072-001	NS	CIRCUIT CARD
60B00132-29	OH	N2 TACHOMETER IND
60B00132-29	OH	IND
60B00132-29	OH	N2 TACHOMETER IND
60B00132-29	OH	IND
60B00302-11	OH	IND
60B00302-11	OH	IND
60B00302-11	OH	ENGINE PRES RAT IND
610-129-003	NE	BRACKET
610BL4B	SV	TEMPERATURE IND.
617854-1	OH	TEMP CONT SELECTOR
618379	SV	SERVO AMP
622-4825-005	OH	RADIO ALTITUDE IND
622-5001-104	OH	RADIO DIST MAG IND
622-5001-104	OH	RADIO DIST MAG IND
622-5001-108	SV	RDMI
622-5001-108	OH	RDMI
622-5001-108	OH	RDMI
622-5001-106	SV	RDMI
622-5001-106	OH	RDMI
622-5001-106	OH	RDMI
622-5001-104	SV	RDMI
622-5001-104	OH	RDMI
622-5001-104	OH	RDMI
622-5001-110	SV	RDMI
622-5001-110	OH	RDMI
622-5001-110	OH	RDMI
622-5001-107	SV	RDMI
622-5001-107	OH	RDMI
622-5001-107	OH	RDMI
622-5001-109	OH	RDMI
622-5001-109	OH	RDMI
622-5001-109	OH	RDMI
622-5001-109	OH	RADIO DIST MAG IND
622-5001-109	SV	RADIO DIST MAG IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-5001-111	SV	RADIO DIST MAG IND
622-5001-111	OH	RADIO DIST MAG IND
622-5001-111	OH	RADIO DIST MAG IND
622-5001-111	SV	RDMI
622-5001-112	OH	RADIO DIST MAG IND
622-5001-112	OH	RADIO DIST MAG IND
622-5001-112	SV	RADIO DIST MAG IND
622-5001-114	OH	RADIO DIST MAG IND
622-5001-114	OH	RADIO DIST MAG IND
622-5001-114	SV	RADIO DIST MAG IND
RDMI-743	SV	RADIO DIST MAG IND
622-5001-503	OH	RADIO DIST MAG IND
622-5001-503	OH	RADIO DIST MAG IND
622-5001-503	SV	RADIO DIST MAG IND
622-5001-501	OH	RADIO DIST MAG IND
622-5001-501	OH	RADIO DIST MAG IND
622-5001-501	SV	RADIO DIST MAG IND
622-5001-502	SV	RADIO DIST MAG IND
622-5001-502	OH	RDMI
622-5001-504	OH	RADIO DIST MAG IND
622-5001-504	SV	RDMI
622-5001-504	OH	RADIO DIST MAG IND
622-5001-601	OH	EFIS CONTROL PANEL
622-5001-601	OH	EFIS CONTROL PANEL
622-5001-601	SV	RADIO DIST MAG IND
622-5001-602	OH	EFIS CONTROL PANEL
622-5001-602	OH	EFIS CONTROL PANEL
622-5001-602	SV	RADIO DIST MAG IND
622-5001-701	OH	EFIS CONTROL PANEL
622-5001-701	OH	EFIS CONTROL PANEL
622-5001-701	SV	RADIO DIST MAG IND
622-5048-	OH	EFIS CONTROL PANEL
622-5048-101	OH	EFIS CONTROL PANEL
622-5048-101	OH	EFIS CONTROL PANEL
622-5048-101	OH	EFIS CONTROL PANEL
622-5048-101	OH	EFIS CONTROL PANEL
622-5048-104	OH	EFIS CONTROL PANEL
622-5048-104	SV	EFIS CONTROL PANEL
622-5048-104	OH	EFIS CONTROL PANEL
622-5048-104	OH	EFIS CONTROL PANEL
622-5048-341	OH	EFIS CONTROL PANEL
622-5048-341	OH	EFIS CONTROL PANEL
622-5048-341	OH	EFIS CONTROL PANEL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-5048-341	OH	EFIS CONTROL PANEL
622-5048-341	OH	EFIS CONTROL PANEL
622-5048-343	OH	EFIS CONTROL PANEL
622-5048-344	OH	EFIS CONTROL PANEL
622-5048-344	OH	EFIS CONTROL PANEL
622-5048-344	OH	EFIS CONTROL PANEL
622-5048-344	OH	EFIS CONTROL PANEL
622-5048-361	OH	EFIS CONTROL PANEL
622-5048-361	OH	EFIS CONTROL PANEL
622-5048-361	OH	EFIC CONTRO PANEL
622-5048-381	OH	EFIS CONTROL PANEL
622-5048-381	OH	EFIS CONTROL PANEL
622-5048-381	OH	EFIS CONTROL PANEL
622-8001-001	OH	EFIS CONTROL PANEL
622-8001-001	OH	EFIS CONTROL PANEL
622-8001-001	OH	EFIS CONTROL PANEL
622-8001-001	OH	EFIS CONTROL PANEL
622-8001-001	OH	EFIS CONTROL PANEL
622-8001-002	OH	EFIS CONTROL PANEL
622-8001-002	OH	EFIS CONTROL PANEL
622-8001-002	OH	EFIS CONTROL PANEL
622-8001-002	OH	EFIS CONTROL PANEL
622-8001-003	OH	EFIS CONTROL PANEL
622-8001-003	OH	EFIS CONTROL PANEL
622-8001-003	OH	EFIS CONTROL PANEL
622-8001-330	OH	EFIS CONTROL PANEL
622-8001-330	OH	EFIS CONTROL PANEL
622-8001-330	OH	EFIS CONTROL PANEL
622-8001-330	OH	EFIS CONTROL PANEL
622-8001-331	OH	EFIS CONTROL PANEL
622-8001-331	OH	EFIS CONTROL PANEL
622-8001-331	OH	EFIS CONTROL PANEL
622-8001-331	OH	EFIS CONTROL PANEL
622-8001-331	OH	EFIS CONTROL PANEL
622-8001-332	OH	EFIS CONTROL PANEL
622-8001-332	OH	EFIS CONTROL PANEL
622-8001-332	OH	EFIS CONTROL PANEL
622-8001-350	OH	EFIS CONTROL PANEL
622-8001-350	OH	EFIS CONTROL PANEL
622-8001-350	OH	EFIS CONTROL PANEL
622-8001-350	OH	EFIS CONTROL PANEL
622-8001-351	OH	EFIS CONTROL PANEL
622-8001-351	OH	EFIS CONTROL PANEL
622-8001-351	OH	EFIS CONTROL PANEL
622-8001-352	OH	EFIS CONTROL PANEL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-8001-352	OH	EFIS CONTROL PANEL
622-8001-352	OH	EFIS CONTROL PANEL
622-8001-352	OH	EFIS CONTROL PANEL
622-8001-370	OH	EFIS CONTROL PANEL
622-8001-370	OH	EFIS CONTROL PANEL
622-8001-370	OH	EFIS CONTROL PANEL
6227	NE	POTENTIOMETER
629-8391-001	NE	POWER SUPPLY
629-8391-001	SV	POWER SUPPLY
630-1001-007	SV	CAP ASSY
630-1001-012	SV	CAP ASSY
630-1001-003	SV	CAP ASSY
630-1001-004	SV	CAP ASSY
630-1001-005	SV	CAP ASSY
630-1001-006	SV	CAP ASSY
630-1001-002	SV	CAP ASSY
63657B	NS	CAP
638-2819-001	NE	CIRCUIT CARD ASSY
642-4586-003	SV	CIRCUIT CARD
646-5157-001	SV	WASHER, FALT
646-5209-001	SV	MASK
646-5209-003	SV	MASK
6465K53P001	SV	SCALEPLATE
6465K60P001	NE	DIAL
6466K19P001	NE	SCALE
6466K33P001	NE	DIAL
6466K57P001	NE	SCALE
65-37328-5	NS	MAP LIGHT
65-37328-5	OH	MAP LIGHT
65-52803-8	OH	WNDW HEAT ACCS U ASY
65-52803-8	OH	WINDOW HEAT ACC UNIT
65-52819-TS	SV	STALL WAR TEST SET
65-52822-3	OH	STALL MANAGEMENT
65-52822-3	OH	MODULE ASSY
65-52822-3	OH	STALL MANAGEMENT
65-52822-7	OH	MODULE ASSY
65-52822-7A	OH	MODULE ASSY
651-2197-001	SV	PLATE, SWITCH-MODE
651-2254-001	SV	BUSHING, CLUCK
651-2256-002	SV	CLUTCH
651-2276-001	SV	IC PROM
659-8319-001	SV	MOUNTING PLATE
659-8321-001	SV	PANEL ASSY, FRONT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
659-8326-001	SV	SPACER
65B47598-7	SV	GUST RESPONSE COMP
6650K43P001	SV	PLATE
665362	NS	TRANSFORMER
674-1031-2015	SV	CAP ASSY
674-1031-2097	SV	CAP ASSY
685835	NE	RELAY
69-37319-39	OH	MODULE
69-37319-39	OH	MODULE ASSY,AIR COND
69-37328-5	OH	MAP LIGHT MOD ASSY
69-37328-5	OH	MAP LIGHT MOD ASSY
69-37328-5	OH	MAP LIGHT MOD ASSY
69-37328-5	OH	MAP LIGHT MOD ASSY
69-60730-1	OH	PC BOARD
69-60730-1	SV	PC ASSY, MASTER
69-75986-4	SV	PROGRAM MEMORY
692757-1	SV	CTR RADAR
7000041-46	NE	CAPACITOR
700662A	OH	LOAD CONTROLLER
70509-0001	NE	I.C.
70653-0001	NS	IC
710-914	OH	TOTALIZER INDICATOR
710-914	OH	TOTALIZER INDICATOR
710-914	SV	TOTALIZER INDICATOR
712B922B	NS	DRUM
7153AS15TPL	NE	LAMP
721985	NS	SOCKET
724124-1	NE	TRANSFORMER
730432-13	NS	CLIP CAP
735560-4	NS	RELAY
736913	NE	RING ASSY
739852-1	NE	STATOR
754-0301-001	OH	LIGHT PLATE
754-0301-003	SV	LIGHTPLATE
754-0301-003	SV	LIGHTPLATE
754-0301-005	SV	LIGHTPLATE
754-0301-005	OH	LIGHT PLATE
754-0529-001	SV	LIGHTPLATE
756-9833-001	SV	SPACER
757-0872-003	NE	PLUG
757-3332-001	SV	GEAR ASSY
757-3354-002	SV	KNOB
761-3220-001	SV	CASE INSTRUMENT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
761-3225-003	SV	MASK
761-3231-001	SV	GEAR
761-3232-001	SV	GEAR
761-3233-001	SV	GEARSHAFT
761-3237-002	SV	GEARSHAFT
761-3238-001	SV	GEAR
761-3242-001	SV	GEAR, SPUR
761-3244-002	SV	BLOCK
761-3250-001	SV	SPACER
761-3250-003	SV	SPACER
761-3250-004	SV	SPACER
761-3251-001	SV	GUIDE TAPE
761-3253-001	SV	GEAR SHAFT
761-3254-001	SV	GEAR SHAFT
761-3257-002	SV	SHAFT
761-3260-001	SV	GEAR CLUSTER
761-3260-002	SV	GEAR CLUSTER
761-3260-004	SV	GEAR CLUSTER
761-3265-001	SV	SPACER
761-3267-001	SV	BRACKET, SWITCH
761-3271-001	SV	SPRING
761-3272-001	SV	POST
761-3273-001	SV	STOP ASSEMBLY
761-3282-001	SV	KNOB
761-3286-001	SV	MASK
761-3286-002	SV	MASK
761-3292-001	SV	PLATE RETAINING
761-3294-001	SV	PLATE RETAINING
761-3295-001	SV	PLATE
761-3296-001	SV	PLATE
761-3298-001	SV	BRACKET
761-3304-003	SV	TAPE, RUNWAY
761-3305-002	SV	COVER
761-3307-001	SV	STOP
761-3311-001	SV	GEAR SPAR
761-3314-001	SV	SPRING
761-3316-001	SV	GEAR
761-7786-004	SV	ELEC COMPONENT ASSY
761-7789-001	SV	PLATE MTG
761-7798-001	SV	GEAR SHAFT
761-7801-001	SV	PLATE MTG
761-7807-003	SV	TAPE DRUM ASSEMBLY
761-7810-001	SV	PLATE RETAINING



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
761-7812-001	SV	LIGHT ASSEMBLY
761-7813-001	SV	LIGHT ASSEMBLY
761-8797-001	SV	BAR
761-8797-002	SV	CAMMAND BAR
763-6036-001	SV	PC BOARD, LIGHT
763-6096-001	SV	DIAL
767-8210-001	SV	STOP, RIGID
767-8215-002	SV	GEAR SPUR
767-8217-001	SV	MASK
768-7453-001	SV	TAPE
775-5320-001	NS	SPRING
768-9077-001	SV	COMMNAD BAR
775-5362-002	SV	SPACER
775-5391-001	SV	BOARD
775-5391-001	SV	MASK
775-5572-001	NS	HEADING KNOB
775-5572-002	NS	KNOB
775-5573-002	SV	KNOB, COURSE
775-5345-001	SV	ROLLER ASSY
522-4825-004	OH	RADIO ALT IND
522-4825-004	SV	RADIO ALT IND
772-5005-001	SV	FLIGHT DIRECTOR IND
772-5005-005	SV	FLIGHT DIRECTOR IND
772-5005-009	SV	FLIGHT DIRECTOR IND
772-0628-001	NE	METER
775-5034-001	SV	GEAR
775-5038-001	NS	COLLAR
775-5074-001	NS	PIN
775-5140-001	SV	COUNTER,ROTATING
775-5191-001	NS	GEAR SHAFT
775-5314-001	NS	CLAMP
775-5082-001	NS	SPRING
775-5040-001	NS	SPACER
775-5040-001	SV	SPACER
775-5082-001	NS	SPRING DETENT
775-5090-001	SV	PRIMS, LIGHT
775-5108-001	NS	RING
775-5119-001	NS	WEAR SHAFT
775-5120-001	NS	GEAR SHAFT
775-5122-002	NS	GEAR SHAFT
775-5135-001	SV	CASE ASSY
775-5138-001	NS	SPIDER
775-5138-001	SV	SPRIDER DIFFERENTIAL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
775-5138-002	SV	SPRIDER, DIFFERENTIA
775-5250-001	SV	DH TAPE
775-5318-001	NS	GEAR
775-5333-001	NS	CLUSTER GEAR
777-1083-001	OH	H.S.I.
777-3043-002	SV	COLLAR
778-0386-001	SV	FRICITION CLUTCH
778-0387-002	SV	SHAFT ASSY
778-1307-001	SV	SCALE, GS
778-1340-002	SV	GEAR, SPUR
778-1351-001	SV	GEAR, SPUR
778-1417-001	SV	GEAR ASSY
778-1439-001	SV	SECTOR ASSY, RH
778-1448-001	SV	INCLINOMETER
779-3122-001	NE	GEAR
779-3423-001	SV	GEAR SHAFT
779-3452-001	SV	PLATE SWITCH
779-3483-001	SV	KNOB, COURSE
779-3492-001	SV	KNOB HEADING
779-3531-001	SV	COLLAR, BRAKE
779-3580-001	SV	BRAKE, GEAR
779-3581-001	SV	BRAKE, GEAR
779-3799-001	OH	DIAL
7834K73P010	SV	SPACER
7834K73P10	NS	SPACER
787-6045-001	OH	SURF. POS. IND
787-6766-001	OH	ATT.DIR. IND
791-2369-001	NE	TAPE
791-2369-002	NE	TAPE INDICATOR
791-2433-001	NS	COLLAR HUB
791-2434-001	SV	GEAR
791-2435-001	SV	GEAR SHAFT
791-2436-002	NS	GEAR SPUR
791-2439-001	SV	GEARSHAFT
791-2445-001	SV	GEAR
791-2449-001	SV	GEAR
791-2454-001	SV	DIAL
791-2485-001	SV	PLATE
792-0595-001	SV	GEAR ASSY
799046	SV	CURSOR CTR
806677	NS	STATOR
814187	SV	TRANSFORMER
818651	NS	GEAR TRAIN



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
836-7035-005	OH	LIGHT PLATE
841-011-001	SV	VOLTAGE REGULATOR
841-011-002	NS	TRANSFORMER
841-025-001	NS	TRANSFORMER
865D909	NS	DIAPHRAM
871231	NS	PINION
875884	NS	SPRING
88000-4102	OH	CLOCK
88000-4103	OH	CLOCK
88000-4103	OH	CLOCK
88000-4104	OH	CLOCK
88000-4104	OH	CLOCK
881637	NS	SIDE COVER ACCESS.
8900801G002	SV	XDUCER PRESS
8905884G130	SV	CAN ASSY
8905884G155	NS	CAN ASSEMBLY
8905884G155	SV	CASE ASSY
8DJ125LWT3	OH	F.F INDICATOR
8DJ125LWX3	OH	FLOWMETER INDICATOR
8DJ125LXD5	OH	F.F IND
8DJ125LXG4	OH	FLOWMETER INDICATOR
8DJ125LXG4U	SV	FLOWMETER IND
8DJ125LXG5	OH	F/FLOW USED/RATE IND
8DJ125LXH2	OH	FUEL FOLOW IND.
8DJ125LXW5	OH	F.F IND
8DJ125LXX5	OH	FUEL/FLOW RATE USED
8DJ125LXX5	OH	F/FLOW RATE/USED IND
8DJ125LYT4	OH	FLOWMETER IND
8DJ162LXH2	SV	N2 TACHOMETER IND
8DJ162LXL2	OH	N1 TACHOMETER IND
8DJ162LXL2	OH	TACHOMETER INDICATOR
8DJ162LZL2	OH	N2 TACHOMETER IND
8DJ162LZL2	OH	N2 TACHOMETER IND
8DJ171LWA3	SV	FUEL FLOW IND
8DJ172LWA1	OH	OIL QTY IUND
8DJ172LWA1	OH	INDICATOR
8DJ172LWA1	OH	INDICTOR
8DJ173LWD1	OH	OIL QTY IND
8DJ173LWD1	SV	OIL QUANTITY IND.
8DJ173LWD1	OH	OIL QUANTITY IND.
8DJ173LWD1	SV	OIL QTY IND
8DJ175LWT2	OH	EGT INDICATOR
8DJ175LWT2	OH	EGT INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
8DJ176LXW1	OH	ENGINE SPEED IND
8DJ176LXW1	SV	ENGINE SPEED IND.
8DJ176LXW1	OH	ENGINE SPEED IND.
8DJ176LZD2	OH	ENGINE FAN SPEED IND
8DJ176LZD2	OH	ENGINE FAN SPEED IND
8DJ176LZF2	OH	ENG CORE SPEED IND
8DJ176WAP2	OH	INDICATOR
8DJ176WAP2	OH	INDICATOR
8DJ177LWN1	OH	TEMPERATURE IND
8DJ177LWN1	SV	TEMPERATURE IND.
8DJ177LWN1	OH	TEMPERATURE IND.
8DJ177LWR1	OH	TEMPERATURE IND
8DJ177LWR1	SV	TEMPERATURE IND.
8DJ177LWR1	OH	TEMPERATURE IND.
8DJ185LWP1	OH	TURBINE GAS TEMP IND
8DJ186LWW1	SV	ENGINE SPEED IND.
8DJ81CBD4	SV	INDICATOR
8DJ811LXF2	OH	TACHOMETER IND
8DJ81LWT4	OH	TACHOMETER INDICATOR
8DJ81LWT4	OH	TACHOMETER INDICATOR
8DJ81LWT4	OH	TACHOMETER INDICATOR
8DJ81LWT4-U	OH	TACHOMETER INDICATOR
8DJ81LXH2	OH	TECHOMETER IND
8DJ81LXH2	OH	TACHOMETER IND
8DJ81LXP2	OH	TACHOMETER IND
8DJ81LXP2	OH	TACHOMETER IND
8DJ86LAH1	OH	FUEL FLOW INDICATOR
8KE25GAC1	OH	FUEL FLOW AMPLIFIER
8KE25GAC1	OH	FUEL FLOW AMP.
8TJ81LWT4-U	OH	TACHOMETER INDICATOR
8TJ88GAN3	OH	FUEL FLOW PWR SUPPLY
8TJ88GAN3	OH	FUEL FLOW PWR SUPPLY
8TJ88GAN3	OH	FUEL FLOW PWR SUPPLY
8TJ88GAN3	OH	FUEL FLOW PWR SUPPLY
8TJ88GBN4	OH	FUEL FLOW POWER SUP.
9-102	OH	FUEL USED INDICATOR
9-102	OH	FUEL USED INDICATOR
9-102	OH	FUEL USED INDICATOR
9-113-09	SV	F/F ELECT PACK
9-113023-03	SV	CRYSTAL
9005-21	SV	MOLDED HOUSING
915F212-6	OH	GENERATOR CNTRL UNIT
950563-1	SV	PRISM



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
9560831-1	SV	ANTI SKID TEST SET
9561006-3R	OH	SKID CONTROL UNIT
9599-607-12118	OH	HEIGHT INDICATOR
9599-607-12118	OH	HEIGHT INDICATOR
9599-607-12118	OH	HEIGHT INDICATOR
974-1065-010	NS	RELAY
974-1065-180	NS	RELAY, AMT
974-1082-020	NS	RELAY ARM
9783055P001	NS	SHAFT GEAR
9819-29	SV	CONT SURF POSIT IND
9819-90-01	OH	FLAP POSITION IND
9819-90-01	OH	FLAP POSITION IND
9819-93-05	OH	FLAP POSITION IND
9819-93-05	OH	FLAP POSITION IND
9850354G017	SV	GEAR & PINION ASSY
9850354G020	SV	GEAR
9886059G001	NS	ROTOR
9886950G003	NS	STATOR ASSY
989993-1	SV	DIAL
989994-1	SV	DIAL
989995-1	SV	DIAL
989997-1	SV	DIAL
A-12	NE	EPOXY-ADHESIVE
A16744	SV	TRANSFORMER
A2005841	SV	TORQUE POT
A2005841	SV	TORQUE POT
A30357-10-006	SV	DIFF.PRESS IND
A32437-10-021	OH	TACOMETER IND.
AM2716/BJA	SV	IC
B0650-71107-1	OH	ALTITUDE ALERT CONT
B0650-71110-1	OH	ALTITUDE ALTER CONTR
B0650-71110-1	OH	ALTITUDE ALERT CONT
B0652-71110-1	OH	ALTITUDE ALERT CONT
B0652-71108-1	OH	ALTITUDE ALERT CONT
B0652-71110-1	SV	ALTITUDE ALERT CONT
B0652-71108-1	SV	ALTITUDE ALERT CONT
B1077-3	OH	OIL QUANTITY IND
B1077-3	OH	OIL QUANTITY IND.
B1123-3464	NE	TANK UNIT
B118-244	OH	FUEL QTY IND
B118-244	OH	FUEL QTY IND
B118-244	OH	FUEL QTY IND
B118-313W	OH	FUEL QTY IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
B118-313W	OH	FUEL QTY IND.
B175-22W	OH	FUEL QUANTITY IND
B175-22W	OH	FUEL QTY IND
B175-28W	OH	FUEL QTY IND
B175-28W	OH	FUEL QTY TOTALIZ IND
B1800-81103	OH	ALTITUDE IND
B1800-81103	OH	ALTITUDE IND
B1800-81103	OH	ALTITUDE IND
B294C-3	OH	OIL QUANTITY IND
B294C-3W	OH	OIL QTY IND
B294C-3W	OH	OIL QTY. IND
B36337-10-001	SV	TRUE AISPEED IND
B37523-19	SV	GEAR
B37524-22	SV	GEAR
B4B-22	NS	CAPACITOR
B711-1	OH	HYD. OIL QTY.IND
B711-1	OH	HYD OIL QTY IND
B852-12	SV	FUEL QUANTITY IND
BAC27DEX5461	NE	MARKER
BACS21DX1B	NE	STUD
BH4654AY	NE	STOP, TOP
BRAYCO 589	NE	LUBRICANT
BRAYCO 589	NE	CORROSIVE PRESERVATI
C29187-10-005	OH	PRESSURE RATIO IND
C29187-10-005	SV	PRESSURE RATIO IND
C29187-10-021	OH	PRESSURE RATION IND
C29187-10-021	OH	PRESSURE RATIO IND.
C556002104-6	SV	DRAG CUP
CDSH-5-A-4/L558	SV	DIFFERENTIAL RESOLVE
CM-7714	NS	LAMP
CM41005018	SV	SYNCHRO TRANSOLVER
CRC-10-PS-1/A434	SV	SYNCHRO RECEIVER
CT-10-JS-4/A004	SV	CONTROL TRANSFORMER
D434-36-001	OH	FLT MODE ANNUNCIATOR
D434-36-001	OH	FLT MODE ANNUNCIATOR
D434-36-001	OH	FLT MODE ANNUNCIATOR
DSF508-4	OH	OIL QUANTITY IND
DSF508-4	OH	OIL QTY IND
DSF508-4	OH	OIL QUANTITY IND
EDSH8XH2L705	SV	DIFFERENTIAL RESOLVE
ERH-10-DUS-04/B924	SV	SYNCHRO RECEIVER
ERH-8-XZ-07/F555	SV	SYNCHRO
ERH10DUS03B595	SV	SYNCHRO RECEIVER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
ERH10DUS04F554	SV	SYNCHRO RECEIVER
ERH8XZ03L736	SV	SYNCHRO
ERH8XZ07L896A	SV	SYNCHRO
ERH8XZ07L930A	SV	SYNCHRO
F310-0091	SV	CAPACITOR
GG-18-A1	NS	SYNCHRO ASSY
GG-18-A2	NS	SYNCHRO ASSY
HA1-4741-2	NS	IC
HA2-2640-2	NS	I.C.
835-0313-020	NS	I.C.
HSI-3182-8	NS	IC
INCLINOMETER	BS	FOR ALL ADI / FDI
INCLINOMETER	NE	WE MFG FOR SIMULATOR
INCLINOMETER	NE	SKIDBALL
JANTX2N4859	NE	TRANSISTOR
JG1052AC03	OH	ALTITUDE ALERT IND
JG1052AC03	OH	ALTITUDE ALERT IND
JG1052AC03	OH	ALTITUDE ALERT IND
JG1208AA02	OH	LOAD SELECT IND
JG298A5	OH	PRESSURE RATION IND
JG298A5	OH	PRESSURE RATION IND
JG298A5	OH	PRESSURE RATIO IND
JG298A5	OH	PRESSURE RATIO IND
JG298H4	OH	E.P.R. IND
JG603C2	OH	FUEL QTY IND
JG603C2	OH	FUEL QTY.IND.
JG603C3	OH	FUEL QTY IND
JG603C3	OH	FUEL QTY. IND.
JG603C3	SV	FUEL QTY IND
JG603C4	OH	FUEL QUANTITY IND
JG603C4	OH	FUEL QTY IND
JG603C44	OH	FUEL QUANTITY IND
JG603C44	OH	FUEL QUANTITY IND
JG603C44	OH	FUEL QUANTITY IND
JG613C45	OH	TOTAL FUEL QTY IND
JG908A17	SV	RAT/EPR IND
JG908A17	OH	RAT/EPR IND
JG908A18	OH	RAT/EPR INDICATOR
JG908A18	OH	TEMP/E.P.R. IND.
JG908A58	OH	RAT/EPR INDICATOR
JG908A58	SV	E.P.R. IND
JG908A1	OH	RAT/EPR INDICATOR
JG908A1	SV	E.P.R. IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
JG908A3	OH	RAT/EPR INDICATOR
JG908A3	SV	E.P.R. IND
JG908A19	OH	RAT/EPR INDICATOR
JG908A19	OH	E.P.R. IND
JG908A21	OH	RAT/EPR INDICATOR
JG908A21	OH	E.P.R. IND
JG908A25	OH	RAT/EPR INDICATOR
JG908A25	OH	E.P.R. IND
LIBB-E32	OH	POSITION INDICATOR
LIBBE32	OH	POSITION INDICATOR
M9071-76	SV	GLIDESLOPE FLAG
M9071-97	SV	GLIDESLOPE FLAG
M907146	SV	RUNWAY FLAG
M9073-25	SV	GLIDESLOPE POINTER
M907325	SV	GLIDESLOPE POINTER
MAP-LIGHT-MOD-ASSY	OH	18 MO WARRANTY
MML-034	SV	METER MOVEMENT
MOLYKOTE-TYPE-GN	NE	METAL ASSY PASTE
MS16632-1025	SV	RING, RETAINING
OL-7153AS15TPL	NE	LAMP
OL6839BPE	NE	LAMP
P1C6050	SV	SEMICONDUCTOR DEVICE
PIC6050	SV	SEMICONDUCTOR DEVICE
PZ97V11PBG18P	NE	BEARING
R1062-12	SV	IC
RD240-117	NE	KNOB
RI062-12	SV	IC
RJR26FX202P	SV	VARIABLE RESISTOR
RN60C2001F	SV	RESISTOR
RN60C5620F	NS	RESISTOR
RSHX-110	NS	RELAY
RT12C2Y202	SV	POTENTIOMETER
S-1412	SV	DIAL
S-1816	SV	SCALE PLATE
S2223A	SV	DIAL
S3805A	SV	DIAL
S3805E	SV	DIAL
S5305B	SV	DIAL
SA9-19010	SV	RESISTOR
SA9-1910	SV	RESISTOR
SA9-9090	SV	RESISTRO
SEL-OC3B	OH	FUEL PRESSURE IND
SEL-OC3B	OH	FUEL PRESSURE IND.



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
SKID BALL	NE	FOR ALL ADI / FDI
SKIDBALL	NE	INCLINOMETER
SKIDBALL-SIMULATED	NE	INCLINOMETER, SIMU
SLIPBALL	NE	INCLINOMETER
SLIPBALL	NE	FOR ALL ADI / FDI
SLIPBALL	NE	INCLINOMETER
SN19400	SV	IC
SN24772J	SV	IC
SP327	OH	SURFACE POSIT TESTER
SR-O7B	OH	HYD ORESSURE IND
SR-O7B	OH	HYD PRESSURE IND
SR2-5SSX2K4011	SV	BEARING
ST8111	SV	MOTOR TACH GENERATOR
T3002409	NE	ANVIL ALIGNING TOOL
T429695	NE	SPANNER WRENCH
TDSH11HR1	SV	TRANSOLVER
TMS9980AJDL	NS	IC
X28VC256SI55	NS	IC
70-1898	NS	IC
Z850X60C01	NS	BEARING
Z850X6C01	NS	BEARING
149155-01-02	OH	INDICATOR
2592920-444	OH	INDICATOR
2592920-444	SV	INDICATOR
SRDL-OC7E	OH	INDICATOR
777-1825-001	OH	INDICATOR
7000466-906	OH	INDICATOR
63600-456-2	OH	INDICATOR
63600-271-1	OH	INDICAOR
61531-005-1	OH	INDICATOR
622-4938-027	OH	RADIO MAGNETIC INDICATOR
OPA544T	NE	IC
63600-271-1	OH	INDICATOR - EGT
393026-092	OH	INDICATOR
393026-092	SV	INDICATOR
393026-095	OH	PRECAL FUEL QTY IND
393026-095	SV	PRECAL FUEL QTY IND
622-4563-008	OH	INDICATOR
2083-10-1	OH	INDICATOR
2083-10-1	SV	INDICATOR
2610-07-1	OH	INDICATOR
522-4114-008	OH	INDICATOR
1784460-655	OH	INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-4563-004	OH	INDICATOR
115099-6	OH	INDICATOR
115099-8	OH	INDICATOR
2047-01-1	OH	EPR INDICATOR
2048-01-1	OH	EPR INDICATOR
2050-01-1	OH	SERVOED ALTITUDE IND
2054-01-1	OH	ALTITUDE IND
2055-01-1	OH	SERVOED ALTITUDE IND
2057-01-1	OH	ALTITUDE IND
2057-02-1	OH	ALTITUDE IND
2061-11-1	OH	FLAP POSITION INDICA
2083-11-1	OH	MACH AIRSPEED IND
2083-11-1	SV	MACH AIRSPEED IND
2091-11-1	OH	EGT INDICATOR
113515	OH	HORIZONTAL SITUATION
114.029	OH	POSITION INDICATOR
114.035	OH	POSITION INDICATOR
114.062	OH	DC AMMETER
114.114	OH	IND
114.114-1	OH	IND
114.115	OH	IND
114.115-1	OH	IND
114.129	OH	POSITION INDICATOR
114.129-1	OH	POSITION INDICATOR
115.099-5	OH	HYDRAULIC PRESS IND
115.099-6	OH	BRAKE PRESSURE IND
115.099-6	SV	BRAKE PRESSURE IND
115.099-6	OH	BRAKE PRESSURE IND
115.099-5	SV	HYDRAULIC PRESS IND
115.099-7	OH	BRAKE PRESSURE IND
115.099-8	OH	BRAKE PRESSURE IND
115.099-9	OH	BRAKE PRESSURE IND
115.159	OH	TEMP INDICATOR
115.159-1	OH	TEMP INDICATOR
115.163	OH	TEMP INDICATOR
115.163-1	OH	TEMP INDICATOR
2061-12-1	OH	FLAP POSITION INDICA
10-61926-2	OH	FLAP POSITION INDICA
2061-12-1	SV	FLAP POSITION INDICA
10-61926-2	SV	FLAP POSITION INDICA
130502-5	OH	CABIN PRESS SLCTR
130502-6	OH	CABIN PRESS SLCTR
130590-1	OH	CABIN AIR PRESSURE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
149150-01-01	OH	ADI
149150-01-02	OH	ADI
149155-01-01	OH	ADI
149155-01-02	OH	ADI
149270-01-01	OH	TAT / EPR LIMIT IND
149270-03-01	OH	TAT / EPR LIMIT IND
149270-04-01	OH	TAT / EPR LIMIT IND
149270-05-01	OH	TAT / EPR LIMIT IND
162BL501	OH	TAT INDICATOR
162BL502	OH	RAM AIR TEMP INDICAT
162BL503	OH	TEMP INDICATOR
162BL504	OH	DUCT TEMP IND
162BL505	OH	TEMP INDICATOR
162BL602	OH	OIL TEMP INDICATOR
162BL701	OH	FUEL TEMP INDICATOR
162BL701A	OH	TEMP INDICATOR
162BL702	OH	OIL TEMP INDICATOR
162BL703	OH	OIL TEMP INDICATOR
162BL704	OH	OIL TEMP INDICATOR
162BL704A	OH	OIL TEMP INDICATOR
162BL704C	OH	OIL TEMP INDICATOR
162BL704D	OH	OIL TEMP INDICATOR
162BL704F	OH	OIL TEMP INDICATOR
162BL704H	OH	OIL TEMP INDICATOR
162BL704K	OH	AUX HYD TEMP IND
162BL704L	OH	HYD TEMP INDICATOR
162BL704N	OH	OIL TEMP INDICATOR
162BL708	OH	CABIN TEMP INDICATOR
162BL709	OH	OIL TEMP INDICATOR
162BL709A	OH	OIL TEMP INDICATOR
162BL709B	OH	OIL TEMP INDICATOR
162BL710	OH	RAM AIR TEMP INDICAT
162BL711	OH	CABIN TEMP INDICATOR
162BL801	OH	FUEL TEMP INDICATOR
162BL802	OH	OIL TEMP INDICATOR
162BL802A	OH	OIL TEMP INDICATOR
162BL803	OH	OIL TEMP INDICATOR
162BL803A	OH	OIL TEMP INDICATOR
162BL804A	OH	OIL TEMP INDICATOR
162BL901	OH	TAT INDICATOR
162BL902	OH	TEMP INDICATOR
162BL903	OH	TEMP INDICATOR
162BL907	OH	TAT INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1776001-154	OH	INDICATOR
1776001-354	OH	INDICATOR
176365-201	OH	HORIZON FLIGHT DIREC
176365-202	OH	HORIZON FLIGHT DIREC
176365-205	OH	HORIZON FLIGHT DIREC
176365-207	OH	HORIZON FLIGHT DIREC
176365-208	OH	HORIZON FLIGHT DIREC
622-5002-207	OH	RADIO MAGNETIC INDICATOR
622-5002-207	SV	RADIO MAGNETIC INDICATOR
622-5002-207	OH	RADIO MAGNETIC INDICATOR
622-5002-203	OH	RADIO MAGNETIC INDICATOR
622-5002-203	SV	RADIO MAGNETIC INDICATOR
622-5002-205	SV	RADIO MAGNETIC INDICATOR
622-5002-205	OH	RADIO MAGNETIC INDICATOR
622-4563-008	OH	INDICATOR
522-4529-004	OH	INDICATOR
JG1052BC01	OH	INDICATOR
SRDL-6D	OH	INDICATOR
482-5084-010	SV	METER MOVEMENT
229-2022-010	SV	SYNCHRO
772-5370-002	SV	INDICATOR
152BCL4B	SV	EGT INDICATOR
152BCL4	SV	INDICATOR
152BCL4D	SV	EGT INDICATOR
152BCL4D	OH	EGT INDICATOR
152BCL4B	OH	EGT INDICATOR
152BCL4	OH	INDICATOR
152BCL4F	OH	EGT INDICATOR
152BCL4F	SV	EGT INDICATOR
152BCL4G2	OH	EGT INDICATOR
152BCL4G2	SV	EGT INDICATOR
152BCL4J	OH	EGT INDICATOR
152BCL4J	SV	EGT INDICATOR
152BCL4P	OH	EGT INDICATOR
152BCL4P	SV	EGT INDICATOR
152BCL4S	OH	EGT INDICATOR
152BCL4S	SV	EGT INDICATOR
152BCL4W	OH	EGT INDICATOR
152BCL4W	SV	EGT INDICATOR
152BL702	OH	EGT INDICATOR
152BL702A	SV	EGT INDICATOR
152BL702D	OH	EGT INDICATOR
152BL702E	SV	EGT INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
152BCL4W	OH	EGT INDICATOR
152BCL4W	SV	EGT INDICATOR
152BL702	OH	EGT INDICATOR
152BL702A	OH	EGT INDICATOR
152BL702D	SV	EGT INDICATOR
152BL702E	OH	EGT INDICATOR
152BL705	SV	EGT INDICATOR
152BL705	OH	EGT INDICATOR
152BL705A	SV	EGT INDICATOR
152BL705A	OH	EGT INDICATOR
152BL705E	SV	EGT INDICATOR
152BL705E	OH	EGT INDICATOR
152BL705F	SV	EGT INDICATOR
152BL705F	OH	EGT INDICATOR
152BL705G	SV	EGT INDICATOR
152BL705G	OH	EGT INDICATOR
152BL705H	SV	EGT INDICATOR
152BL705H	OH	EGT INDICATOR
152BL705J	SV	EGT INDICATOR
152BL705J	OH	EGT INDICATOR
152BL705L	SV	EGT INDICATOR
152BL705L	OH	EGT INDICATOR
152BL705N	SV	EGT INDICATOR
152BL705N	OH	EGT INDICATOR
152BL705P	SV	EGT INDICATOR
152BL705P	OH	EGT INDICATOR
152BL705R	SV	EGT INDICATOR
152BL705R	OH	EGT INDICATOR
152BL705S	SV	EGT INDICATOR
152BL705S	OH	EGT INDICATOR
152BL706	OH	EGT INDICATOR
152BL708	SV	EGT INDICATOR
152BL708A	OH	EGT INDICATOR
152BL708H	OH	EGT INDICATOR
152BL709	SV	EGT INDICATOR
152BL801	OH	EGT INDICATOR
152BL801	SV	EGT INDICATOR
152BL801A	OH	EGT INDICATOR
152BL801A	SV	EGT INDICATOR
152BL801C	OH	EGT INDICATOR
152BL801C	SV	EGT INDICATOR
152BL801D	OH	EGT INDICATOR
152BL801D	SV	EGT INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
152BL801E	OH	EGT INDICATOR
152BL801E	SV	EGT INDICATOR
792-6357-001	SV	EGT INDICATOR
792-6357-001	OH	EGT INDICATOR
792-6357-002	SV	EGT INDICATOR
792-6357-002	OH	EGT INDICATOR
792-6357-007	SV	EGT INDICATOR
792-6357-007	OH	EGT INDICATOR
792-6357-008	SV	EGT INDICATOR
792-6357-008	OH	EGT INDICATOR
792-6357-011	SV	EGT INDICATOR
792-6357-011	OH	EGT INDICATOR
622-3672-001	SV	EGT INDICATOR
61531-005-1	OH	INDICATOR
61531-005-1	SV	INDICATOR
JG105BC01	SV	INDICATOR
622-4938-027	OH	INDICATOR
622-4938-027	SV	INDICATOR
2594624-906	OH	INDICATOR
2594624-906	SV	INDICATOR
393026-092	OH	INDICATOR
393026-092	SV	INDICATOR
4016341-906	OH	INDICATOR
520-3137-304	OH	INDICATOR
520-3137-304	SV	INDICATOR
3137LB63C	OH	INDICATOR
3137LB63C	SV	INDICATOR
4016341-903	OH	BAROMETRIC ALT IND
4016341-903	SV	BAROMETRIC ALT IND
4016341-905	OH	BAROMETRIC ALT IND
4016341-905	SV	BAROMETRIC ALT IND
522-2638-001	SV	INDICATOR
522-2638-001	OH	INDICATOR
11046-MD	NS	VIBRATOR MOTOR
11195	NS	REPLACEMENT HANDLE
11195-TL	NS	REPLACEMENT HANDLE
11319-3	NS	SWITCH
11661	NS	INSERT
118960-003	NS	IC
118961-002	NS	IC
118H	NS	POTENTIOMETER
119954-01	NS	TUBE FILTER
11A619	NS	END BELL ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
121275	NS	VARIABLE TRANSFORMER
1215813-1	NS	RESISTOR
12195-PS	NS	POWER SUPPLY
12227TR	NS	TRANSFORMER
1231438-1	NS	TRANSFORMER
1239751-1	NS	TRANSFORMER
12494-CH	NS	CHOKE
1249746-2	NS	TERMINAL
1255097-1	NS	COVER
1255106-1	NS	PIVOT
12677481	NS	LATCH
1256695-1	NS	SWITCH
1267748-1	NS	LATCH
1271567-1	NS	SHAFT
1274425-7	NS	POINTER
1274898-1	NS	GEAR
1275323-1	NS	GLASS
1276492	NS	JEWEL SCREW
1278401-1	NS	ROTOR
127978	NS	JEWEL
12810MD	NS	GEARHEAD MOTOR MAXON
1282167-1	NS	TRANSFORMER
1282372-1	NS	POTENTIOMETER
1287-223B	NS	SPRING, LEAF
1287419-1	NS	DECAL
1293028-1	NS	ROTOR
1293542-1	NS	SLIP RING ASSY
1293564-1	NS	BRACKET
1293607-1	NS	TRANSFORMER
1293641-1	NS	BRUSH BLOCK ASSY
1293642-1	NS	BRUSH BLOCK ASSY
1294780-1	NS	ID PLATE
129522-2	NS	SHAFT
12B4A	NS	VACUUM TUBE
12BH121A-GR	NS	BATTERY HOLDER
12HPS-10	NS	POTENTIOMETER
12SL2GT	NS	VACUUM TUBE
12SK7	NS	VACUUM TUBE
12SL7GT	NS	VACUUM TUBE
JAN-CG-12SL7GT	NS	VACUUM TUBE
12SM4	NS	MICRO SWITCH
12SN7GTA	NS	VACUUM TUBE
12SX1-T	NS	SWITCH



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
12SX2-T	NS	MICRO SWITCH
1282167-1	NS	TRANSFORMER
1302827-1	NS	TRANSFORMER
6615-723-1766	NS	SEALING STRIP
1307094-1	NS	TRANSFORMER
1307876-1	NS	MICROSWITCH
1309425-1	NS	BOOT
131-3000	NS	CROCODILE CLIP
131297-01	NS	SEALING STRIP
6615-723-17566	NS	SEALING STRIP
140-0-0-502	NS	POTENTIOMETER
1400K72P001	NS	BEARING PLATE
14033-MG	NS	SMALL BAR MAGNET
149-115	NS	TUBE FILTER
149-120	NS	WINDOW, DIAL
152BCL	NS	HARDWARE KIT
154-7647	NS	MODULAR JACK
155-0001-001	NS	POTENTIOMETER
15549-001	NS	COVER
156-PDLE-13	NS	SHOCK, MOUNT
792-6357-002	OH	INDICATOR
792-6357-002	SV	INDICATOR
JG402A42	SV	INDICATOR
2594621-918	OH	INDICATOR
2594621-918	SV	INDICATOR
229-6026-030	SV	SYNCHRO
229-5022-010	SV	SYNCHRO
229-6026-030	SV	SYNCHRO
229-3017-018	SV	SYNCHRO
350-0083-010	SV	AMPLIFIER
350-0083-020	SV	AMPLIFIER
350-0083-020	SV	AMPLIFIER
4277-31-01	SV	SYNCHRO
R931-017	SV	SYNCHRO
TSH11F08A049	SV	SYNCHRO
7775-5580-001	SV	CASE ASSY
229-0216-000	SV	SYNCHRO
229-7031-010	SV	SYNCHRO
229-3047-016	SV	SYNCHRO
229-3047-016	SV	SYNCHRO
772-5370-001	SV	INDICATOR
229-0091-010	SV	SYNCHRO
229-0194-000	SV	SYNCHRO



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
229-5022-010	SV	SYNCHRO
2591411-444	SV	ATTITUDE DIRECT IND
2591411-444	OH	ATTITUDE DIRECT IND
40-618-11	SV	STABILISER TRIM
40-618-11	OH	STABILISER TRIM
9599-607-12118	SV	INDICATOR
9599-607-12118	OH	INDICATOR
40-618-8	SV	STABILISER TRIM
40-618-8	OH	STABILISER TRIM
154-7647	NE	MODULE JACK
155-0001-001	NE	POTENTIOMETER
155-0001-001	NE	POTENTIOMETER
15549-001	NE	COVER
1558/BPAJC	NE	L.C.
1558/BPAJC	NE	I.C
156-PDLE-13	NE	SHOCK MOUNT
157-1020-34-001	NE	KIT, PCB
157-1021-34-001	NE	POTENTIOMETER
157-21-502	NE	POTENTIOMETER
157-887V1	NE	BOARD
1571927-5	NE	SWITCH
15845-TL	NE	SOLDER STATION, LED
15846-TL	NE	HANDLE ASSY
15849-TL	NE	TIP, POINT
1585K33P001	NE	TERMINAL BOARD
1598K84P001	NE	CARD ASSY
15PA90-6W	NE	SWITCH
160-103109-001	NE	PWA-RTOM
160-103210-001	NE	PWA-RTOM
160-103336-001	NE	PWA-PWR/FAIL/DISTR
160-103478-005	NE	PWA-1MB/1MM
160-103478-005	NE	MEMORY BOARD
160-103509-001	NE	IOP-DEVICE INTERFACE
160-103526-001	NE	PWA-CPU/SGL/SLOT
160-103538-001	NE	PWA-MPCI
160-103554-001	NE	PWA-HSDI
160-103556-001	NE	COPPER FPU
160-103557-001	NE	COOPER FPU-B BOARD
160-103583-001	NE	PWA-CACHE/SELBUS
160-103583-001	NE	CSU
160-103612-001	NE	PWA-LP/FD CONT
160-103623-001	NE	PWA-UDP
160-103654-002	NE	MICRO SEQUENCER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
160-103654-002	NE	MICRO SEQUENCER
160-103656-001	NE	PWA-CPU/IPU/1E2
160-103656-001	NE	IEU
160-103768-001	NE	PWA-8/LINE/CONT
1600607-1	NE	STATOR
160103J630C-F	NE	CAPACITOR
1602042-1	NE	SPRING
160561	NE	SHIP
1605961-1	NE	GLASS
160A604	NE	YELLOW, LIGHT INDI
160A604YELLOW	NE	LIGHT INDICATOR
160A604Y	NE	YELLOW, LIGHT INDI
160A604W	NE	WHITE LIGHT INDICATOR
160A604R	NE	RED LIGHT INDICATOR
160A604G	NE	GREEN LIGHT INDICATOR
160A604W	NE	WHITE LIGHT INDICATOR
161022-B	NE	MODULE V2, VIBRATOR
1613012-1	NE	FLAX LEAD
16171	NE	BASE, LAMP
16179	NE	PACKING
161J10	NE	TRANSFORMER
162-565W	NE	LAMP ASSY
162-570W	NE	LAMP ASSY, POINTER
1624T012S	NE	MOTOR
1631492-1	NE	BRACKET
1639-RG	NE	REGULATOR
164176-01	NE	BOARD ASSY
165440	NE	WEIGHT
16562TE	NE	MULTIMETER
166L25	NE	TRANSFORMER
166L28	NE	TANSFORMER
166L5	NE	POWER TRANSFORMER
166L5	NE	POWER TRANSFORMER
622-5001-503	OH	INDICATOR
622-5001-503	SC	INDICATOR
393026-044	OH	INDICATOR
393026-044	SV	INDICATOR
393026-069	OH	INDICATOR
393026-069	SV	INDICATOR
393086-01236	OH	INDICATOR
114-029	OH	INDICATOR
114-029	SV	INDICATOR
264-1	OH	INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
264-1	SV	INDICATOR
36154-1AF25A1	OH	INDICATOR
36154-1AF25A1	SV	INDICATOR
772-5370-001	OH	INDICATOR
772-5370-001	SV	INDICATOR
155-0001-001	NE	POTENTIOMETER
15549-001	NE	COVER
1559C956	NE	HAND STAFF ASSY
157-21-502	NE	POTENTIOMETER
157-887V1	NE	BOARD ASSY
1571927-5	NE	SWITCH, DEDT MINI
15845-TL	NE	SOLDER, STATION, LED
15846-TL	NE	HANDLE ASSY
15849-TL	NE	TIP, POINT
1585K33P002	NE	TERMINAL BOARD
1598K84P001	NE	CARD ASSY
166L28	NE	TANSFORMER
166L5	NE	POWER TRANSFORMER
166L5	NE	POWER TRANSFORMER
1783867-11	OH	SERVO, AMPLIFER
1783867-11	SV	SERVO, AMPLIFER
G-515BA	OH	AMPLIEFIER, AUDIO
G-515BA	SV	AMPLIEFIER, AUDIO
JG7005A53	OH	RATE GYRO INDICATOR
JG7005A53	SV	RATE GYRO INDICATOR
777-1224-001	OH	FLIGHT DIRECTOR IND
777-1224-001	SV	FLIGHT DIRECTOR IND
772-5370-001	OH	INDICATOR COURSE
772-5370-001	SV	INDICATOR COURSE
622-6523-001	OH	CONTROL HEAD
622-6523-001	SV	CONTROL HEAD
622-6523-005	OH	CONTROL HEAD
622-6523-005	SV	CONTROL HEAD
522-4114-003	OH	RADAR INDICATOR
522-4114-003	SV	RADAR INDICATOR
65691-204-1	OH	N1 INDICATOR
65691-204-1	SV	N1 INDICATOR
622-5001-601	OH	N1 INDICATOR
622-5001-601	SV	N1 INDICATOR
622-5001-602	OH	N1 INDICATOR
622-5001-602	SV	N1 INDICATOR
522-2638-006	OH	H.S.I
522-2638-006	SV	H.S.I.



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
36140-1AJ25B1	OH	RADIO MAG IND
36140-1AJ25B1	SV	RADIO MAG IND
2592920-444	OH	RADIO MAG IND
2592920-444	SV	RADIO MAG IND
160-103565-001	NE	IEU
160-103768-001	NE	PWA-8/LINE/CONT
1600607-1	NE	STATOR
160103J630C-F	NE	CAPACITOR
1602042-1	NE	SPRING
160561	NE	SHIM
1605961-1	NE	GLASS
161022-B	NE	MODEL V2 VIBRATOR
16171	NE	BASE, LAMP
16179	NE	PACKING PREFORMED
161J10	NE	TRANSFORMER
162-408	NE	FRONT GASKET
162-565W	NE	LAMP ASSY
162-570W	NE	LAMP ASSY
1624T012S	NE	MOTOR
1631492-1	NE	BRACKET
1631492-1	NE	BRACKET
1639-RG	NE	LM342P12 REGULATOR
164176-01	NE	BOARD ASSY
165-10-1000	NE	CONNECTOR
165-11	NE	CONNECTOR
165-73-1001X	NE	CONNECTOR
165440	NE	WEIGHT
16562TE	NE	MULTIMETER
16179	NE	PACKING PREFORMED
161J10	NE	TRANSFORMER
162-408	NE	FRONT GASKET
162-565W	NE	LAMP ASSY
162-570W	NE	LAMP ASSY
1624T012S	NE	MOTOR
1631492-1	NE	BRACKET
1631492-1	NE	BRACKET
1639-RG	NE	LM342P12 REGULATOR
164176-01	NE	BOARD ASSY
165-10-1000	NE	CONNECTOR
16562TE	NE	CONNECTOR
166L25	NE	TRANSFORMER
166L28	NE	POWER TRANSFORMER
166L5	NE	POWER TRANSFORMER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
166L5	NE	POWER TRANSFORMER
1672-10S	NE	FREZE SPRAY
16847-TL	NE	UTILITY BRSH, PLSTI
16848-TL	NE	UTLTU BRSH
168C9073P001	NE	CRANK ASSY
1699K35P001	NE	BRAKET
17-830	NE	SEALING STRAP
1700791	NE	SHIM
1700793	NE	GEAR SHAFT
1716405	NE	GEAR SHAFT
1717583	NE	SPRING WASHER
1717798	NE	SHAFT
1717T012S	NE	DC MOTOR
1717T012SR	NE	DC MOTOR
1718170	NE	DECAL
1718751	NE	MASK
1720042	NE	CAM
1720043	NE	SPACER
1720043	NE	SPACER
1720045	NE	GUIDE
1720046	NE	BRACKET
1720065-1	NE	CLAMP
1749374-1	NE	LEVEL SWITCH
175-16-006	NE	BOARD ASSY
175-16-006	NE	BOARD ASSY
175-26W603	NE	PLATE
1750217	NE	GASKET
1751053	NE	GEAR
1751055	NE	WHEEL
1751055	NE	WHEEL
1751295	NE	TERMINAL
1752806-10	NE	TERMINAL
1752807-2	NE	FLAG ASSY
1753859	NE	ANVIL
1754612-2	NE	RELAY
1755262	NE	POINTER
1755278	NE	GEAR
1755278	NE	GEAR
1755560	NE	DESIGNATION PLATE
1755576	NE	SPRING
1755577	NE	SHAFT
1755703	NE	GEAR
1755739	NE	MASK



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1755745	NE	CLAMP
1758696-1	NE	METER MOVEMENT
1758696-2	NE	METER MOVEMENT
1765603-1	NE	RESISTOR
176B601-P1	NE	RING
1771281-1	NE	SPRINGS
1775140-1	NE	LEVEL SWITCH
1781190-1	NE	MOUNT
1781293-12	NE	NAMEPLATE
1751295	NE	TERMINAL
1781293-12	NE	NAMEPLATE
1781293-13	NE	NAMEPLATE
1781293-17	NE	NAMEPLATE
1781293-28	NE	NEMEPLATE
1781293-29	NE	NAMEPLATE
1782702	NE	LIGHT BLOCK
1782846	NE	WINDOW
1755739	NE	MASK
1758696-1	NE	METER MOVEMENT
1758696-2	NE	METER MOVEMENT
1771281-1	NE	SPRINGS
1775140-1	NE	LEVEL SWITCH
1781190-1	NE	MOUNT
1781293-12	NE	NAMEPLATE
1781293-13	NE	NAMEPLATE
1781293-17	NE	NAMEPLATE
1781293-28	NE	NAMEPLATE
1781293-29	NE	NAME PLATE
1782702	NE	LIGHTBLOCK
1782846	NE	WINDOW
1783067-1	NE	COUNTER WEIGHT
1783149	NE	NAMEPLATE
1784280	NE	LIGHT ASSY
1786941-1	NE	STUD
49-058-002M	NE	MODULE ASSY
30-0906-4	SV	RECOGNITION LIGHT
8DJ81LAA1	SV	INDICATOR
8DJ81LAA1	OH	INDICATOR
CM41005012	SV	SYNCHRO
229-7031-010	SV	SYNCHRO
8CDR-300-B-34A	SV	SYNCHRO
4039891-903	SV	AIRSPED
4039891-903	OH	AIRSPED



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
S906-40078-1	SV	LIGHT PANEL
335-101	SV	LIGHT PANEL
2594466-906	SV	MACH AIRSPEED
2594466-906	OH	MACH AIRSPEED
4005123-907	SV	ALTIMETER
4005123-907	OH	ALTIMETER
4056511-904	SV	DIMMING PANEL
4056511-904	OH	DIMMING PANEL
4034240-906	SV	VHF NAV CONTROL PANEL
4034240-906	OH	VHF NAV CONTROL PANEL
2047-02-1	SV	ENG PRESS RATIO IND
2047-02-1	OH	ENG PRESS RATIO IND
124-514-6	SV	EGT INDICATOR
124-514-6	OH	EGT INDICATOR
WL503RC	SV	CABIN RATE OF CLIMB IND
WL503RC	OH	CABIN RATE OF CLIMB IND
522782	SV	DICATOR-ENG VIBRAT
522782	OH	DICATOR-ENG VIBRAT
2592920-444	SV	DEVIATION INDICATOR
2592920-444	OH	DEVIATION INDICATOR
8DJ81WCW4	SV	INDICATOR
8DJ81WCW4	OH	INDICATOR
8DJ81WCW4U	SV	INDICATOR
8DJ81WCW4U	OH	INDICATOR
162BL403C	SV	TEMP ELEC RESISTANCE IND
162BL709C	OH	TEMP ELEC RESISTANCE IND
162BL708	SV	TEMP ELEC RESISTANCE IND
162BL708	OH	TEMP ELEC RESISTANCE IND
162BL709C	SV	TEMP ELEC RESISTANCE IND
162BL403C	OH	TEMP ELEC RESISTANCE IND
4043142-901	NE	DIAL
A2005841	SV	TORQUE POT
009MBH02	SV	TORQUE POT
447610-1	NE	ENCODER SWITCH
4043116-1	SV	COUNTER
2186-000-1	SV	COUNTER
4039838-1	SV	MOTOR
433-673-1004-4060	SV	SWITCH
778-1448-001	SV	INCLINOMETER
3S2791G200R11	NS	ENCODER SWITCH
6X5GT	NS	VACUUM TUBE
100-19	SV	POT
609-8072-001	SV	POWER SUPPLY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
10-61800-1504	SV	LIGHTPLATE
100-19	SV	POTENTIOMETER
1025700-13	SV	CIRCUIT CARD ASSY
124-833	SV	DC VOLTMETER
124-837	SV	AC AMMETER
149270-05-01	SV	TAT-EPR LIMIT INDICATOR, 60B00
609-8072-001	OH	POWER SUPPLY
10-61800-1504	OH	LIGHTPLATE
100-19	OH	POTENTIOMETER
1025700-13	OH	CIRCUIT CARD ASSY
124-833	OH	DC VOLTMETER
124-837	OH	AC AMMETER
149270-05-01	OH	TAT-EPR LIMIT INDICATOR, 60B00
157405-03-01	SV	TAT-ENG N1 LIMIT INDICATOR
157405-03-01	OH	TAT-ENG N1 LIMIT INDICATOR
1724T024S	NS	MOTOR
1778686-655	SV	COMPASS INDICATOR
1778686-655	OH	COMPASS INDICATOR
1784460-355	SV	GYROSYN COMPASS INDICATOR
1H5GT	SV	1H5GT, VACUUME TUBE (JAN-CH
200-007-005	SV	HYDRAULIC FLUID QTY INDICATC
200-3130	NS	SWITCH
206-001-003W	SV	FUEL QUANTITY INDICATOR
2070-03-1	SV	VERTICAL SPEED INDICATOR
684-113-9001	NS	SWITCH
2083-11-1	SV	MACH AIRSPEED
229-2050-010	SV	MOTOR TACHOMETER GENERAT
229-7031-010	NE	SYNCHRO TRANSOLVER
4255-15-01	NE	SYNCHRO TRANSOLVER
8CDR-300-B-34A	NE	SYNCHRO TRANSOLVER
CDSH-8-BQ-4/A013	NE	SYNCHRO TRANSOLVER
CM41005012	NE	SYNCHRO TRANSOLVER
2504524-1	NS	METER
241004-117	NS	METER
2556328-1	NS	METER
2579272	SV	TOGGLE SWITCH
2588371-901	OH	RADIO DIRECTION INDICATOR
2588371-901	SV	RADIO DIRECTION INDICATOR
2594620-905	SV	BAROMETRIC ALTITUDE INDICAT
2594620-905	OH	BAROMETRIC ALTITUDE INDICAT
2594624-912	SV	HORIZONTAL SITUATION INDICA
262-0441-010	SV	DISPLAY MODULE 4 DIGIT, A4122
280195	SV	BRUSH



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
281-0661-430	SV	KNOB
285T0017-103	SV	POWER SUPPLY MODULE ASSY
30-0906-4	SV	RECOGNITION LIGHT
311-711-1537-001	SV	SWITCH
311-711-1537-006	SV	SWITCH
393020-01789	SV	OIL QUANTITY INDICATOR
393026-03236	SV	FUEL QUANTITY INDICATOR
393026-042	SV	FUEL QUANTITY INDICATOR
393081-103	SV	FUEL QUANTITY TOTALIZER INDI
393090-107	SV	PRIMARY FUEL QTY INDICATOR
3S2791G200R11	NE	RELAY
40-300-1	SV	STATIC AIR TEMPERATURE INDIC
4034559-901	OH	DISTANCE BEARING INDICATOR
4034559-901	SV	DISTANCE BEARING INDICATOR
4034559-908	OH	DISTANCE BEARING INDICATOR
4034559-908	SV	DISTANCE BEARING INDICATOR
4039838-1	SV	MOTOR, SERVO
4039892-908	SV	BAROMETRIC ALTIMETER
4039893-902	SV	VERTICAL SPEED INDICATOR
4039893-903	SV	VERTICAL SPEED INDICATOR
4043116-1	SV	COUNTER ASSY (2186-000-1)
4003417-3	SV	SCREW ASSY
4043517-902	SV	INDICATOR
4043517-903	SV	FLAG INDICATOR
4053499	SV	FLAG
407857	SV	CONTROL PANEL , IND
433-673-1004-4060	SV	SWITCH ASSY, BCREFA0525,
447610-1	SV	ENCODER SWITCH
463405-052	SV	DIAL
48-60V5M1	SV	ATTITUDE DIRECTOR INDICATOR
482-5027-000	SV	METER MOVEMENT
482-5051-010	SV	SPEED FLAG
482-5053-010	SV	LOC FLAG
482-5058-010	SV	METER MOVEMENT/SPEED POIN
482-5068-010	SV	METER MOVEMENT
482-5083-020	SV	METER MOVEMENT
482-5083-060	SV	METER MOVEMENT
482-5084-010	SV	TO-FROM POINTER
482-5086-010	SV	METER MOVEMENT,
482-5087-010	SV	NAV FLAG
482-5088-010	SV	SOLENOID
482-5096-010	SV	METER MOVEMENT
482-5096-040	SV	METER COMPUTER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
482-5111-010	SV	DATA SOURCE ACTUATOR
482-5115-010	SV	HEADING FLAG
520-3117-303	SV	RADIO MAGNETIC INDICATOR
522-2782-004	SV	COURSE INDICATOR
522-3120-004	SV	INSTRUMENT AMPLIFIER
522-3122-012	SV	FLIGHT DIRECTOR INDICATOR
522-3138-007	SV	COURSE INDICATOR
522-3877-001	SV	FLIGHT DIRECTOR INDICATOR
522-4430-005	SV	FLIGHT DIRECTOR INDICATOR
522-4825-005	SV	RADIO ALTITUDE INDICATOR
554-8965-003	SV	BRACKET
55820-190-1	SV	LCD DISPLAY
55820-300-1	SV	LCD DISPLAY
5987	SV	VECUUME TUBE
609-8072-001	SV	POWER SUPPLY ASSY
60B00132-29	SV	N1 TACHOMETER INDICATOR
60B00302-11	SV	ENG PRESSURE RATIO INDICATC
622-4938-027	SV	RADIO MAGNETIC INDICATOR
622-5001-109	SV	RADIO DISTANCE MAGNETIC IND
622-5001-110	SV	RADIO DISTANCE MAGNETIC IND
622-5001-111	SV	RDMI-RADIO DISTANCE MAGNET
622-5001-504	SV	RADIO DISTANCE MAGNETIC IND
622-5001-601	SV	RADIO DISTANCE MAGNETIC IND
622-5048-344	SV	EFIS CONTROL PANEL
622-5048-361	SV	EFIS CONTROL PANEL
622-8001-001	SV	EFIS CONTROL PANEL
622-8001-002	SV	EFIS CONTROL PANEL, EFIC-701I
622-8001-003	SV	EFIS CONTROL PANEL (EFIC-701I
622-8001-350	SV	EFIS CONTROL PANEL
622-8001-352	SV	EFIS CONTROL PANEL
622-8001-370	SV	EFIS CONTROL PANEL
64891-002-4	SV	CONTROL SURFACE POSITION IN
65-52822-3	SV	INDICATOR
6841008625	SV	POTENTIOMETER
69-60730-1	SV	PC ASSY, MASTER CAUTION & V/
6X5GT	SV	VACUUM TUBE
700662A	SV	LOAD CONTROLLER GENERATOR
736913	SV	SLIP RING ASSY
754-0301-001	SV	LIGHTPLATE
772-5005-005	SV	FLIGHT DIRECTOR INDICATOR
777-1083-001	SV	HORIZONTAL SITUATION INDICA
778-1448-001	SV	INCLINOMETER ASSY
787-6045-001	SV	SURFACE POSITION INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
8107305ADP5	SV	BRUSH
837-0007-010	SV	SWITCH, MATRIX
837-2001-020	SV	ROTARY SWITCH
88000-4102	SV	CLOCK
8DJ125LXX5	OH	FUEL FLOW USED RATE INDICATOR
8DJ162LXL2	OH	N1 TACHOMETER INDICATOR
8DJ162LZL2	OH	N2 TACHOMETER INDICATOR
8DJ176LZD2	OH	ENGINE FAN SPEED INDICATOR
8DJ176WAZ2	OH	ENGINE FAN SPEED INDICATOR
8DJ81LWT4	OH	TACHOMETER INDICATOR
8DJ81LXH2	OH	TACHOMETER INDICATOR
8DJ81LXP2	OH	TACHOMETER INDICATOR
9-102	OH	FUEL USED INDICATOR
9-116-02	OH	FUEL USED INDICATOR
9599-607-12118	OH	HEIGHT INDICATOR
974-1082-020	OH	RELAY
A2005841	SV	TORQUE POT
AA1752807-1	SV	METER MOVEMENT
B118-244	SV	FUEL QUANTITY INDICATOR
B1800-81103	SV	ALTITUDE INDICATOR
BG6227998SBA	SV	SKID BALL, (Ball Slip inclinometer)
D434-36-001	SV	FLIGHT MODE ANNUNCIATOR
GMT4190-020	SV	ELECTRONIC CLOCK
JG298A5	SV	PRESSURE RATIO INDICATOR
JG603C44	SV	FUEL QUANTITY INDICATOR
LIBB-E32	SV	POSITION INDICATOR
S906-40078-1	SV	PILOT CALL PANEL
SR-O7K	SV	HYDRAULIC BRAKE PRESSURE INDICATOR
TMS9980AJDL	NS	IC
10-61926-2	SV	INDICATOR
10-61926-2	OH	INDICATOR
40-302-3	SV	INDICATOR
40-302-3	OH	INDICATOR
40-302-4	SV	INDICATOR
40-302-3	OH	INDICATOR
40-618-8	SV	INDICATOR
40-618-8	OH	INDICATOR
285T0021-19	SV	INDICATOR
285T0021-19	OH	INDICATOR
836-7035-005	SV	LIGHTPLATE
393026-01838	SV	INDICATOR
393026-01838	OH	INDICATOR
285T0557-1	SV	INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
285T0557-1	OH	INDICATOR
65806-002-1	SV	INDICATOR
65806-002-1	OH	INDICATOR
6040-232665	SV	ROTOR INDICATOR
AF-33-600-22565	SV	ROTOR INDICATOR
JG403B4	SV	INDICATOR
JG403B4	OH	INDICATOR
622-5001-003	OH	INDICATOR
622-5001-003	SV	INDICATOR
3511-180-43191	SV	DC MOTOR
915F212-6	OH	GENERATOR CONTROL
915F212-6	SV	GENERATOR CONTROL
915F212-6	OH	GENERATOR CONTROL
972C487-1	NS	PLATE MODIFICATION
U-396031	NS	TORQUE POT
U396031	NS	TORQUE POT
301-0163-001	NS	TORQUE POT
U-310217-1	NS	TORQUE POT
WCS218-5	SV	SWITCH
WCS218-6	SV	SWITCH
381-1730-010	NS	POT
300-955	NS	POT
2590624-921	OH	INDICATOR
2590624-921	SV	INDICATOR
772-5370-002	OH	INDICATOR
772-5370-001	OH	INDICATOR
772-5370-001	SV	INDICATOR
162BL704D	SV	OIL TEMPERATURE INDICATOR
162BL704D	OH	OIL TEMPERATURE INDICATOR
65806-002-1	SV	ELECTRONIC CLOCK
65806-002-1	OH	ELECTRONIC CLOCK
285T0017-103	SV	MODULE, POWER SUPPLY
285T0017-103	OH	MODULE, POWER SUPPLY
285T0017-104	SV	MODULE, POWER SUPPLY
285T0017-104	OH	MODULE, POWER SUPPLY
WCS223-2	SV	SWITCH
WCS223-022	SV	KNOB
90-02233	SV	SWITCH
285T0017-104	SV	POWER SUPPLY
285T0017-104	OH	POWER SUPPLY
WCS223-1	SV	SWITCH
WCS223-3	SV	SWITCH
31-2911-7	NE	CAPACITOR
792-1053-002	SV	COUNTER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
792-1053-001	SV	COUNTER
4053499-901	SV	FLAG ASSY
160-103768-001	SV	PART
PWA-8-Line/cont	SV	PART
2045-06-1	OH	INDICATOR
2045-06-1	SV	INDICATOR
2591092-904	OH	INDICATOR
2591092-904	SV	INDICATOR
GMT4200	OH	INDICATOR
GMT4200	SV	INDICATOR
8DJ225WAD2	OH	INDICATOR
8DJ225WAD2	SV	INDICATOR
393080-118	OH	INDICATOR
393080-118	SV	INDICATOR
69-37307-112	SV	INDICATOR
69-37317-64	OH	INDICATOR
69-37317-64	SV	INDICATOR
200-002-002	OH	INDICATOR
200-002-002	SV	INDICATOR
200-002-001	OH	INDICATOR
200-002-001	SV	INDICATOR
30-0906-101	OH	LIGHT ASSY
30-0906-101	SV	LIGHT ASSY
30-0906-104	OH	LIGHT ASSY
30-0906-104	SV	LIGHT ASSY
30-0906-105	OH	LIGHT ASSY
30-0906-105	SV	LIGHT ASSY
WL203EED3	OH	FUEL FLOW/USED INDIC
WL203EED3	SV	FUEL FLOW/USED INDIC
182936	OH	INDICATOR OXYGEN PRE
182936	SV	INDICATOR OXYGEN PRE
10-60735-1	OH	INDICATOR OXYGEN PRE
1122-19LW	SV	INDICATOR OXYGEN PRE
1122-19LW	OH	INDICATOR OXYGEN PRE
241010-121	SV	FLAG ASSY
A2005841	SV	TORQUER POT
A1179402	SV	TORQUER POT
009MBH02	SV	TORQUER POT
192-2060-030	SV	WEDGE, LTG
482-5152-010	SV	METER MOVEMENT
482-5144-010	SV	METER MOVEMENT
482-5151-010	SV	METER MOVEMENT
482-5143-010	SV	WEDGE, LTG



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
482-5148-010	SV	METER MOVEMENT
482-5147-030	SV	METER MOVEMENT
482-5146-010	SV	METER MOVEMENT
482-5149-010	SV	LOC PTR, METER MOVEMENT
797-2482-004	SV	PITCH AND ROLL CMD BOARD (A
618-3577-002	SV	PITCH AND ROLL ATTITUDE BOAI
797-2484-001	SV	RUNWAY BOARD
526-0349-010	SV	TRANSFORMER, POWER
1249226	SV	TRANSFORMER, POWER
526-0348-010	SV	TRANSFORMER, POWER
124P262	SV	TRANSFORMER, POWER
609-3175-001	SV	SCALE, GLIDESCOPE
609-3187-001	SV	SCALE, SPEED
609-3533-001	SV	TAPE DRUM ASSY
792-1529-001	SV	GEAR SPUR
609-3678-001	SV	TAPE ASSY
fc	SV	ROLLER
792-1509-001	SV	GEARSHAFT, SPUR
792-1508-001	SV	ROLLER
792-1506-001	SV	MASK
792-1533-001	SV	SHAFT
797-7770-002	SV	TAPE, ALTITUDE
UM23A	SV	TORQUER POT
941942-3	SV	COUNTER
772-5370-001	OH	COURSE INDICATOR
772-5370-001	SV	COURSE INDICATOR
30-0837-9	OH	STROBE LIGHT
30-0837-9	SV	STROBE LIGHT
285T0112-4	OH	AUTOBRIGHT SENSOR
285T0112-4	OH	AUTOBRIGHT SENSOR
285T0112-4	SV	AUTOBRIGHT SENSOR
DNM100030	SV	MODULE ASSY. LCD
DNM100-030	SV	MODULE ASSY. LCD
S182-10809-4	SV	MODULE ASSY. LCD
S182-10809-41	SV	MODULE ASSY. LCD
DNM10003006	SV	MODULE ASSY. LCD
DNM-100-030-06	SV	MODULE ASSY. LCD
CND500-099	SV	MODULE ASSY. LCD
1783875-5	AR	INDICTOR
2067048-2402	AR	INDICTOR
172754-2104	AR	INDICTOR
7-362A	AR	INDICTOR
1780607-53	AR	INDICTOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2388146-903	AR	INDICTOR
178607-53	AR	INDICTOR
1783875-5	AR	INDICTOR
60B40044-16	AR	INDICTOR
2067048-2402	AR	INDICTOR
2504060-2	NS	RELAY
2504061	NS	BRUSH BLOCK
2504072-1	NS	ROTOR
2504094-14	NS	COIL
2504124-203	NS	THYRISTOR
2504386-3	NS	FLAG
2504447	NS	BRUSH
2504462-1	NS	SPRING
2504482-1	NS	LIGHT BLOCK
2504524-1	NS	METER
2504533-232	NS	I.C.
2504533-245	NS	I.C.
2504905	NS	INCLINOMETER
2504909-251	NS	ZENER DIODE
251011-901	NS	CENTER DIAL
251192-901	NS	VERIABLE RESISTOR
2516224	NS	SKIRT
2519149	NS	SPACER
2519164-1	NS	PANEL BEZEL
2519270-2	NS	PC BOARD
139988-01	NS	POTENTIOMETER
2519394-2	NS	POST
2553663-8	NS	BRUSH BLOCK
2553765	NS	BRUSH BLOCK
2554676	NS	SPRING
2554738	NS	TRANSISTOR HOLDER
2555350	NS	SHAFT
2555440	NS	LEVEL SWITCH
2555483	NS	GEAR
2556209	NS	KNOB
2556238	NS	LAMP HOLDER
2556265	NS	MOD PLATE
2556523	NS	SHAFT
2556744-1	NS	SWITCH GUARD
2575317	NS	TRANSISTOR
2575319-4	NS	GASKET
2579442-7	NS	CUSHION
2579603	NS	INDICATOR, POWER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2579765-1	NS	GEAR
2580794	NS	BRACKET
2580877	NS	MONITOR ASSY
2580935-1	NS	BRACKET
2581381-3	NS	COVER
2581479-101	NS	POINTER
2581492	NS	GEAR
2582419	NS	FRAME ASSY
2582875-102	NS	GYRO CONNECTOR PLATE
2582922	NS	LEAD ASSY
2582978-1	NS	PRINTED CABLE
2582978-2	NS	PRINTED CABLE
2582978-3	NS	PRINTED CABLE
25885565	NS	BEARING ASSY HOLDER
2585566	NS	ROTOR
2586894	NS	FRAME
2588428-3	NS	SPHERE
2588867	NS	POWER SUPPLY
259-2893-030	NS	SWITCH
2591149	NS	GUIDE
2591613-902	NS	LOC AMPLIFIER
2592668	NS	BRUSH BLOCK
2594085-901	NS	POWER SUPPLY
2594665	NS	GEAR
2594676	NS	COIL
2594737	NS	COIL
2594850-903	NS	MODULE
25F1140	NS	RED LAMP
25TTS08	NS	CONNECTOR
25Z6GT	NS	VACCUM TUBE
26-20SSKGD	NS	CONNECTOR
26-361	NS	LOW PROFILE HEAT
2650K76P001	NS	SPRING
265641	NS	CONTACT ASSY
265642	NS	RING
266-7112-060	NS	LENS, PB, ILLUM WHITE
266-7566-010	NS	SWITCH PUSH
266493-001	NS	GASKET
267826	NS	RELAY
26902-1	NS	FILTER
26C6	NS	VACCUM TUBE
26ET9-T	NS	SWITCH, TOGGLE
26SF18	NS	RELAY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
26V08RCT4PS0K	NS	TRANSOLVER
27-181	NS	POWER PLUG
27-32260-0010	NS	FILTER
275-4	NS	GOMMET
276-1537	NS	D-SUB CONNECT
2774W14G700	NS	COUNTER ASSY
2774W30G716	NS	DIAL
27995A521	NS	CABOLT, DRILL BIT
2793557-1	NS	ACTUATOR, SWITCH
27C010-2	NS	EPROM
280-3778-010	NS	DECAL
280-3778-050	NS	STICKER MOD
280-3778-100	NS	STICKER MOD
280-3778-100	NS	STICKER MOD
28005-03	NS	LIGHT PALTE
280195	NS	BRUSH
4041393-412	SV	IC
SCL4700-J7-MSP	SV	IC
H6C0049A	SV	IC
2P780-8943	NS	CAPACITOR
2SB463	NS	TRANSISTOR
2SC281	NS	TRANSISTOR
2SD205	NS	TRANSISTOR
2TL150-3D	NS	SWITCH
30-07-G	NS	RELAY, HERMETICALLY SEALED
300-192-2K	NS	VARIABLE RESISTOR
300-955	NS	POTENTIOMETER
300250-001	NS	SHAFT
30050M-109	NS	LIGHT, IND. AMB
3005P-M18-103	NS	RESISTOR
3006P1-102	NS	POTENTIOMETER
301-0091-001	NS	SYNCHRO
30585A65	NS	DRILL BITS & RODS
305954	NS	BEARING
306-1342-000	NS	TERMINAL
306-2474-110	NS	TERMINAL
306-706-1002-002	NS	PILOT CALL PANEL
309-1557-000	NS	BEARING
f	NS	BEARING
30900	NS	FILTER
30YY2312	NS	SWITCH, PUSHBUTTON
31-2511-1	NS	ID PLATE
31-2691-1	NS	MOUNTING PLATE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
31-2835-1	NS	GASKET
31-3485-1	SV	SPACER
311-711-1537-006	SV	SWITCH, PUSHBUTTON
3116E2041S	SV	CONNECTOR
3116W15P001	NS	DIAL
3119W95P001	NS	DIAL
3120W34P001	NS	DIAL
3130W67P001	NS	DIAL
3132W73P001	NS	SCALEDIAL
3142W24G703	NS	DIFFUSER
314397-02	NS	UNIT WHEEL
315004	SV	FUSE
31CN205	SV	POTENTIOMETER
31CX505	NS	POTENTIOMETER
32-3040	NS	TERMINAL
320-0021-006	NS	MOUNTING KIT
3200-1087	NS	POTENTIOMETER
3200-2311	NS	POTENTIOMETER
3200-557	NS	POTENTIOMETER
32050-1002	NS	SHAFT
32076-35351	NS	CONNECTOR
321070	NS	CAP
321073	NS	TUBE
322400B00	NS	ANODIZE, BLK
322505B00	NS	ANODIZE TO-5
70-22322	SV	KNOB
522-3120-005	OH	INSTR. AMPLIFIER
522-3120-005	SV	INSTR. AMPLIFIER
262-1302-040	SV	DISPLAY ASSY
262-1302-010	SV	DISPLAY ASSY
CR70018-3	SV	DISPLAY ASSY
CR70018-2	SV	DISPLAY ASSY
200394-003	SV	MOTOR
70516-0003	SV	CIRCUIT INTEGRATED
3250I-1-102	NS	TRIMPOT
327425	NS	SHAFT
327426	NS	GEAR CLUSTER
328003	NS	SHAFT
328008-1	NS	SHAFT
32D5494	NS	CAPACITORS
32PL	NS	CAPACITORS
33-149	NS	AA NICKEL BATTERY
33-25732-0080	NS	GEAR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
330226-2	NS	HEATER
330796	NS	GASKET
330813	NS	COVER
329WT09-102	NS	VARIABLE RESISTOR
334338	NS	SWITCH
334740-1	NS	POT
336244	NS	NAME PLATE
3396W51G701	NS	BOARS ASSY
33JR117-1		CONNECTOR
3437634		BEARINGS
34BSX21COBORAV11G18		BEARINGS
34BSX23ORA		BEARINGS
34BSX52C20IRO11		BEARINGS
772-5005-001	OH	FLIGHT DIRECTOR IND
772-5005-005	OH	FLIGHT DIRECTOR IND
772-5005-009	OH	FLIGHT DIRECTOR IND
772-5005-009	SV	FLIGHT DIRECTOR IND
35-21	NS	SHIM
350-0083-002	NS	IC AMPLIFIER
350-0103-010	NS	IC ERROR AMPLIFIER
350-0116-030	NS	IC AMPLIFIER
350-0142-010	NS	IC MONITOR
350-3070-030	NS	IC
350-9055-010	NS	IC
350-9077-010	NS	IC AUU WARN OUTPUT
3500S-447-022	NS	POTENTIOMETER
350364	NS	PART
350156	NS	CAP ASSU
351-2017-010	NS	IC
351-2017-010	NS	IC
35115	NS	SPLICE
350-0083-020	NS	IC AMPLIFIER
350-0103-010	NS	IC ERROR AMPLIFIER
35312	NS	DISPENSER
3540S-1-202L	NS	POTENTIOMETER
3540S-1-501	NS	POTENTIOMETER
358104-1	NS	END CAP
35AMP	NS	FUSE
360-13	NS	PIVOT
361-1739E070A05	NS	"O" RING
363004-54-8	NS	PIN
37-3-2125	NS	PLATE
37-6-2113-2	NS	INSULATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
37-6-5002	NS	INSULATOR
37-6-5005	NS	WASHER
372-2255-020	NS	ELECT CONTACT
372-2501-090	NS	CONTACT
372086	NS	INSULATOR
372117	NS	SEAL WASHER
3738W10G703	NS	FLAG & FRAME ASSY
3782-24-02	NS	MINI GRABBER LEADS
3782-24-2	NS	MINI GRABBER LEADS
38-204	NS	TRIMPOT
380-3356-060	NS	RESISTOR
381878	NS	TERMINAL POST ASSY
382-0082-010	NS	POTENTIOMETER
382550	NS	DECAL, FULL
382981	NS	DECAL
3830K75P001	NS	GASKET
3830K75P003	NS	GASKET
3830K80PP01	NS	GASKET
383156	NS	END PLATE
383177	NS	GEAR BOX
4005683	NS	TAPE
4007977-8	NS	LENS-AMBER
4007986-902	NS	BEZEL
400H	SV	AC VACUM
401-0778-006	NS	MASK
4010927	NS	PIN
4010969-902	NS	MODULE
4012287	NS	TRANSFORMER
E-384	NS	TRANSFORMER
4012343	NS	DECAL
4012352-901	NS	PUSH BUTTON
4012978-13	NS	PLATE
4015723-23	NS	ID PLATE
4015723-26	NS	ID PLATE
4015723-30	NS	ID PLATE
4015723-7	NS	ID PLATE
4015725-4	NS	ID PLATE
4016902-901	NS	MODULE FLAG
4018175-19	NS	ID PLATE
4018175-20	SV	ID PLATE
4018175-3	SV	PLATE
4018175-3	NS	PLATE
4018175-4	NS	ID PLATE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4018606-901	NS	MODULE
4034924	NS	SPRING
4034989-1	NS	POINTER
4034989-2	NS	POINTER
4037210-11	NS	BEARING
4037210-21	NS	BEARING
4037210-22	NS	BEARING
4037210-23	NS	BEARING
4037210-24	NS	BEARING
4038097	NS	GASKET
4039590-13	NS	DECAL
4039594	NS	GLASS
4039817-902	NS	SENTRI AMP
4039K70P001	NS	GUARD
404-112	NS	SWITCH GARD
4041412-622	NS	IC
4043126-901	NS	CCA, A/D/A
4043142-901	NS	DIAL
4050319-43	NS	IC
4051524-120	NS	ID PLATE
4051524-121	NS	ID PLATE
4051577-205	NS	PLATE
4051577-211	NS	ID PLATE
4051577-217	NS	NAME PLATE
4061836	NS	BUSHING
4065516-367	NS	ID PLATE
1753029-1	NS	BOOT
FTC307401	NS	TRANSFORMER
015-2027-000	NS	BRUSH
0-25-3SS	NS	BALL
0164-3	NS	LOCK WASHER
0164-4	NS	LOCK WASHER
0164-5	NS	LOCK WASHER
0164-7	NS	LOCK WASHER
035149	NS	SCREW
0411-29	NS	SCREW
0444-130	NS	SCREW
0492-3	NS	RING, RETANING
MS16633-2009	NS	RING, RETAINING
0495-3	SV	SPRING PIN
44370	NS	UNKNOWN
495013	NS	UNKNOWN
35-21	NS	SHIM



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
350-0083-002	NS	IC AMPLIFIER
350-0103-010	NS	IC ERROR AMPLIFIER
350-0116-030	NS	IC AMPLIFIER
350-0142-010	NS	IC MONITOR
350-3070-030	NS	IC
350-9055-010	NS	IC
350-9077-010	NS	IC AUU WARN OUTPUT
3500S-447-022	NS	POTENTIOMETER
350364	NS	PART
350156	NS	CAP ASSU
351-2017-010	NS	IC
351-2017-010	NS	IC
35115	NS	SPLICE
350-0083-020	NS	IC AMPLIFIER
350-0103-010	NS	IC ERROR AMPLIFIER
35312	NS	DISPENSER
3540S-1-202L	NS	POTENTIOMETER
3540S-1-501	NS	POTENTIOMETER
358104-1	NS	END CAP
35AMP	NS	FUSE
360-13	NS	PIVOT
361-1739E070A05	NS	"O" RING
363004-54-8	NS	PIN
37-3-2125	NS	PLATE
37-6-2113-2	NS	INSULATOR
37-6-5002	NS	INSULATOR
37-6-5005	NS	WASHER
372-2255-020	NS	ELECT CONTACT
372-2501-090	NS	CONTACT
372086	NS	INSULATOR
372117	NS	SEAL WASHER
3738W10G703	NS	FLAG & FRAME ASSY
3782-24-02	NS	MINI GRABBER LEADS
3782-24-2	NS	MINI GRABBER LEADS
38-204	NS	TRIMPOT
380-3356-060	NS	RESISTOR
381878	NS	TERMINAL POST ASSY
382-0082-010	NS	POTENTIOMETER
382550	NS	DECAL, FULL
382981	NS	DECAL
3830K75P001	NS	GASKET
3830K75P003	NS	GASKET
3830K80PP01	NS	GASKET



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
383156	NS	END PLATE
383177	NS	GEAR BOX
4005683	NS	TAPE
4007977-8	NS	LENS-AMBER
4007986-902	NS	BEZEL
400H	SV	AC VACUM
401-0778-006	NS	MASK
4010090	NS	SLIDER
4010927	NS	PIN
4010969-902	NS	MODULE
4012287	NS	TRANSFORMER
E-384	NS	TRANSFORMER
4012343	NS	DECAL
4012352-901	NS	PUSH BUTTON
4012978-13	NS	PLATE
4015723-23	NS	ID PLATE
4015723-26	NS	ID PLATE
4015723-30	NS	ID PLATE
4015723-7	NS	ID PLATE
4015725-4	NS	ID PLATE
4016902-901	NS	MODULE FLAG
4018175-19	NS	ID PLATE
4018175-20	SV	ID PLATE
4018175-3	SV	PLATE
4018175-3	NS	PLATE
4018175-4	NS	ID PLATE
4018606-901	NS	MODULE
4034924	NS	SPRING
4034989-1	NS	POINTER
4034989-2	NS	POINTER
4037210-11	NS	BEARING
4037210-21	NS	BEARING
4037210-22	NS	BEARING
4037210-23	NS	BEARING
4037210-24	NS	BEARING
4038097	NS	GASKET
4039590-13	NS	DECAL
4039594	NS	GLASS
4039817-902	NS	SENTRI AMP
4039K70P001	NS	GUARD
404-112	NS	SWITCH GARD
4041412-622	NS	IC
4043126-901	NS	CCA, A/D/A



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4043142-901	NS	DIAL
4050319-43	NS	IC
4051524-120	NS	ID PLATE
4051524-121	NS	ID PLATE
4051577-205	NS	PLATE
4051577-211	NS	ID PLATE
4051577-217	NS	NAME PLATE
4061836	NS	BUSHING
4062225-101	NS	ID PLATE
4065516-367	NS	ID PLATE
1753029-1	NS	BOOT
15549-001	NS	COVER
156PDLE13	NS	SHOCK MOUNT
1585K33P002	NS	TERMINAL BOARD
1598K84P001	NS	CARD ASSY
1600607-1	NS	STATOR
1602042-1	NS	SPRING
160561	NS	SHIM
1631492-1	NS	BRACKET
1613012-1	NS	FLEX LEAD
495013	NS	PART
44370	NS	PART
NC111K	NS	PART
015-2027-000	NS	BRUSH
BB-195-1316	NS	BRUSH
0411-29	NS	SCREW
0-25-3SS	NS	BALL
0-25-3SS	NS	BALL
0444-130	NS	SCREW
0444-224	NS	SCREW
0492-3	NS	RING, RETAINING
MS16633-2009	NS	RING, RETAINING
0495-3	NS	SPRING PIN
2953	NS	TRANSFORMER
07187-603999	NS	TRANSFORMER
07187-603999	NS	TRANSFORMER
08sm2606-6	NS	SERVO MOTOR
M7798	NS	TRANSFORMER
841-011-002	NS	TRANSFORMER
OB2WA	NS	VACUUM TUBE
OB2WA	NS	VACUUM TUBE
JAN-OB2WA	NS	VACUUM TUBE
JRP-OB2WA	NS	VACUUM TUBE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
OA2WA	NS	VACUUM TUBE
GB-0A2WA	NS	VACUUM TUBE
JAN-0A2WA	NS	VACUUM TUBE
0770-3	NS	WASHER
MS15795-802	NS	WASHER
104547	NS	COIL ASSY
1000364	NS	TERMINAL
10-117911-183	NS	CONNECTOR
BAC-10-60479-115	NS	CONNECTOR
10023325-101	NS	DIAL
10023329-101	NS	DIAL
10023331-101	NS	DIAL
7246	NS	POT
100K POT	NS	POT
267004-024	SV	METER MOVEMENT
520465	SV	METER MOVEMENT
M9070-30	SV	METER MOVEMENT
A4I222	SV	DISPLAY MODULE
A4I222	SV	DISPLAY MODULE
GMT4190-020	SV	CLOCK, ELECTORNIC
GMT4150	OH	CLOCK, ELECTORNIC
GMT4150	OH	CLOCK, ELECTORNIC
GMT4150	OH	CLOCK, ELECTORNIC
GMT4190-054P1	NE	FILTER, CARD
4043115-3	NE	KNOB
4043115-1	NE	KNOB
4043115-1	NE	GEARS
37621132	NS	INSULATOR
350-9075-010	SV	IC MONITOR
814187	SV	TRANSFORMER
101594	SV	SHAFT ASSY
8096K76G700	SV	COIL
3621K70G700	SV	FLAG
266-5031-010	NS	LENS ,PB ILLUM WHITE
10M-150-AJ-7B	NE	MOTOR
19808A5	NE	MOTOR
1208549-1	NE	SPRING
118-120-154	NE	PLATE
117334	NS	CONTACT ASSY
11237	NS	LAMP
110207	NS	CAP
109772	NS	RESISTOR SPOOL
108H	NE	KNOB, SWITCH



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
10630060-35	SV	CONNECTOR
1230497-1	NE	AMPLIFIER ASSY
MHX-4160	NE	RELAY
1223299-1	NS	HOUSING
1208555-1	NS	SCREW
778-1397-001	NE	BUSHING
778-1397-001	NS	BUSHING
1268625-2	NS	SPRING
1282834-P1	NS	LUCKNUT
1282372-1	NS	POT
12684	NE	SCREW
4141772P059	NE	GLASS
4141928G003	NE	DISC ASSY
4142159G003	NE	ARMATURE
4145566P031	NS	SPRING
4145566P066	NS	SPRING
4145642G125	NS	POINTER
4145642G188	NS	POINTER
4145811P001	NE	CONNECTOR
4149327P008	NS	SCREW
4149327P001	NE	SCREW
4149327P011	NE	SCREW
4149392P011	NS	SCREW
4149399G004	NS	JEWEL
42-27-11-012	SV	CAM
42-27-11-011	SV	CAM
4149463P003	NE	GROUND CLIP
4149471P015	NS	BEARING
4152030P002	NS	TERMINAL
4152232G010	NS	DISK
417572	NE	STRAP
41LK015	NE	TRANSFOMER
42-100-13-05	NE	GASKET
42-64-13-201	NS	MASK
42-191	NE	POS PRE-SENS PC BOARD
42-27-04-011	NS	DUMMY CASING
42-27-04-014	NS	HUB SCREW WRENCH
42-27-04-015	NS	FRONT HUB NUT WRENCH
42-27-11-011	NS	CAM
42-27-12-022	NE	KNOB
42-31-11-025	NS	TRACK
42-31-12-018	NE	WASHER
42-43-12-29	NE	KBRAKE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
42-43-13-229	NS	SLIP RING ASSY
42-43-13-84	NS	GASKET
42-44-04-010	NE	ADJUSTMENT SUPPORT
42-55-13-14	NS	BRUSH BLOCK
42-64-13-004	NS	NAME PLATE
42-89-13-48	NS	DRUM
42-91-13-05	NS	LABEL LABEL
42-91-13-201	NE	MASK
3830W13P001	NE	GASKET
3830W75P001	NE	GASKET
383156	NE	END PLATE
383177	NS	GEAR BOX ASSY
383229	NS	TUBE, EVACUATING
383269	NS	GEAR BOX ASSY
383283	NS	SWITCH PLATE
383713	NE	GASKET
383908	NS	RING, FRICTION
383909	NE	KNOB
3857-TL	NE	HOMOSTATS
3881K78G700	NS	GEAR & SHAFT
3881K78G701	NS	GEAR & SHAFT
388530	NE	DECAL BIAS
3888K77P001	NS	GEAR
3894W17P001	NS	GEAR
3895K75P004	NS	GEAR
3895K75P005	NS	GEAR
39-00-0041	NE	PIN, HEADERS & WIRE
3991159	NE	GASKET
391162	NE	CONTACT ASSY
39199-2	NE	CAPACITOR
397052	NS	GEAR BOX
397455	NS	FACE PLATE
397804	NS	AMPLIFIER
397833-1	NS	SHAFT AND WIPER
397849-01235	NE	TRANSFORMER
39K10	NE	REACTOR
3A177	NE	FILTER
3AB21	NS	CONVERTER, DC-DC
3AB25	NS	CONVERTER, DC-DC
3C5A2	NE	RESISTOR
3FS-448	NS	TRANSFORMER
3LV78	NS	AC ADAPTER
3M TYPE 79	NS	TAPE, GLASS CLOTH



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
3M-2307-2	NS	TAPE
3N170	NE	TRANSISTOR
3S2791G200R11	NE	RELAY
3S2791G200V9SD	NE	RELAY
3SM	NS	BULB
3SX1-T	NS	SWITCH
3U974	NE	SOLUTION TANK DISPENS
3V4	NS	TUVE
3V484	NS	FIXTURE
4-330808-9	NS	SOCKET SRPING
4-470-10564-16	NS	LIGHT ASSY
40-618-5	OH	STABILIZER TRIM
40-618-5	SV	STABILIZER TRIM
4000011	NE	PACKING
4000136	NE	TRANSFORMER
4000138-1	NE	INCLINOMETER
4000281-903	NS	MODULE
4000354-901	NS	AMPLIFIER
4000983	NS	BRACKET
4001474-1	NS	GASKET
4001844	NE	TRANSFORMER
4002375-1	NS	INDICATOR
4002735-901	NE	MASK
4002746	NE	GEAR
4002844-3	NS	TERMINAL
4003492-902	NS	MODULE
4003825	NE	TRANSFORMER
4272K70P001	NS	HOOK
4277-03-01	NS	SYNCHRO
42802300	NS	MOTOR-TACH GENERATOR
229-2007-000	NS	MOTOR-TACH GENERATOR
42802301	NS	MOTOR-TACH GENERATOR
42802302	NS	MOTOR-TACH GENERATOR
6229-67-02	NS	MOTOR-TACH GENERATOR
665-55-113-1	NS	MOTOR-TACH GENERATOR
ST10017-4	NS	MOTOR-TACH GENERATOR
U-216187	NS	MOTOR-TACH GENERATOR
42802300	NE	MOTOR-TACH GENERATOR
428506-17	NE	POTENTIOMETER
428518-6	NE	POTENTIOMETER
428518-8	NS	POTENTIOMETER
428527-7	NS	POTENTIOMETER
4287-7	NE	LENS



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
42955A18	NS	CARBIDE
4302F3-5V	NS	AMBER DIFFUSED
432936	NS	BOLT
433-100-005	NS	GARD SWITCH
433232	NE	TRANSFORMER
433391-4	NE	CAPACITOR
433391-5	NS	CAPACITOR
433924-4	NS	RESISTANCE WINDING
433924-7	NS	RESISTANCE WINDING
434-674-1031-2001	NE	LIGHT ASSY INDICAOTR
434336-11	NS	CARD ASSY
434683-1	NE	SWITCH PLATE ASSY
435H10	NE	DIODE
436481-3	NS	CASE ASSY
436931	NS	SPUR GEAR
436998	NE	BEARINGS PLATE
437467-2	NS	WIPER ASSY
4381W10P001	NS	HUB
439-5276-000	NS	WIRE
439300	NS	SPACER
44-1055	NE	SHIELD
441-R328	NE	FUSE HOLDER
441173-3	NE	ROTOR
442469	NS	PC BOARD
442587	NS	PC BOARD
454381	NS	PC BOARD
482-5098-000	SV	GS POINTER
482-5098-010	SV	GS POINTER
482-5100-010	SV	SPEED POINTER
482-5102-010	SV	GS FLAG
482-5099-010	SV	R/T POINTER
M9073-25	SV	GLIDESLOPE FLAG
M9076-25	SV	GLIDESLOPE FLAG
M9073-27	SV	SPEED CONTROL POINTER
M9071-76	SV	GLIDESLOPE FLAG
484-5102-010	SV	FLAG
482-5098-010	SV	FLAG
482-5100-020	SV	POINTR
482-5100-010	SV	RT POINTER
797-7616-001	SV	COMMAND BOARD
778-1455-001	SV	MASK
778-1306-001	SV	SCALE, SPEED
778-1307-001	SV	SCALE, GS



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1822-369LW	OH	VIBRAT MONITOR INDICATOR
10-62067-1	OH	VIBRAT MONITOR INDICATOR
1822-369LW	SV	VIBRAT MONITOR INDICATOR
10-62067-1	SV	VIBRAT MONITOR INDICATOR
522782	SV	VIBRAT MONITOR INDICATOR
2580011	SV	DIAL
2580952	SV	GEAR CLUSER
2557020	SV	PLATE
2557017	SV	TERMINAL BARD
25567441	NS	SWITCH GARD
2556177	SV	GEAR CLUSTER
2556175	SV	GEAR CLUSTER
2556168	SV	BRACKET
2579765-1	NE	GEAR
2579442-1	NS	BOLT
2580258	SV	DIAL
2580011	SV	DIAL
1778673	SV	FLAG
1752807-2	NS	FLAG ASSY
1775140-1	NS	LEVEL SWITCH
176B601-P1	NS	RING
175-21W-154-3	SV	DIAL
175-26W603	NE	PLATE
175-21W-154-4	SV	PLATE
147C161P001	NE	PICKOFF ASSY
1307876-1	NE	MICRO SWITCH
139288-01	NS	ID PLATE
1383842	SV	CLIP
135	NE	SPRING
1298705-	NE	NAME PLATE
1295162P002	NE	NUT
1293542-3	NE	SLIP RING ASSY
1293542-2	NS	SLIP RING ASSY
125K7	NS	VACUUM TUBE
12SK7	NS	VACUUM TUBE
442-040-009	SV	DIAL ASSY
4016460-1	SV	SYNCHRO
442-040-002	NS	DIAL
4012287	NS	TRANSFORMER
E-384	NS	TRANSFORMER
4001844	NS	TRANSFORMER
3v4	NS	TUBE
4003825	NS	TRANSFORMER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
46-982-1	NE	SWITCH ASSY
461905-4	NE	RESISTOR
463322-00116	NE	CONNECTOR
463395	NS	PLATE
463404-02237	NS	LIGHTINGASSY
463405-01235	NS	DIAL, SCALE
463405-01508	NS	DIAL, SCALE
463432	NS	LIGHT SHIELD
463548-001	NS	RING, LIGHTING
463683	NS	CONNECTOR
463694J	NS	TRANSFORMER
463700	NS	TRANSFORMER
463704	NS	PC BOARD
463712	NS	GEAR ASSY
463750	NS	WASHER
463750-1	NS	WAHSER
463751	NS	POST
463751-1	NE	SPACER
463760	NS	PLATE IDENTIFICATION
463763	SV	PIN COTTER
463777-03235	SV	GEAR ASSY
463803-03335	NS	TRANSFORMER
463817-714	NS	DIODE
792-6091-001	OH	H.S.I.
792-6091-001	SV	H.S.I.
772-5006-005	OH	H.S.I.
772-5006-005	OH	H.S.I.
772-5006-005	OH	H.S.I.
801EED6	NS	PLACARD
800EED6	NS	PLACARD
CMP505	OH	PANEL
AC30-0003-3	SV	AUTOBRAKE SELECT SWITCH
AC30-0003-3	SV	AUTOBRAKE SELECT SWITCH
454866-22	NE	CLUTCH ASSY
454866-19	NE	CLUTCH ASSY
454866-17	NE	CLUTCH ASSY
454381	NS	P.C. BOARD
454973-6	SV	GEAR ASSY
454974-6	NE	GEARSHAFT
452656	NE	STRIP
452574-2	NE	ROTOR
452571	NE	ROTOR
452525	NS	PIN



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
S233T100-546	NS	LIGHTPANEL
451778	NS	REACTOR
266-7035-070	SV	LENS
851-35277-107	SV	LENS, PUSHBUTTON
266-7035-090	SV	LENS
851-35277-109	SV	SWITCH, LENS
439444-4	NS	ID PLATE
439300	NE	SPACER
437467-2	NE	WIPER ASSY
436998	NE	BEARING PLATE
434336-7	NE	CARD ASSY
4043198	SV	SPACER
4043196	SV	SHAFT
2503594-55	SV	WHASHER, FAT
4043195	SV	GEAR
234597-649	SV	SPRING
4043199	SV	SPACER
2500148-19	SV	SETSCREW
482-0066-050	SV	FLAG POINTER
482-0066-050	SV	FLAG POINTER
482-0066-030	SV	FLAG MOVMENT SOLENOID
482-0066-010	SV	FLAG MOVMENT SOLENOID
482-0066-030	SV	FLAG MOVMENT SOLENOID
482-0066-010	SV	FLAG MOVMENT SOLENOID
642-3997-012	SV	BOARD CIRCUIT
642-3997-012	SV	BOARD CIRCUIT
642-4584-005	SV	CIRCUIT CARD ASSY
642-4584-005	SV	CIRCUIT CARD ASSY
642-4000-003	SV	POWER SUPPLY
622-5739-002	SV	ENCODER
642-4589-003	SV	CARD ASSY
642-4592-006	SV	CARD ASSY
522-4114-012	OH	RADIO ALTITUDE INDICATOR
522-4114-012	SV	RADIO ALTITUDE INDICATOR
262-2848-160	NS	LIGHT, INDICATOR. AMB
30050M-109	NS	LIGHT, INDICATOR. AMB
665-000176-2	SV	SWITCH ASSY
4041990-1	SV	SYNCHRO REOLVER
CSH-8-E-1	SV	SYNCHRO REOLVER
2186-000-1	SV	COUNTER
2186-0001	SV	COUNTER
4043116-1	SV	COUNTER
4043116-1	SV	COUNTER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
MS51957-2	SV	SCREW
2500480-38	SV	SCREW
4043142-901	SV	DIAL
4043142	SV	DIAL
4043173-904	SV	BEZEL
4043173-901	SV	BEZEL
4043173-905	SV	BEZEL
4045190-405	SV	MICROCIRCUIT
4045190-403	SV	MICROCIRCUIT
4045190-406	SV	MICROCIRCUIT
4045190-404	SV	MICROCIRCUIT
RSA2366-1	SV	SOLENOID, ROTARY
531295-966	SV	MECHANISM ASSY
182936	OH	H.S.I.
182936	SV	H.S.I.
DM74126N	NS	IC
DM8094N	NS	IC
351-7728-010	NS	IC
906-50037-110	NS	DIODE
BAS78	NS	DIODE
DM74LS30N	NS	IC
ECG4017B	NS	IC
4017B	NS	IC
70509-0001	NS	IC
351-1112-012	NS	IC
IRF730B	NS	IC
4034801-608	NS	IC
L1A2361	NS	CLOCK DRIVER
6900W11P004	NS	CLOCK DRIVER
351-8776-020	NS	IC
7802801EA	NS	IC
SG1526BJ/883B	NS	IC
SI4559EY	NS	MOSFET
TL082BCP	NS	IC
192-2071-010	NS	WEDGE LIGHTING
1867901-1	NS	BRACKET, LEVEL ASSY
1916114-1	NS	PIN
1916114-2	NS	PIN
1931249-1	NS	MAST-INDICATOR
192-2015-010	NS	GLASS
19-1611-01	NS	POINTER
187174-001	NS	PIVOT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1931290-1	NS	BLOCK LIGHTING
1931410-1	NS	PLATE LIGHTING
1931416-1	NS	RING-FUDUCIAL
19315-729685-2	NS	CLIP
192-2003-010	NS	LIGHT WEDGE
192-2010-010	NS	WEDGE LIGHTING
1886563-1	NS	BRACKET
65691-301-1	OH	EPR INDICATOR
65691-301-1	SV	EPR INDICATOR
65691-301-1	OH	EPR INDICATOR
SR-07B	OH	HYD PRESSURE IND
SR-07B	SV	HYD PRESSURE IND
393026-047	OH	INDICATOR
393026-047	SV	INDICATOR
393026-048	OH	FUEL QTY INDICATOR
393026-048	SV	FUEL QTY INDICATOR
307AAK	NE	IC
DG307AAK/883	NE	IC
4039142-407	NE	IC
1040	NE	ARBOR
463405-01840	NE	DIAL, SCALE
736377	NE	KNOB
500539-004	NE	DIAL PLATE
393026-047	OH	FUEL QTY INDICATOR
393026-047	SV	FUEL QTY INDICATOR
WL203EED8	OH	INDICATOR
WL203EED8	SV	INDICATOR
9-116-02	OH	FUEL USED IND
9-116-02	SV	FUEL USED IND
8DJ125LXF4	OH	FLOWMETER INDICATOR
8DJ125LXF4	SV	FLOWMETER INDICATOR
8DJ339WAF1	OH	STANDBY ENG IND
8DJ339WAF1	SV	STANDBY ENG IND
622-5390-001	OH	VHF COMM FRES PANEL
622-5390-001	SV	VHF COMM FRES PANEL
622-6831-001	OH	VHF COMM PANEL
622-6831-001	SV	VHF COMM PANEL
393026-036	OH	FUEL QTY INDICATOR
393026-036	SV	FUEL QTY INDICATOR
2061-14-1	OH	FLAP POSITION IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2061-14-1	SV	FLAP POSITION IND
10-61926-4	OH	FLAP POSITION IND
10-61926-4	SV	FLAP POSITION IND
2061-13-1	OH	FLAP POSITION IND
2061-13-1	SV	FLAP POSITION IND
10-61926-3	OH	FLAP POSITION IND
10-61926-3	SV	FLAP POSITION IND
522-3487-002	OH	FLIGHT DIRECTOR INDICATOR
522-3487-002	SV	FLIGHT DIRECTOR INDICATOR
329B-7C	OH	FLIGHT DIRECTOR INDICATOR
329B-7C	SV	FLIGHT DIRECTOR INDICATOR
522-3667-001	OH	FLIGHT DIRECTOR INDICATOR
522-3667-001	SV	FLIGHT DIRECTOR INDICATOR
329B-7G	OH	FLIGHT DIRECTOR INDICATOR
329B-7G	SV	FLIGHT DIRECTOR INDICATOR
522-3700-004	OH	FLIGHT DIRECTOR INDICATOR
522-3700-004	SV	FLIGHT DIRECTOR INDICATOR
329B-8A	OH	FLIGHT DIRECTOR INDICATOR
329B-8A	SV	FLIGHT DIRECTOR INDICATOR
5036964-01	OH	FLIGHT DIRECTOR INDICATOR
5036964-01	SV	FLIGHT DIRECTOR INDICATOR
JG403B3	OH	FUEL QTY INDICATOR
JG403B3	SV	FUEL QTY INDICATOR
10-3065-258	OH	FUEL QTY INDICATOR
10-3065-258	SV	FUEL QTY INDICATOR
JG403B1	OH	FUEL QTY INDICATOR
JG403B1	SV	FUEL QTY INDICATOR
10-3065-256	OH	FUEL QTY INDICATOR
10-3065-256	SV	FUEL QTY INDICATOR
610BL24B	OH	TEMPERATURE IND
610BL24B	SV	TEMPERATURE IND
SEDL-OC9A	OH	DUAL DUCT PRESS IND
SEDL-OC9A	SV	DUAL DUCT PRESS IND
S231T245-2	OH	DUAL DUCT PRESS IND
S231T245-2	SV	DUAL DUCT PRESS IND
SR-04E	OH	DUAL DUCT PRESS IND
SR-04E	SV	DUAL DUCT PRESS IND
SR-O4E	OH	OIL PRESS IND
SR-O4E	SV	OIL PRESS IND
SEDL-OC9A	OH	DUAL DUCT PRESS IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
SEDL-0C9A	SV	DUAL DUCT PRESS IND
393026-03335	OH	FUEL QTY INDICATOR
393026-03335	SV	FUEL QTY INDICATOR
10-60520-27	OH	FUEL QTY INDICATOR
10-60520-27	SV	FUEL QTY INDICATOR
M9071-106	SV	HDG FLAG
482-5117-010	SV	HDG FLAG
2555440	NS	LEVEL SWITCH
2553765	NE	BRUSH BLOCK
2555483	NS	GEAR
2501538-2	SV	DC MOTOR
21107A-CY-04/D134	SV	DC MOTOR
21107A-CY-04/D425	SV	DC MOTOR
947283-3	SV	SYNCHRO
4000313-1	SV	MAG WHEEL IND
4017822-1	SV	MAG WHEEL IND
2594625-903	SV	RDDMI
2594625-903	OH	RDDMI
100925-3	SV	MAG WHEEL IND
1783636-27	SV	CONNECTOR
482-5051-010	SV	SPEED FLAG
MODEL 9833	SV	SPEED FLAG
196734-901	SV	GLIDE SLOPE
482-5002-000	SV	GLIDE SLOPE
MODEL 9880	SV	GLIDE SLOPE
196734	SV	GLIDE SLOPE
196978-901	SV	GLIDE SLOPE
482-5017-000	SV	GLIDE SLOPE
MODEL 9880	SV	GLIDE SLOPE
482-5013-000	SV	VOR-LOC FLAG
M9071-50	SV	VOR-LOC FLAG
1996581-1	SV	SWITCH BLOCK
2781630-1	SV	BOARD, DIODE MOUNTING
3585-02CN	SV	COIL, HELICAL
2781627-1	SV	COMPONENT ASSY
6SX1H58	SV	SWITCH , PUSH
1975214-2	SV	ROTARY SWITCH
1980959-1	SV	CLAMP
1996561-1	SV	CLAMP
1975194-1	SV	CLUTCH ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1975244-1	SV	SPUR GEAR
1967696-1	SV	CLUTCH , MAGNETIC
CK5020-10A1	SV	MOTOR, CONTROL
1928818-4	SV	MOTOR, CONTROL
772-5005-006	OH	FLIGHT DIRECTOR
772-5005-006	SV	FLIGHT DIRECTOR
772-5005-005	OH	FLIGHT DIRECTOR
772-5005-005	SV	FLIGHT DIRECTOR
622-5002-701	OH	FLIGHT DIRECTOR
622-5002-701	SV	FLIGHT DIRECTOR
1903585-3	SV	RADIO DISTANCE MAGNETIC IND
1903585-3	OH	RADIO DISTANCE MAGNETIC IND
622-6831-002	OH	VHF COMM PANEL
622-6831-002	SV	VHF COMM PANEL
8DJ81WAG2	OH	TACHOMETER INDICATOR
8DJ81WAG2	SV	TACHOMETER INDICATOR
152BL801E	OH	EGT INDICATOR
152BL801E	SV	EGT INDICATOR
162BL802	OH	OIL TEMPERATURE IND
162BL802	SV	OIL TEMPERATURE IND
501-1228-02	OH	EMERGENCY POWER SUPPLY
501-1228-02	SV	EMERGENCY POWER SUPPLY
393080-118	OH	TOTAL FUEL/V-REF IND
393080-118	SV	TOTAL FUEL/V-REF IND
GMT4190-053P2	SV	CARD PROCESSING
GMT4190-052P2	SV	CARD POWER SUPPLY
GMT4190-054P1	SV	CARD FILTER
116371	SV	CARD PROCESSING
GMT4190-053P2	SV	CARD PROCESSING
GMT4190-052P2	SV	CARD POWER SUPPLY
GMT4190-054P1	SV	CARD FILTER
116371	SV	CARD PROCESSING
2504468-3	SV	INDICATOR, LOC
2504468-2	SV	INDICATOR, RWY
2556535-901	SV	INCLINOMETER
2556535	SV	INCLINOMETER
393026-01837	OH	FUEL QUANTITY INDICTOR
393026-01837	SV	FUEL QUANTITY INDICTOR
393026-01838	OH	FUEL QUANTITY INDICTOR
393026-01838	SV	FUEL QUANTITY INDICTOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
393026-01840	OH	FUEL QUANTITY INDICTOR
393026-01840	SV	FUEL QUANTITY INDICTOR
393026-002	OH	FUEL QUANTITY INDICTOR
393026-002	SV	FUEL QUANTITY INDICTOR
393026-01880	OH	FUEL QUANTITY INDICTOR
393026-01880	SV	FUEL QUANTITY INDICTOR
393026-03235	OH	FUEL QUANTITY INDICTOR
393026-03235	SV	FUEL QUANTITY INDICTOR
393026-03236	OH	FUEL QUANTITY INDICTOR
393026-03236	SV	FUEL QUANTITY INDICTOR
393026-03335	OH	FUEL QUANTITY INDICTOR
393026-03335	SV	FUEL QUANTITY INDICTOR
393026-037	OH	FUEL QUANTITY INDICTOR
393026-037	SV	FUEL QUANTITY INDICTOR
393206-037	SV	FUEL QUANTITY INDICTOR
393026-069	OH	FUEL QUANTITY INDICTOR
393026-069	SV	FUEL QUANTITY INDICTOR
393026-077	OH	PRECAL FUEL QTY IND
393026-077	SV	PRECAL FUEL QTY IND
393026-078	OH	FUEL QUANTITY INDICTOR
393026-078	SV	FUEL QUANTITY INDICTOR
393080-103	OH	FUEL QUANTITY INDICTOR
393080-103	SV	FUEL QUANTITY INDICTOR
10-61371-3	OH	FUEL QUANTITY INDICTOR
10-61371-3	SV	FUEL QUANTITY INDICTOR
393084-04359	OH	OIL QTY IND
393084-04359	SV	OIL QTY IND
10-60722-5	OH	OIL QTY IND
10-60722-5	SV	OIL QTY IND
393086-01236	OH	OIL QTY IND
393086-01236	SV	OIL QTY IND
10-60520-5	OH	OIL QTY IND
10-60520-5	SV	OIL QTY IND
393086-01508	OH	OIL QTY IND
393086-01508	SV	OIL QTY IND
10-60520-23	OH	OIL QTY IND
10-60520-23	SV	OIL QTY IND
69B46116-11	OH	MOD ASSY, DC METERS
69B46116-11	SV	MOD ASSY, DC METERS
2594621-917	OH	AIRSPEED/MACH INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2594621-917	SV	AIRSPED/MACH INDICATOR
4004255-901	OH	ATTITUDE DIRECTOR IND
4004255-901	SV	ATTITUDE DIRECTOR IND
8DJ81WAG2	OH	TACHOMETER INDICATOR
152BL801E	OH	EGT INDICATOR
162BL802	OH	OIL TEMPERATURE INDICATOR
393080-118	OH	TOTAL FUEL/V-REF IND
8DJ81WAG2	SV	TACHOMETER INDICATOR
152BL801E	SV	EGT INDICATOR
162BL802	SV	OIL TEMPERATURE INDICATOR
393080-118	SV	TOTAL FUEL/V-REF IND
2854292178	NS	LIGHT PANEL
GCC11-13P4	SV	ENCODER
3499134	SV	ENCODER
778-1306-001	NS	SCALE, SPEED
778-1306-001	SV	SCALE, SPEED
50YY29101	SV	ROTARY SWITCH
259-2900-150	SV	ROTARY SWITCH
50YY29101	NE	ROTARY SWITCH
259-2900-150	NE	ROTARY SWITCH
609-3175-002	SV	SCALE GLIDESLOPE
11-0368-25NF	SV	EXIT LIGHT COVER
10-60991-49	SV	EXIT LIGHT COVER
22800B3	NS	RESISTOR
989995-1	NS	DIAL
1765603-1	NS	RESISTOR
1215813-1	NS	RESISTOR
1804181-2	NS	RESISTOR
351-8766-011	NS	MICROCIRCUIT
2594625-903	SV	RMI INDICATOR
40-60V5M1	SV	ADI
2594624-912	SV	H.S.I.
64878-000-1	SV	DUAL PRESS EMG IND
65691-204-1	SV	N1 INDICATOR
2594625-903	OH	RMI INDICATOR
40-60V5M1	OH	ADI
2594624-912	OH	H.S.I.
64878-000-1	OH	DUAL PRESS EMG IND
65691-204-1	OH	N1 INDICATOR
DNM100-082	SV	MODULE LCD



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
61YY11002-7	SV	ENCODER
H4281N1	NS	ANNUNCIATOR
2501463-14	NS	ANNUNCIATOR
900-12597-4	SV	ENCODER
900-12376-1	SV	MODULE LCD
900-12376-1	SV	MODULE LCD
797-2482-001	SV	PCB ASSY
618-3577-002	SV	ATTITUDE BOARD
797-2484-003	SV	CCA, RUNWAY (A5)
763-5909-001	SV	TRANSFORMER
526-0348-010	SV	TRANSFORMER
TF5T03ZZ	SV	TRANSFORMER
797-2486-003	SV	POWER SUPPLY
629-8391-001	SV	POWER SUPPLY
609-3291-001	SV	MASK
609-3189-001	SV	SCALE GS
482-5150-010	SV	METER MOVEMENT
482-5145-020	SV	METER MOVEMENT
482-5148-010	SV	METER MOVEMENT
609-4192-004	SV	CASE ASSY
482-5152-010	SV	METER MOVEMENT
482-5144-010	SV	METER MOVEMENT
482-5143-010	SV	METER MOVEMENT
482-5147-030	SV	METER MOVEMENT
482-5151-010	SV	METER MOVEMENT
797-2482-001	SV	PCB ASSY
618-3577-002	SV	ATTITUDE BOARD
797-2484-003	SV	PCB ASSY
763-5909-001	SV	TRANSFORMER
526-0348-010	SV	TRANSFORMER
TF5T03ZZ	SV	TRANSFORMER
797-2486-003	SV	POWER SUPPLY
629-8391-001	SV	POWER SUPPLY
609-3291-001	SV	MASK
609-3189-001	SV	SCALE GS
482-5150-010	SV	METER MOVEMENT
482-5145-020	SV	METER MOVEMENT
482-5148-010	SV	METER MOVEMENT
609-4192-004	SV	CASE ASSY
482-5152-010	SV	METER MOVEMENT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
482-5144-010	SV	METER MOVEMENT
482-5143-010	SV	METER MOVEMENT
482-5147-030	SV	METER MOVEMENT
482-5151-010	SV	METER MOVEMENT
772-5370-003	OH	COURSE INDICATOR
772-5370-003	SV	COURSE INDICATOR
772-5370-005	OH	COURSE INDICATOR
772-5370-005	SV	COURSE INDICATOR
772-5431-001	OH	FLIGHT DIRECTOR IND
772-5431-001	SV	FLIGHT DIRECTOR IND
772-8797-001	NS	SPRING HELICAL
772-8797-001	NS	SPRING HELICAL
775-5034-001	SV	GEAR
775-5034-001	SV	GEAR
775-5739-002	SV	TAPE ROLLER ASSY
775-5739-002	SV	TAPE ROLLER ASSY
622-3371-001	SV	TRANSMITER
618-3577-004	SV	PC BOARD
618-3577-005	SV	PC BOARD
382-0028-010	SV	VARIABLE RESISTOR
55FL1-109	SV	VARIABLE RESISTOR
1020-553	SV	VARIABLE RESISTOR
659-8322-001	SV	CASE ASSY
659-8315-001	SV	CASE ASSY
659-8320-001	SV	CASE ASSY
5906-10097-101	SV	PANEL ASSY
285U0038-32	SV	PCB ASSY
285U0040-18	SV	PCB ASSY
900-12597-4	SV	ENCODER
61YY11002-7	SV	ENCODER
285U0039-14	SV	PLATE ASSY
285U0051-3	SV	PLATE ASSY
55FL1-109	SV	VARIABLE RESISTOR
1020-553	SV	VARIABLE RESISTOR
659-8322-001	SV	CASE ASSY
659-8315-001	SV	CASE ASSY
659-8320-001	SV	CASE ASSY
5906-10097-101	SV	PANEL ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
285U0038-32	SV	PCB ASSY
285U0040-18	SV	PCB ASSY
900-12597-4	SV	ENCODER
61YY11002-7	SV	ENCODER
285U0039-14	SV	PLATE ASSY
285U0051-3	SV	PLATE ASSY
522-4363-007	OH	RADIO ALTITUDE IND
522-4363-007	SV	RADIO ALTITUDE IND
339H-1B	OH	RADIO ALTITUDE IND
339H-1B	SV	RADIO ALTITUDE IND
522-4363-004	OH	RADIO ALTITUDE IND
522-4363-004	SV	RADIO ALTITUDE IND
4028193-901	SV	POWER SUPPLY
7822031	NS	PLATE
782276-1	NS	STATOR
779-3516-001	NS	GEAR
778-1346-001	NS	COMMAND BAR
778-1344-001	NS	COMMAND BAR
7834K73P010	NS	SPACER
7834K72P043	NS	SPACER
7762W10P001	NS	SOCKET
F611-1	OH	FLAP POSITION IND
F611-1	SV	FLAP POSITION IND
10-0067-9	OH	EMERGENCY EXIT LIGHT
10-0067-9	SV	EMERGENCY EXIT LIGHT
10-60091-101	OH	EMERGENCY EXIT LIGHT
10-60091-101	SV	EMERGENCY EXIT LIGHT
55806-270-1	SV	LCD DISPLAY
DND100-271	SV	LCD DISPLAY
A1123973	SV	CONNECTOR FLEX
55806-740-1	SV	BEZEL
622-6830-001	OH	ADF FREQUENCY PANEL
622-6830-001	SV	ADF FREQUENCY PANEL
100-003-182-001	SV	DISPLAY
100-003-182-001	SV	DISPLAY
2594621-913	SV	MACH AIRSPEED
2594621-913	OH	MACH AIRSPEED
4057800-901	SV	MACH AIRSPEED



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4057800-901	OH	MACH AIRSPEED
2045-06-1	SV	MACH AIRSPEED
2045-06-1	OH	MACH AIRSPEED
95F212-4	OH	GENERATOR CONTROL
95F212-4	SV	GENERATOR CONTROL
4005123-907	OH	ALTIMETER
4005123-907	SV	ALTIMETER
482-5101-010	SV	METER FLAG "RUNWAY"
241010-130	SV	METER FLAG "RUNWAY"
8DJ164LWV2	OH	FUEL FLOW IND
8DJ164LWV2	SV	FUEL FLOW IND
2067635-0706	OH	ALTIMETER INDICATOR
2067635-0706	SV	ALTIMETER INDICATOR
1NA-51A	OH	ALTIMETER INDICATOR
1NA-51A	SV	ALTIMETER INDICATOR
2594620-915	OH	BAROMET ALTITUDE IND
2594620-915	SV	BAROMET ALTITUDE IND
255302-5	OH	DIRECTIONAL GYRO
229-0245-00	SV	SYNCHRO RECEIVER
229-0245-000	SV	SYNCHRO RECEIVER
2400-3	NE	SWITCH
797-3567-005	SV	DME BOARD
621-1523-001	SV	BOARD ASSY
JG298A4	SV	PRESSURE RATION IND
JG298A4	OH	PRESSURE RATION IND
55806-964-2	SV	BOARD
55806-982-03	SV	BOARD
55806-973-4	SV	BOARD
55806-992-1	SV	PCB POWER SUPPLY
55806-911-1	SV	BOARD
50YY23566	SV	SWITCH
8YY23955	SV	SWITCH
57351-307-1	SV	SWITCH
646-8257-001	SV	CIRCUIT, CARD
646-5179-005	SV	CIRCUIT, CARD ASSY
837-2001-07	SV	SWITCH ROTARY
4003734-901	OH	RMI
4003734-901	SV	RMI



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
RH-551C	OH	RMI
RH-551C	SV	RMI
JG141A2	OH	FUEL QTY INDICATOR
JG141A2	SV	FUEL QTY INDICATOR
4002001-1	SV	INDICATOR, FLAG
4000440-1	SV	MONITOR
4000440-901	SV	MONITOR. MODULE
4000440-901	SV	MONITOR. MODULE
18-36480A01	NS	SINE/COSINE POT
4016460-1	SV	MONITOR. MODULE
ERH-10-DUS-04/B924	SV	SYNCHRO RECEIVER
SR2ARHH5P24	NS	BEARINGS
15DO22A016	NS	BEARINGS
APE4190-014	SV	CLOCK
APE4190-014	OH	CLOCK
6107W14P003	SV	RELAY
6900W12P006	SV	IC
2341W26P002	SV	CLAMP
000300-1539	SV	SOCKET RELAY
001-312-2	SV	BLADE NOTCHED
0-25-3SS	SV	BALL
00016-0001-001	SV	SUPPORT BLOCK
00110420002	SV	PIN, MALE
005-0669-000	SV	ADHESIVE
005-1154-490	SV	ENAMEL, AMBER
005-2030-030	SV	EPOXY
005-2030-030	SV	EPOXY
006-1-0	SV	ADAPTER
006-1-0	SV	ADAPTER
006-4004	SV	JACK
006-4004	SV	JACK
010110-1	SV	TEMPERATURE RECORDER
010110-1	SV	TEMPERATURE RECORDER
010110-2	SV	TEMPERATURE RECORDER
0134-PL	SV	DB-37-HOOD
015-2027-000	SV	BRUSHES
0164-13	SV	LOCK WASHER
019-07246-000	SV	TRANSFORMER
01F965	SV	TRANSFORMER
01F384	SV	TRANSFORMER
020885	SV	CAPACITOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
020886	SV	CAPACITOR
020887	SV	CAPACITOR
025-1155-001	SV	DUST CAP
030-2259-000	SV	PIN (MALE)
030-2409-001	SV	PINS
030-2409-001	SV	PINS
030-2409-003	SV	CONTACT
030-2409-003	SV	CONTACT
030-2491-001	SV	SOCKETS
030-2491-001	SV	SOCKETS
031-9074-002	SV	PIN
031-9134-001	SV	PINS
031-9134-004	SV	SOCKET
031-9206-004	SV	SOCKET
033108-001	SV	DIODE
03335	SV	DIAL
035149	SV	SCREW
0363-RG	SV	REGULATOR
036629-718	SV	DIODE
039-0187	SV	PIN
03F604	SV	TRANSFORMER
03F6610	SV	TRIMMER
04-1061-00	SV	LCD DISPLAY
043P103	SV	TRIMMER RESISTOR
043P203	SV	TRIMMER RESISTOR
043P502	SV	TRIMMER
043P503	SV	TRIMMER
04410809	SV	TAP
04420808	SV	TAP
0450-7	SV	PIN
0453-128	SV	SCREW
0453-220	SV	SCREW
0468.500	SV	FUSE
05F1432	SV	TRANSFORMER
05F301	SV	TRANSFORMER
060R0050U	SV	RESETTABLE PTC
06F664	SV	DISPLAY
07187-603999	SV	TRANSFORMER
07187-603999	SV	TRANSFORMER
0770-3	SV	WASHER
08F6425	SV	SEMICONDUCTOR
08F700	SV	POTENTIOMETER
08F715	SV	POTENTIOMETER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
08SM260-6	SV	SERVO MOTOR
08YY23955D	SV	SWITCH ROTARY
0A2WA	SV	VACUM TUBE
0B2WA	SV	VACUM TUBE
1.5KE11	SV	DIODE
10-60479-115	SV	CONNECTOR
10-60479-116	SV	CONNECTOR
10-78-2592	SV	RESISTOR
1000364	SV	TERMINAL
1000364	SV	TERMINAL
10022335-101	SV	POINTER ASSY
10022348-102	SV	INSTRUCTION PLATE
100224-01-01	SV	PCB ASSY, DRIVR
10023325-101	SV	DIAL
10023327-101	SV	DIAL
10023329-101	SV	DIAL
1002760	SV	ID PLATE
1002761	SV	ID PLATE
10030152-101	SV	DIAL
10032660-103	SV	GEAR
10033071-101	SV	CLUTCH
10033705-101	SV	LAMP
10E01-6	SV	LENS
100KOHM10TURN	SV	POTENTIOMETER
100OHM10TURN	SV	POTENTIOMETER
1010-2	SV	SHIM STOCK
1010B	SV	VARIAC
101123	SV	COUPLING ASSY
101124A	SV	SWITCH
101124B	SV	SWITCH
101125A	SV	SWITCH
101172	SV	RESISTOR
1077-1-159	SV	ACTUATOR
108-0007-EVX	SV	SWITCH, TOGGLE
108-0029-EVX	SV	SWITCH, MIN
108-0302-001	SV	BANANA PLUG
108-0303-001	SV	BANANA PLUG
736913	SV	SLIP RING ASSY
1H5GT	SV	VACUUME, TUBE
100-19	SV	POTENTIOMETER
500OHM1TURN	SV	POTENTIOMETER
5987	SV	VACUUME, TUBE
609-8072-001	SV	POWER SUPPLY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
280195	SV	BRUSHES
8107305ADP5	SV	BRUSHES
8107305	SV	BRUSHES
6841008625	SV	POTENTIOMETER
000300-1539	SV	SOCKET RELAY
001-312-2	SV	BLADE NOTCHED
005-0569-000	NE	ADHESIVE
019-07246-0000	SV	TRANSFORMER
030-9081-000	SV	PIN CONTACT
07187-603999	SV	TRANSFORMER
0A2WA	SV	TUBE
0B2WA	SV	TUBE
1-040-0003	NS	VIBRATION MONITOR
10-61800-1504	NS	LIGHTPLATE
1000364	SV	TERMINAL
10022335-101	NS	POINTER ASSY
10024188-101	NS	DIAL SCALE
10033071-101	SV	CLUTCH
10060-7	NS	GLOBAL NAV
1023K71P001	SV	ADAPTER
1025700-13	NS	CIRCUIT CARD
10400	NS	REGULATOR
10400-13	NS	DILUTER
1045-109B	SV	KNOB
1045-387B	SV	KNOB
10M-101-B-1	NS	SERVO MOTOR
1229752-1	SV	TRANSFORMER
1231438-1	SV	TRANSFORMER
1235750-1	NS	TRANSFORMER
1239751-1	SV	TRANSFORMER
124-836	SV	WATTMETER
124.514-1	SV	IND
124.514-1	SV	IND
124.514-1	SV	EGT INDICATOR
124.832	SV	IND
124.833	SV	IND
124.833	SV	IND
124.833	SV	DC VOLTMETER
124.834	SV	IND
124.834	SV	IND
124.834	SV	DC AMMETER
124.836	SV	IND
124.836	SV	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
124.837	SV	IND
124.837	SV	IND
124.837	SV	AC AMMETER
1244259-3	SV	RELAY
1252699-15	SV	THERMAL RELAY
1255097-1	SV	COVER
1267753-1	SV	RELAY
1278401-1	SV	ROTOR
1293564-1	SV	BRACKET
13504-001	SV	MATRIX SWITCH
136224-001	SV	WINDOW
1426-29D-B17	NS	AIRPEED INDICATOR
1426-47J-B17	OH	AIRPEED INDICATOR
147BDL2	SV	TEMPERATURE IND
147BL701	OH	TEMP INDICATOR
147BL702	OH	AIR TEMP INDICATOR
147D2	SV	OIL TEMP RISE IND
148231-01	SV	VARIABLE RESISTOR
149150-01-01	SV	ATTITUDE DIRECT IND
149150-01-02	SV	ATTITUDE DIRECT IND
149155-01-01	SV	IND
149155-01-01	SV	IND
149270-05-01	SV	TAT/EPR LIMIT IND
149270-05-01	SV	TAT/EPR LIMIT IND
149270-05-01	SV	TAT/EPR LIMIT IND
152BL702	SV	E.G.T. INDICATOR
152BL702	OH	EGT INDICATOR
152BL702D	SV	INDICATOR
152BL702E	SV	IND
152BL702E	SV	IND
152BL702E	SV	E.G.T. INDICATOR
152BL705A	SV	IND
152BL705A	SV	IND
152BL705A	SV	EGT INDICATOR
152BL705H	SV	IND
152BL705H	SV	IND
152BL705H	SV	EGT INDICATOR
152BL705L	SV	IND
152BL705L	SV	IND
152BL705L	SV	EGT INDICATOR
152C4E	OH	EXH TEMP
154BL702E	SV	EGT INDICATOR
157405-02-01	SV	TAT-ENG N1 LIMIT IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
157405-02-01	SV	TAT-ENG N1 LIMIT IND
157-887V1	SV	BOARD
160015-5	SV	WATER PUMP ASSY.
162BCL10	SV	IND
162BCL10	SV	IND
162BCL10	SV	OIL TEMPERATURE IND
162BCL11	OH	CABIN TEMP INDICATOR
162BL704C	SV	IND
162BL704C	SV	IND
162BL704C	SV	OIL TEMP. INDICATOR
162C23B	OH	ENG. TEMP INDICATOR
1636-6A-B1	OH	VERTICAL SPEED IND.
165-73-1001X	SV	CONNECTOR
1701115	SV	GASKET
1724T024S	SV	MOTOR
175-26W603	SV	PLATE
1755606	SV	BLOCK
1755606	SV	BLOCK
1776365-924	SV	HORIZON IND.
1776366-601	SV	PICTORIAL DEV.IND
1778686-655	SV	IND
1778686-655	SV	IND
1778686-655	SV	GYROSYN COMPASS IND
1783867-1	SV	AMPLIFIER
1783867-1	SV	AMPLIFIER
1783867-1	SV	SERVO AMPLIFIER
1784460-355	SV	IND
1784460-355	SV	INDICATOR
1784460-355	SV	IND
1784460-355	SV	GYROSYN COMPASS IND
1784460-656	SV	IND
1784460-656	SV	GYROSYN COMPASS IND
1784460-656	SV	GYROSYN COMPASS IND
1784460-656	OH	GYROSYN COMPASS IND
1784460-656	OH	GYROSYN COMPASS IND
1784460-656	OH	GYROSYN COMPASS IND
18-1299-3	SV	IND
18-1299-3	SV	IND
18-1299-3	SV	FLAP POSITION IND
1877874-1	SV	FLAG ASSY
1889366-3	NS	LENS
192-2004-010	NS	GLASS
192-2010-001	NS	WEDGE LIGHTING



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
19200-1	NS	PERCENT SPEED IND
19200-3	NS	PERCENT SPEED IND
193333-904	NS	FLAG
1986462-1	NS	DIAL
1988990-1	NS	DIAL
1988991-1	NS	DIAL
1988992-1	NS	DIAL
1988993-1	NS	DIAL
19GE331	SV	GEAR
1BA60	SV	ASSY
1U320-001-11	OH	TACH INDICATOR
1U320-001-11	OH	TACHOMETER IND
200-001-003W	SV	IND
200-002-001	SV	IND
200-002-001	SV	TAG '09 /18 MNTH WTY
200-002-001	SV	IND
200-002-001	SV	FUEL QTY IND
200-007-005	SV	HYD FLUID QTY IND
200-007-005	SV	HYD FLUID QTY IND
200-007-005	SV	HYD FLUID QTY IND
2000075-1	OH	DIAL
202-1A5A5K	OH	TEMPERATURE IND
203054-L	SV	BEARING
203221	SV	CONTACT SLEEVE
2057-01-1	SV	ALTITUDE IND
206-001-003W	SV	INDICATOR
206-001-003W	SV	IND
206-001-003W	SV	FUEL QTY IND
2061-13-1	OH	FLAP POSITION IND
2067635-0701	SV	IND
2067635-0701	SV	IND
2068860-0001	OH	RELAY
2070-03-1	SV	IND
2070-03-1	SV	IND
2070-03-1	SV	VERTICAL SPEED IND
2083-11-1	SV	INDICATOR
2083-11-1	SV	INDICATOR
2083-11-1	SV	INDICATOR
2092-01-1	SV	RPM INDICATOR
2092-02-1	OH	RPM INDICATOR
21607A-CY-04/D430	OH	MOTOR, DC
21607A-CY-04/D539	OH	MOTOR, DC
21607ACY04D576	OH	MOTOR, DC



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
21607ACY04D593	OH	MOTOR, DC
217-03221	SV	TORQUE PRESS IND
2187K10G700	OH	CASE ASSY, LOWER
22-995-06-1	OH	AIR TEMP IND
225010-035	OH	METER MOVEMENT
225010-039	OH	METER MOVEMENT
229-2050-010	OH	MOTOR-TACH GEN
229-3044-010	OH	SYNCHRO TRANSMITTER
229-6026-020	OH	SYNCHRO
230967	SV	ANVIL
241235	SV	LATCH
24128-1	OH	DIAL
243005-103	SV	METER
243005-103	SV	METER
243005-103	OH	IND KW
248640	OH	RIVET
248697	SV	LOADMETER
248697	SV	LOADMETER
248697	SV	DUAL LOADMETER
248992	OH	SPEED FLAG
25-0037-1	SV	LENS FILTER
2500150-33	NS	CAPACITOR
2500276-102	SV	TERMINAL BOARD
2500276-105	SV	TERMINAL BOARD ASSY
2500277-27	SV	CONNECTOR
2500391	NS	I.C.
2501444-4	NE	LAMP
2501592-1	NS	SYNCHRO
2501597-1	NS	TRANSOLVER
2501599-1	NS	SYNCHRO
2575929-910	NS	F/D CONTROL PANEL
2579272	SV	SWITCH
2579442-1	SV	STUD
2579765-1	SV	GEAR
2582922	SV	LEAD ASSEMBLY
2582978-1	SV	PRINTED CABLE ASSY
2582978-2	SV	PRINTED CABLE ASSY
2582978-3	SV	PRINTED CABLE ASSY
2585703	NS	SLAVING AMPLIFIER
2586894	SV	FRAME
2588369-902	SV	IND
2588369-902	SV	IND
2588371-901	SV	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2588371-901	SV	IND
2588371-901	SV	RADIO DIRECTION IND
2588381-901	SV	IND
2588381-901	SV	IND
2588381-901	SV	GYROSAN CMPASS IND
2589112-905	SV	IND
2589112-905	SV	IND
2589112-905	SV	HORIZ FLT DIRECT IND
2589150-904	NS	CAPACITOR CARD
2589804-904	NS	AMPLIFIER CARD
259-9670-030	SV	SWITCH
2591149	SV	GUIDE
2591439-901	NS	MODE SELECT PANEL
2591439-903	NS	COURSE MODULE ASSY
2591464	NS	A/T MOD CONTROL
2591485	NS	MODE SELECT PANEL
2591603-901	NS	SOLENOID DRIVER MODU
2591603-903	NS	SOLENOID MODULE ASSY
2591780-902	NS	V/S MODULE ASSY
2591852	NS	HEADING MODULE ASSY
2592668	SV	BRUSH BLOCK
2592838-901	SV	PICT. DIVIAT. IND.
2593200-951	SV	COMP
2593200-951	SV	COMP
2593200-951	SV	AIR DATA COMPUTER
2593368	NS	A/P COMMAND MODULE
2593842-901	NS	CONTROL MODULE ASSY
2594620-905	SV	IND
2594620-905	SV	IND
2594625-901	OH	RADIO DIGITAL DISTAN
2594943-901	OH	SP-COMM MODULE ASSY
2594964-901	OH	PITCH F/D SUMP AMP M
260909	SV	IND
260909	SV	IND
260909	SV	VALVE POSITION IND
262-0441-010	NS	DISPLAY MODULE
266-0140-000	NS	ADAPTER
266-7112-060	NS	LENS
266-7142-050	NS	SWITCH PUSHBUTTON
266-7566-010	NS	PUSH SWITCH
267004-024	NS	MOTER MOVENT
26V08RT4B-02	NS	SYNCHRO TRANSMITER
27ET29-T	NS	SWITCH, TOGGLE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
281-0661-070	SV	KNOB
281-0661-210	SV	KNOB
281-0661-220	SV	KNOB
281-0661-430	SV	KNOB
281-0670-020	SV	KNOB
281-0670-0301	SV	KNOB
285T00017-104	SV	POWER SUPPLY MOD ASY
285T0017-103	SV	POWER SUPPLY MODULE
285T0017-103	SV	MODULE
285T0017-103	SV	MODULE
285T1201-1	OH	PANEL
2965007	OH	STATOR
309-1953-020	OH	BEARING BALL
310933-01	OH	TRANSFORMER
3132W73P001	OH	SCALE PLATE
3133W11P001	OH	SCALE PLATE
3133W62P001	OH	SCALE PLATE
321-0409-000	OH	SCREW MATCH SST
321070	NS	CAP
328-0368-000	NS	SET SCREW
328-0371-000	NS	SETSCREW
330813	SV	COVER ACCESS
3310-00001	OH	RPM INDICATOR
334-0287-000	NS	NUT
335-0005-000	NS	SET SCREW
335-0133-000	NS	SET SCREW
335-101	OH	PANEL, PILOT CALL
3382W23G702	OH	BOARD ASSY
3382W25G702	OH	BOARD ASSY
33K5	SV	BEARING
340-0112-000	NS	RING RETAINER
340-0113-000	NS	RING RETAINER
350-0093-010	SV	IC
350-0095-010	SV	DIFF. SENSOR
350-0103-010	NS	ERROX AMPLIFIER
350-0116-010	NS	IC AMP
350-9056-010	NS	IC NET.VLT
350-9060-010	NS	IC ERROR MONITOR
3511-180-41662	NS	TAPE
3511-180-42122	NS	TAPE, ALTITUDE
35AV1350A2	SV	RELAY
36135-1S-19-B1	OH	RADIO MAG IND
367-1009-01	NS	'O' RING



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
37-3-2125	SV	NUT
3759028-6	SV	PANEL
3759028-6	SV	PANEL
3759028-6	SV	PITCH CONTROL PANEL
3759082-6	SV	CONTROL PANEL, PITCH
3759082-6	OH	CONTROL PANEL, PITCH
3798055-1	OH	RATE GYRO
383056-06835	OH	OIL QTY
3830K75P001	NS	GASKET
3830K75P003	NE	GASKET
383156	NE	CONNECTOR
383177	NE	GEAR ASSY
383269	NE	GEAR ASSY
3881K78G701	NS	GEAR ANS SHAFT ASSY
3894W13P004	NS	GEAR
3894W15P004	NS	GEAR
3899W22P006	NS	GEAR
3899W22P007	NS	GEAR
393004-099	NS	FUEL QUANTITY IND.
393004-63421	SV	FUEL QUANTITY IND
393020-01789	SV	IND
393020-01789	OH	INDICATOR
393020-01789	OH	IND
393020-01789	OH	OIL QTY IND
393020-01789	OH	OIL QTY IND
393024-03842	OH	ENG OIL IND
393026-03236	OH	IND
393026-03236	OH	FUEL QUANTITY IND
393026-03236	OH	FUEL QUANTITY IND
393026-03508	OH	FRESH TAG/18 MNTH WTY
393026-03508	SV	FUEL QTY INDICATOR
393026-03508	SV	FUEL QUANTITY IND
393020-01789	SV	OIL QTY IND
393020-01789	SV	OIL QTY IND
393024-03842	SV	ENG OIL IND
393026-03236	SV	IND
393026-03236	SV	FUEL QUANTITY IND
393026-03236	SV	FUEL QUANTITY IND
393026-03508	OH	FRESH TAG/18 MNTH WTY
393026-03508	SV	FUEL QTY INDICATOR
393026-03508	SV	FUEL QUANTITY IND
393026-042	SV	IND
393026-042	SV	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
393026-042	OH	FUEL QTY IND
393026-042	OH	FUEL QUANTITY IND
10-60520-50	OH	FUEL QTY IND
10-60520-50	SV	FUEL QUANTITY IND
393026-079	SV	IND
393026-079	SV	IND
393026-079	SV	PRECAL FUEL QTY IND
393026-079	SV	FUEL QUANTITY IND
393026-080	SV	IND
393026-080	SV	IND
393026-080	SV	PERCAL FUEL QTY IND
393026-080	SV	FUEL QUANTITY IND
393028-10645	SV	HYD QTY IND
393080-104	SV	TOTAL FUEL /V-REF IN
393080-104	OH	TOTAL FUEL/R REF IND
10-61371-4	SV	TOTAL FUEL /V-REF IN
10-61371-4	OH	TOTAL FUEL/R REF IND
393081-103	SV	IND
393081-103	SV	IND
393081-103	SV	FUEL QTY TOTALIZ IND
393081-103	SV	FUEL QTY TOTALIZ IND
393081-105	SV	IND
393081-105	SV	IND
393081-105	SV	FUEL QTY TOTALIZ IND
393081-105	SV	FUEL QTY TOTALIZ IND
393090-103	SV	PRIMARY FUEL QTY IND
393090-103	OH	PRIMARY FULE ATI IND
393090-105	SV	IND
393090-105	SV	IND
393090-105	SV	PRIMARY FUEL QTY IND
393090-107	SV	IND
393090-107	SV	IND
393090-107	SV	PRIMARY FULE QTY IND
393090-107	SV	PRIMARY FUEL QTY IND
393103-107	SV	TAT/RATED EPR IND.
393103-109	SV	IND
393103-109	SV	IND
393103-109	SV	EPR INDICATOR
396-100P1-D1	SV	OIL PRESSURE IND
3S2791G200R11	NE	RELAY
3SM	NS	BULB ASSY
40-300-1	SV	STATIC AIR TEMP IND
40-300-1	SV	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
40-300-1	SV	IND
40-300-1	SV	STATIC AIR TEMP IND
40-302-101	NS	LIGHT ASSY
40-302-4	SV	TOTAL AIR TEMP IND
40-309-1	SV	TRUE AIRSPEED IND
40-309-1	SV	TRUE AIRSPEED IND
40-309-1	SV	TRUE AIRSPEED IND
40-652-2162	NE	IC
4000052-1	NE	PANEL SMOKE DETCTR
4000136	SV	TRANSFORMER
4003434-902	NS	MODULE ASSY
4004028	NS	GLASS
4004744-1	NS	TRANSOLVER
4004744-2	NS	TRANSOLVER
4005123-901	SV	ALTIMETER
4005123-901	SV	ALTIMETER
4005123-901	SV	ALTIMETER
4012663-904	OH	DETECTOR AMPLIFIER
4015991-901	SV	POWER SUPPLY
4016461-1	NS	SYNCHRO
4031660-2	NS	WEDGE
4039572-1	NS	RESOLVER
4039838-1	NS	MOTOR, DC
4039892-906	SV	BAROMETRIC ALTIMETER
4039892-906	SV	BAROMETRIC
4039892-908	SV	ALTIMETER
4039892-908	SV	ALTIMETER
4039892-908	SV	BAROMETRIC ALTIMETER
4039892-909	SV	BAROMETRIC ALTIMETER
4039892-909	SV	BAROMETRIC ALTIMETER
4039892-909	SV	BAROMETRIC ALTIMETER
4039892-911	SV	BAROMETRIC ALTIMETER
4039893-90	SV	VERTICAL SPEED IND
4039893-902	SV	VERTICAL SPEED IND
4039893-902	SV	VERTICAL SPEED IND
4039893-902	SV	IND
4039893-903	SV	IND
4039893-903	SV	IND
4039893-903	SV	VERTICAL SPEED IND
4039893-903	SV	VERTICAL SPEED IND
4043124-903	NS	ANALOG OUTPUT CARD
4043126-901	NS	CIRCUIT CARD
4043128-901	NS	BOARD ASSY
4043128-902	NS	MEMORY I/O CARD



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4043132-901	NS	BOARD ASSY
4043134-903	NS	BOARD ASSY
4043142-901	SV	DIAL
4043173-903	NS	BEZEL
4043194	NS	SHAFT
4043495-1	NS	CASE
4043517-902	OH	INDICATOR
4045190-403	NS	PROGRAM IC
4045190-404	NS	PROGRAM IC
4045190-405	NS	PROGRAM IC
4045190-406	NS	PROGRAM IC
405876	SV	CONTROL PANEL
405876	OH	CONTROL PANEL
406809	NS	MOTOR
407-312-0023	NS	WINDOW
407857	SV	IND CONTROL PANEL
407857	SV	IND
407857	SV	IND
407857	SV	CONT PANEL IND
408-1159-020	SV	RELAY
4145811P008	SV	CONNECTOR/RECEPTICLE
4136822G004	SV	CONNECTOR ASSY
41470	SV	JEWELL ASSY
4149899G004	NS	JEWEL HOLDER ASSY
417237	SV	TERMINAL
42-27-04-011	SV	DUMMY CASING
42-27-11-011	SV	CAM 5 DEG.
42-89-13-48	SV	DRUM
421503T1	NS	DIAL
433-673-1004-4060	NS	SWITCH LIGHTED PUSH
4381W10P001	SV	HUB
44456	SV	HEIGHT INDICATOR
445604-3	SV	TRANSFORMER
448769	NE	SEALING RING
451778	SV	REACTOR
452525	NE	PIN
455354	SV	DIAL
456764-3	SV	SHAFT ASSY
456764-31	SV	SHAFT
456764-9	SV	SHAFT
458992	SV	BEARING PLATE
46-982-1	SV	CONNECTOR
463404-01235	SV	LIGHTING ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
463404-02237	NS	MOD KIT W/O TRANS.
463405-042	NS	DIAL
463405-047	NS	DIAL SCALE
463405-052	NS	DIAL, SCALE
463694	NS	TRANSFORMER
463694	NS	TRANSFORMER
463695	NS	TRASFORMER
463704	NS	PC BOARD
463738-052	NS	GEAR ASSY
463750	NS	WASHER
463750	NS	WASHER SEALING
463751	NS	POST
463751	NS	POST
463790	NS	PC BOARD ASSY
463790	NS	PC BOARD ASSY
463803-047	NS	TRANSFORMER
463803-047	NS	TRANSFORMER
463935	NS	COVER END PLATE
463935	NS	COVER, END PLATE
463939	NS	COUNTER
463939	NS	COUNTER
463946	NS	POTENTIOMETER
46463102	NS	SHIELD
46463394	NS	LAMP ASSY
47-003-0067	NS	SWITCH ROTARY
48-1012R-12P7	NS	CONNECTOR
48-60V5M1	SV	ADI
48-60V5M1	SV	ADI
48-60V5M1	SV	ADU
48-60V5M1	SV	ATTITUDE DIRECTOR IN
482-5068-010	NS	FLAG ASSY.
482-5086-010	NS	METER MOVEMENT
2033833-0001	SV	FREQUENCY TAPE
2504524-1	SV	METER
482-5057-010	NS	GS FLAG
482-5053-010	SV	LOC FLAG
482-5087-010	SV	NAV FLAG
482-5087-010	NS	METER MOVEMENT
482-5088-010	SV	SOLENOID
482-5096-010	NS	METER MOVEMENT
482-5098-010	NS	GLIDESLOPE POINTER
482-5101-030	NS	METER FLAG
482-5102-010	NS	GLIDESLOPE FLAG



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
482-5107-010	SV	METER MOVEMENT
482-5111-010	NS	DATA SOURCE ACTUATOR
482-5114-050	OH	SPEED FLAG
482-5121-010	SV	FLAG ASSY.
482-5142-010	NS	R/T FLAG
482-5144-010	NS	GS FLAG
482-5144-040	NS	GS FLAG
482-5152-010	OH	GYRO FLAG
482-5164-010	SV	METER MOVE
482-5165-010	SV	FLAG ASSY.
482-5170-010	SV	FLAG ASSY,
482-5174-020	SV	SOLENOID FLAG
482-5174-030	SV	SOLENOID FLAG
4864K72P001	NE	LAMP
495013	SV	ASSY
500980-002	NS	WEDGE
50233-4	OH	RUD HYD PRESSURE IND
508-064-001	SV	RESISTOR ASSY
520-3117-303	SV	RADIO MAGNETIC IND
520-3117-303	SV	IND
520-3117-303	SV	IND
520-3117-303	SV	RADIO MAGNETIC IND
520-3117-303	OH	RADIO MAGNETIC IND
520-3117-303	OH	IND
520-3117-303	OH	IND
520-3117-303	OH	RADIO MAGNETIC IND
520010	OH	NAV FLAG
520063	NS	GLIDESLOPE POINTER
520775	SV	ENGINE VIBRATION IND
521142	SV	IND
521142	SV	IND
521142	SV	APU TACHOMETER IND
522-2782-004	OH	COURSE INDICATOR
522-2782-004	SV	COURSE IND
522-2782-004	SV	COURSE INDICATOR
522-3120-004	SV	INSTRUMENT AMPLIFIER
522-3120-004	SV	INSTRUMENT AMPLIFIER
522-3122-000	SV	IND
522-3122-000	SV	IND
522-3122-000	SV	FLIGHT DIRECTOR IND
522-3122-000	SV	FLIGHT DIRECTOR IND
522-3122-012	SV	IND
522-3122-012	SV	IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
522-3122-012	SV	FLIGHT DIRECTOR IND
522-3122-012	SV	FLIGHT DIRECTOR IND
522-3122-013	SV	IND
522-3122-013	SV	IND
522-3122-013	SV	FLIGHT DIRECTOR IND
522-3122-013	SV	FLIGHT DIRECTOR IND
522-3138-007	SV	IND
522-3138-007	SV	IND
522-3138-007	SV	COURSE IND
522-3138-007	SV	COURSE INDICATOR
522-3343-012	SV	IND
522-3343-012	OH	IND
522-3343-012	SV	DISTANCE INDICATOR
522-3343-012	SV	DISTANCE INDICATOR
522-3874-005	SV	AMPLIFIER
522-3874-005	SV	AMPLIFIER
522-3874-005	SV	INSTRUMENT AMPLIFIER
522-3877-001	SV	IND
522-3877-001	SV	IND
522-3877-001	SV	FLIGHT DIRECTOR IND
522-4114-003	SV	RADIO ALTITUDE IND
522-4114-003	SV	IND
522-4430-001	SV	IND
522-4430-001	SV	IND
522-4430-001	SV	FLIGHT DIRECTOR IND
522-4430-002	SV	F. DIR
522-4430-005	SV	FLT DIRECTOR IND
522-4430-005	SV	IND
522-4430-005	SV	IND
522-4430-005	SV	FLIGHT DIRECTOR IND
522-4825-005	SV	RADIO ALTITUDE IND
522-4825-005	SV	RADIO ALTITUDE IND
522-4825-005	SV	RADIO ALTITUDE IND
522-4825-005	SV	IND
522-4825-005	SV	RADIO ALTITUDE IND
522-4825-005	SV	RADIO ALT. IND.
522-4825-005	SV	RADIO ALTITUDE IND
522200	SV	IND
522200	SV	IND
522200	SV	FLOW INDICATOR
532060-001	SV	WEDGE
540-9006-003	NS	POST
541-1232-003	SV	WASHER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
541-3617-002	NS	SPRING
544-3521-002	NS	COLLAR
544-3521-003	NS	COLLAR
544-8953-004	NS	GEAR
546-1828-005	NS	COUNTER COURSE
5472811G006	SV	SVS ASSY.
5478299G002	SV	DIFFUSER
548-4941-004	NS	SCALE PITCH
5484200P001	SV	DIAL
554-8965-003	NS	BRACKEET
554-8985-002	NS	GEAR
5601-01	SV	PALLET
5709K81G701	SV	PLT POST ASSY.
5709K81G701	NS	PLATE
5709K81G702	NS	PLATE
57234-900-1	NS	PACKING
5772	SV	POTENTIOMETER
5785K76G715	NS	POINTER
5910-172	NS	SOLENOID
591976	SV	STATIC AIR TEMP IND
593-1-000	SV	TONE GENERATOR
593-1-000	OH	TONE GENERATOR ASSY
59500000-	SV	DUAL DME INDICATOR
59500000-1	SV	DUAL DME INDICATOR
5987	SV	TUBE
609-3189-002	NS	SCALE SPEED
609-8072-001	SV	CIRCUIT CARD
60B00132-29	SV	N2 TACHOMETER IND
60B00132-29	SV	IND
60B00132-29	SV	N2 TACHOMETER IND
60B00132-29	SV	IND
60B00302-11	SV	IND
60B00302-11	SV	IND
60B00302-11	SV	ENGINE PRES RAT IND
610-129-003	SV	BRACKET
610BL4B	OH	TEMPERATURE IND.
617854-1	SV	TEMP CONT SELECTOR
618379	NS	SERVO AMP
622-4825-005	SV	RADIO ALTITUDE IND
622-5001-104	SV	RADIO DIST MAG IND
622-5001-104	SV	RADIO DIST MAG IND
622-5001-108	OH	RDMI
622-5001-108	SV	RDMI



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-5001-108	SV	RDMI
622-5001-106	OH	RDMI
622-5001-106	SV	RDMI
622-5001-106	SV	RDMI
622-5001-104	OH	RDMI
622-5001-104	SV	RDMI
622-5001-104	SV	RDMI
622-5001-110	OH	RDMI
622-5001-110	SV	RDMI
622-5001-110	SV	RDMI
622-5001-107	OH	RDMI
622-5001-107	SV	RDMI
622-5001-107	SV	RDMI
622-5001-109	SV	RDMI
622-5001-109	SV	RDMI
622-5001-109	SV	RDMI
622-5001-109	SV	RADIO DIST MAG IND
622-5001-109	OH	RADIO DIST MAG IND
622-5001-111	OH	RADIO DIST MAG IND
622-5001-111	SV	RADIO DIST MAG IND
622-5001-111	SV	RADIO DIST MAG IND
622-5001-111	OH	RDMI
622-5001-112	SV	RADIO DIST MAG IND
622-5001-112	SV	RADIO DIST MAG IND
622-5001-112	OH	RADIO DIST MAG IND
622-5001-114	SV	RADIO DIST MAG IND
622-5001-114	SV	RADIO DIST MAG IND
622-5001-114	OH	RADIO DIST MAG IND
RDMI-743	OH	RADIO DIST MAG IND
622-5001-503	SV	RADIO DIST MAG IND
622-5001-503	SV	RADIO DIST MAG IND
622-5001-503	OH	RADIO DIST MAG IND
622-5001-501	SV	RADIO DIST MAG IND
622-5001-501	SV	RADIO DIST MAG IND
622-5001-501	OH	RADIO DIST MAG IND
622-5001-502	SV	RADIO DIST MAG IND
622-5001-502	SV	RDMI
622-5001-504	SV	RADIO DIST MAG IND
622-5001-504	OH	RDMI
622-5001-504	SV	RADIO DIST MAG IND
622-5001-601	SV	EFIS CONTROL PANEL
622-5001-601	SV	EFIS CONTROL PANEL
622-5001-601	OH	RADIO DIST MAG IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-5001-602	SV	EFIS CONTROL PANEL
622-5001-602	SV	EFIS CONTROL PANEL
622-5001-602	OH	RADIO DIST MAG IND
622-5001-701	SV	EFIS CONTROL PANEL
622-5001-701	SV	EFIS CONTROL PANEL
622-5001-701	OH	RADIO DIST MAG IND
622-5048-	SV	EFIS CONTROL PANEL
622-5048-101	SV	EFIS CONTROL PANEL
622-5048-101	SV	EFIS CONTROL PANEL
622-5048-101	SV	EFIS CONTROL PANEL
622-5048-101	SV	EFIS CONTROL PANEL
622-5048-104	SV	EFIS CONTROL PANEL
622-5048-104	OH	EFIS CONTROL PANEL
622-5048-104	SV	EFIS CONTROL PANEL
622-5048-104	SV	EFIS CONTROL PANEL
622-5048-341	SV	EFIS CONTROL PANEL
622-5048-341	SV	EFIS CONTROL PANEL
622-5048-341	SV	EFIS CONTROL PANEL
622-5048-341	SV	EFIS CONTROL PANEL
622-5048-341	SV	EFIS CONTROL PANEL
622-5048-343	SV	EFIS CONTROL PANEL
622-5048-344	SV	EFIS CONTROL PANEL
622-5048-344	SV	EFIS CONTROL PANEL
622-5048-344	SV	EFIS CONTROL PANEL
622-5048-344	SV	EFIS CONTROL PANEL
622-5048-344	SV	EFIS CONTROL PANEL
622-5048-361	SV	EFIS CONTROL PANEL
622-5048-361	SV	EFIS CONTROL PANEL
622-5048-361	SV	EFIC CONTRO PANEL
622-5048-381	SV	EFIS CONTROL PANEL
622-5048-381	SV	EFIS CONTROL PANEL
622-5048-381	SV	EFIS CONTROL PANEL
622-8001-001	SV	EFIS CONTROL PANEL
622-8001-001	SV	EFIS CONTROL PANEL
622-8001-001	SV	EFIS CONTROL PANEL
622-8001-001	SV	EFIS CONTROL PANEL
622-8001-001	SV	EFIS CONTROL PANEL
622-8001-002	SV	EFIS CONTROL PANEL
622-8001-002	SV	EFIS CONTROL PANEL
622-8001-002	SV	EFIS CONTROL PANEL
622-8001-003	SV	EFIS CONTROL PANEL
622-8001-003	SV	EFIS CONTROL PANEL
622-8001-003	SV	EFIS CONTROL PANEL
622-8001-330	SV	EFIS CONTROL PANEL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-8001-330	SV	EFIS CONTROL PANEL
622-8001-330	SV	EFIS CONTROL PANEL
622-8001-330	SV	EFIS CONTROL PANEL
622-8001-331	SV	EFIS CONTROL PANEL
622-8001-331	SV	EFIS CONTROL PANEL
622-8001-331	SV	EFIS CONTROL PANEL
622-8001-331	SV	EFIS CONTROL PANEL
622-8001-332	SV	EFIS CONTROL PANEL
622-8001-332	SV	EFIS CONTROL PANEL
622-8001-332	SV	EFIS CONTROL PANEL
622-8001-350	SV	EFIS CONTROL PANEL
622-8001-350	SV	EFIS CONTROL PANEL
622-8001-350	SV	EFIS CONTROL PANEL
622-8001-350	SV	EFIS CONTROL PANEL
622-8001-351	SV	EFIS CONTROL PANEL
622-8001-351	SV	EFIS CONTROL PANEL
622-8001-351	SV	EFIS CONTROL PANEL
622-8001-352	SV	EFIS CONTROL PANEL
622-8001-352	SV	EFIS CONTROL PANEL
622-8001-352	SV	EFIS CONTROL PANEL
622-8001-352	SV	EFIS CONTROL PANEL
622-8001-352	SV	EFIS CONTROL PANEL
622-8001-370	SV	EFIS CONTROL PANEL
622-8001-370	SV	EFIS CONTROL PANEL
622-8001-370	SV	EFIS CONTROL PANEL
6227	SV	POTENTIOMETER
629-8391-001	SV	POWER SUPPLY
629-8391-001	NS	POWER SUPPLY
630-1001-007	NS	CAP ASSY
630-1001-012	NS	CAP ASSY
630-1001-003	NS	CAP ASSY
630-1001-004	NS	CAP ASSY
630-1001-005	NS	CAP ASSY
630-1001-006	NS	CAP ASSY
630-1001-002	NS	CAP ASSY
63657B	NS	CAP
638-2819-001	SV	CIRCUIT CARD ASSY
642-4586-003	NS	CIRCUIT CARD
646-5157-001	NS	WASHER, FALT
646-5209-001	NS	MASK
646-5209-003	NS	MASK
6465K53P001	NS	SCALEPLATE
6465K60P001	SV	DIAL
6466K19P001	SV	SCALE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
6466K33P001	SV	DIAL
6466K57P001	SV	SCALE
65-37328-5	SV	MAP LIGHT
65-37328-5	SV	MAP LIGHT
65-52803-8	SV	WNDW HEAT ACCS U ASY
65-52803-8	SV	WINDOW HEAT ACC UNIT
65-52819-TS	NS	STALL WAR TEST SET
65-52822-3	SV	STALL MANAGEMENT
65-52822-3	SV	MODULE ASSY
65-52822-3	SV	STALL MANAGEMENT
65-52822-7	SV	MODULE ASSY
65-52822-7A	SV	MODULE ASSY
651-2197-001	NS	PLATE, SWITCH-MODE
651-2254-001	NS	BUSHING, CLUCK
651-2256-002	NS	CLUTCH
651-2276-001	NS	IC PROM
659-8319-001	NS	MOUNTING PLATE
659-8321-001	NS	PANEL ASSY, FRONT
659-8326-001	NS	SPACER
65B47598-7	NS	GUST RESPONSE COMP
6650K43P001	NS	PLATE
665362	SV	TRANSFORMER
674-1031-2015	NS	CAP ASSY
674-1031-2097	NS	CAP ASSY
685835	NS	RELAY
69-37319-39	SV	MODULE
69-37319-39	SV	MODULE ASSY,AIR COND
69-37328-5	SV	MAP LIGHT MOD ASSY
69-37328-5	SV	MAP LIGHT MOD ASSY
69-37328-5	SV	MAP LIGHT MOD ASSY
69-37328-5	SV	MAP LIGHT MOD ASSY
69-60730-1	SV	PC BOARD
69-60730-1	NS	PC ASSY, MASTER
69-75986-4	NS	PROGRAM MEMORY
692757-1	NS	CTR RADAR
7000041-46	SV	CAPACITOR
700662A	SV	LOAD CONTROLLER
70509-0001	SV	I.C.
70653-0001	SV	IC
710-914	SV	TOTALIZER INDICATOR
710-914	SV	TOTALIZER INDICATOR
710-914	SV	TOTALIZER INDICATOR
712B922B	SV	DRUM



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
7153AS15TPL	NE	LAMP
721985	SV	SOCKET
724124-1	SV	TRANSFORMER
730432-13	SV	CLIP CAP
735560-4	SV	RELAY
736913	SV	RING ASSY
739852-1	SV	STATOR
754-0301-001	SV	LIGHT PLATE
754-0301-003	NS	LIGHTPLATE
754-0301-003	NS	LIGHTPLATE
754-0301-005	NS	LIGHTPLATE
754-0301-005	SV	LIGHT PLATE
754-0529-001	SV	LIGHTPLATE
756-9833-001	SV	SPACER
757-0872-003	SV	PLUG
757-3332-001	NS	GEAR ASSY
757-3354-002	NS	KNOB
761-3220-001	NS	CASE INSTRUMENT
761-3225-003	NS	MASK
761-3231-001	NS	GEAR
761-3232-001	NS	GEAR
761-3233-001	NS	GEARSHAFT
761-3237-002	NS	GEARSHAFT
761-3238-001	NS	GEAR
761-3242-001	NS	GEAR, SPUR
761-3244-002	NS	BLOCK
761-3250-001	NS	SPACER
761-3250-003	NS	SPACER
761-3250-004	NS	SPACER
761-3251-001	NS	GUIDE TAPE
761-3253-001	NS	GEAR SHAFT
761-3254-001	NS	GEAR SHAFT
761-3257-002	NS	SHAFT
761-3260-001	NS	GEAR CLUSTER
761-3260-002	NS	GEAR CLUSTER
761-3260-004	NS	GEAR CLUSTER
761-3265-001	NS	SPACER
761-3267-001	NS	BRACKET, SWITCH
761-3271-001	NS	SPRING
761-3272-001	NS	POST
761-3273-001	NS	STOP ASSEMBLY
761-3282-001	NS	KNOB
761-3286-001	NS	MASK



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
761-3286-002	NS	MASK
761-3292-001	NS	PLATE RETAINING
761-3294-001	NS	PLATE RETAINING
761-3295-001	NS	PLATE
761-3296-001	NS	PLATE
761-3298-001	NS	BRACKET
761-3304-003	NS	TAPE,RUNWAY
761-3305-002	NS	COVER
761-3307-001	NS	STOP
761-3311-001	NS	GEAR SPAR
761-3314-001	NS	SPRING
761-3316-001	NS	GEAR
761-7786-004	NS	ELEC COMPONENT ASSY
761-7789-001	NS	PLATE MTG
761-7798-001	NS	GEAR SHAFT
761-7801-001	NS	PLATE MTG
761-7807-003	NS	TAPE DRUM ASSEMBLY
761-7810-001	NS	PLATE RETAINING
761-7812-001	NS	LIGHT ASSEMBLY
761-7813-001	NS	LIGHT ASSEMBLY
761-8797-001	NS	BAR
761-8797-002	NS	CAMMAD BAR
763-6036-001	NS	PC BOARD, LIGHT
763-6096-001	NS	DIAL
767-8210-001	NS	STOP, RIGID
767-8215-002	NS	GEAR SPUR
767-8217-001	NS	MASK
768-7453-001	NS	TAPE
775-5320-001	SV	SPRING
768-9077-001	NS	COMMAD BAR
775-5362-002	NS	SPACER
775-5391-001	NS	BOARD
775-5391-001	NS	MASK
775-5572-001	SV	HEADING KNOB
775-5572-002	SV	KNOB
775-5573-002	SV	KNOB, COURSE
775-5345-001	NS	ROLLER ASSY
522-4825-004	SV	RADIO ALT IND
522-4825-004	OH	RADIO ALT IND
772-5005-001	OH	FLIGHT DIRECTOR IND
772-5005-005	OH	FLIGHT DIRECTOR IND
772-5005-009	OH	FLIGHT DIRECTOR IND
772-0628-001	SV	METER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
775-5034-001	NS	GEAR
775-5038-001	SV	COLLAR
775-5074-001	NS	PIN
775-5140-001	NS	COUNTER, ROTATING
775-5191-001	SV	GEAR SHAFT
775-5314-001	SV	CLAMP
775-5082-001	SV	SPRING
775-5040-001	SV	SPACER
775-5040-001	NS	SPACER
775-5082-001	SV	SPRING DETENT
775-5090-001	NS	PRIMS, LIGHT
775-5108-001	SV	RING
775-5119-001	SV	WEAR SHAFT
775-5120-001	SV	GEAR SHAFT
775-5122-002	SV	GEAR SHAFT
775-5135-001	NS	CASE ASSY
775-5138-001	SV	SPIDER
775-5138-001	NS	SPRIDER DIFFERENTIAL
775-5138-002	NS	SPRIDER, DIFFERENTIAL
775-5250-001	NS	DH TAPE
775-5318-001	SV	GEAR
775-5333-001	SV	CLUSTER GEAR
777-1083-001	SV	H.S.I.
777-3043-002	NS	COLLAR
778-0386-001	NS	FRICION CLUTCH
778-0387-002	NS	SHAFT ASSY
778-1307-001	NS	SCALE, GS
778-1340-002	NS	GEAR, SPUR
778-1351-001	NS	GEAR, SPUR
778-1417-001	NS	GEAR ASSY
778-1439-001	NS	SECTOR ASSY, RH
778-1448-001	NS	INCLINOMETER
779-3122-001	SV	GEAR
779-3423-001	NS	GEAR SHAFT
779-3452-001	NS	PLATE SWITCH
779-3483-001	NS	KNOB, COURSE
779-3492-001	NS	KNOB HEADING
779-3531-001	NS	COLLAR, BRAKE
779-3580-001	NS	BRAKE, GEAR
779-3581-001	NS	BRAKE, GEAR
779-3799-001	SV	DIAL
7834K73P010	NS	SPACER
7834K73P10	SV	SPACER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
787-6045-001	SV	SURF. POS. IND
787-6766-001	SV	ATT.DIR. IND
791-2369-001	SV	TAPE
791-2369-002	SV	TAPE INDICATOR
791-2433-001	SV	COLLAR HUB
791-2434-001	NS	GEAR
791-2435-001	NS	GEAR SHAFT
791-2436-002	SV	GEAR SPUR
791-2439-001	NS	GEARSHAFT
791-2445-001	NS	GEAR
791-2449-001	NS	GEAR
791-2454-001	NS	DIAL
791-2485-001	NS	PLATE
792-0595-001	NS	GEAR ASSY
799046	NS	CURSOR CTR
806677	SV	STATOR
814187	NS	TRANSFORMER
818651	SV	GEAR TRAIN
836-7035-005	SV	LIGHT PLATE
841-011-001	NS	VOLTAGE REGULATOR
841-011-002	SV	TRANSFORMER
841-025-001	SV	TRANSFORMER
865D909	SV	DIAPHRAM
871231	SV	PINION
875884	SV	SPRING
88000-4102	SV	CLOCK
88000-4103	SV	CLOCK
88000-4103	SV	CLOCK
88000-4104	SV	CLOCK
88000-4104	SV	CLOCK
881637	SV	SIDE COVER ACCESS.
8900801G002	NS	XDUCER PRESS
8905884G130	OH	CAN ASSY
8905884G155	SV	CAN ASSEMBLY
8905884G155	NS	CASE ASSY
8DJ125LWT3	SV	F.F INDICATOR
8DJ125LWX3	SV	FLOWMETER INDICATOR
8DJ125LXD5	SV	F.F IND
8DJ125LXG4	SV	FLOWMETER INDICATOR
8DJ125LXG4U	OH	FLOWMETER IND
8DJ125LXG5	SV	F/FLOW USED/RATE IND
8DJ125LXH2	SV	FUEL FOLOW IND.
8DJ125LXW5	SV	F.F IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
8DJ125LXX5	SV	FUEL/FLOW RATE USED
8DJ125LXX5	SV	F/FLOW RATE/USED IND
8DJ125LYT4	SV	FLOWMETER IND
8DJ162LXH2	OH	N2 TACHOMETER IND
8DJ162LXL2	SV	N1 TACHOMETER IND
8DJ162LXL2	SV	TACHOMETER INDICATOR
8DJ162LZL2	SV	N2 TACHOMETER IND
8DJ162LZL2	SV	N2 TACHOMETER IND
8DJ171LWA3	OH	FUEL FLOW IND
8DJ172LWA1	SV	OIL QTY IUND
8DJ172LWA1	SV	INDICATOR
8DJ172LWA1	SV	INDICTOR
8DJ173LWD1	SV	OIL QTY IND
8DJ173LWD1	OH	OIL QUANTITY IND.
8DJ173LWD1	SV	OIL QUANTITY IND.
8DJ173LWD1	OH	OIL QTY IND
8DJ175LWT2	SV	EGT INDICATOR
8DJ175LWT2	SV	EGT INDICATOR
8DJ176LXW1	SV	ENGINE SPEED IND
8DJ176LXW1	OH	ENGINE SPEED IND.
8DJ176LXW1	SV	ENGINE SPEED IND.
8DJ176LZD2	SV	ENGINE FAN SPEED IND
8DJ176LZD2	SV	ENGINE FAN SPEED IND
8DJ176LZF2	SV	ENG CORE SPEED IND
8DJ176WAP2	SV	INDICATOR
8DJ176WAP2	SV	INDICATOR
8DJ177LWN1	SV	TEMPERATURE IND
8DJ177LWN1	OH	TEMPERATURE IND.
8DJ177LWN1	SV	TEMPERATURE IND.
8DJ177LWR1	SV	TEMPERATURE IND
8DJ177LWR1	OH	TEMPERATURE IND.
8DJ177LWR1	SV	TEMPERATURE IND.
8DJ185LWP1	SV	TURBINE GAS TEMP IND
8DJ186LWW1	OH	ENGINE SPEED IND.
8DJ81CBD4	OH	INDICATOR
8DJ811LXF2	SV	TACHOMETER IND
8DJ81LWT4	SV	TACHOMETER INDICATOR
8DJ81LWT4	SV	TACHOMETER INDICATOR
8DJ81LWT4	SV	TACHOMETER INDICATOR
8DJ81LWT4-U	SV	TACHOMETER INDICATOR
8DJ81LXH2	SV	TECHOMETER IND
8DJ81LXH2	SV	TACHOMETER IND
8DJ81LXP2	SV	TACHOMETER IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
8DJ81LXP2	SV	TACHOMETER IND
8DJ86LAH1	SV	FUEL FLOW INDICATOR
8KE25GAC1	SV	FUEL FLOW AMPLIFIER
8KE25GAC1	SV	FUEL FLOW AMP.
8TJ81LWT4-U	SV	TACHOMETER INDICATOR
8TJ88GAN3	SV	FUEL FLOW PWR SUPPLY
8TJ88GAN3	SV	FUEL FLOW PWR SUPPLY
8TJ88GAN3	SV	FUEL FLOW PWR SUPPLY
8TJ88GAN3	SV	FUEL FLOW PWR SUPPLY
8TJ88GBN4	SV	FUEL FLOW POWER SUP.
9-102	SV	FUEL USED INDICATOR
9-102	SV	FUEL USED INDICATOR
9-102	SV	FUEL USED INDICATOR
9-113-09	OH	F/F ELECT PACK
9-113023-03	OH	CRYSTAL
9005-21	OH	MOLDED HOUSING
915F212-6	SV	GENERATOR CNTRL UNIT
950563-1	OH	PRISM
9560831-1	OH	ANTI SKID TEST SET
9561006-3R	SV	SKID CONTROL UNIT
9599-607-12118	SV	HEIGHT INDICATOR
9599-607-12118	SV	HEIGHT INDICATOR
9599-607-12118	SV	HEIGHT INDICATOR
974-1065-010	SV	RELAY
974-1065-180	SV	RELAY, AMT
974-1082-020	SV	RELAY ARM
9783055P001	SV	SHAFT GEAR
9819-29	OH	CONT SURF POSIT IND
9819-90-01	SV	FLAP POSITION IND
9819-90-01	SV	FLAP POSITION IND
9819-93-05	SV	FLAP POSITION IND
9819-93-05	SV	FLAP POSITION IND
9850354G017	SV	GEAR & PINION ASSY
9850354G020	NS	GEAR
9886059G001	SV	ROTOR
9886950G003	SV	STATOR ASSY
989993-1	NS	DIAL
989994-1	NS	DIAL
989995-1	NS	DIAL
989997-1	NS	DIAL
A-12	NE	EPOXY-ADHESIVE
A16744	NS	TRANSFORMER
A2005841	NS	TORQUE POT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
A2005841	NS	TORQUE POT
A30357-10-006	NS	DIFF.PRESS IND
A32437-10-021	SV	TACOMETER IND.
AM2716/BJA	NS	IC
B0650-71107-1	SV	ALTITUDE ALERT CONT
B0650-71110-1	SV	ALTITUDE ALTER CONTR
B0650-71110-1	SV	ALTITUDE ALERT CONT
B0652-71110-1	SV	ALTITUDE ALERT CONT
B0652-71108-1	SV	ALTITUDE ALERT CONT
B0652-71110-1	OH	ALTITUDE ALERT CONT
B0652-71108-1	OH	ALTITUDE ALERT CONT
B1077-3	SV	OIL QUANTITY IND
B1077-3	SV	OIL QUANTITY IND.
B1123-3464	OH	TANK UNIT
B118-244	SV	FUEL QTY IND
B118-244	SV	FUEL QTY IND
B118-244	SV	FUEL QTY IND
B118-313W	SV	FUEL QTY IND
B118-313W	SV	FUEL QTY IND.
B175-22W	SV	FUEL QUANTITY IND
B175-22W	SV	FUEL QTY IND
B175-28W	SV	FUEL QTY IND
B175-28W	SV	FUEL QTY TOTALIZ IND
B1800-81103	SV	ALTITUDE IND
B1800-81103	SV	ALTITUDE IND
B1800-81103	SV	ALTITUDE IND
B294C-3	SV	OIL QUANTITY IND
B294C-3W	SV	OIL QTY IND
B294C-3W	SV	OIL QTY. IND
B36337-10-001	OH	TRUE AISPEED IND
B37523-19	NS	GEAR
B37524-22	NS	GEAR
B4B-22	SV	CAPACITOR
B711-1	SV	HYD. OIL QTY.IND
B711-1	SV	HYD OIL QTY IND
B852-12	OH	FUEL QUANTITY IND
BAC27DEX5461	SV	MARKER
BACS21DX1B	SV	STUD
BH4654AY	SV	STOP, TOP
BRAYCO 589	NE	LUBRICANT
BRAYCO 589	NE	CORROSIVE PRESERVATI
C29187-10-005	SV	PRESSURE RATIO IND
C29187-10-005	OH	PRESSURE RATIO IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
C29187-10-021	SV	PRESSURE RATION IND
C29187-10-021	SV	PRESSURE RATIO IND.
C556002104-6	OH	DRAG CUP
CDSH-5-A-4/L558	OH	DIFFERENTIAL RESOLVE
CM-7714	NS	LAMP
CM41005018	NS	SYNCHRO TRANSOLVER
CRC-10-PS-1/A434	NS	SYNCHRO RECEIVER
CT-10-JS-4/A004	NS	CONTROL TRANSFORMER
D434-36-001	SV	FLT MODE ANNUNCIATOR
D434-36-001	SV	FLT MODE ANNUNCIATOR
D434-36-001	SV	FLT MODE ANNUNCIATOR
DSF508-4	SV	OIL QUANTITY IND
DSF508-4	SV	OIL QTY IND
DSF508-4	SV	OIL QUANTITY IND
EDSH8XH2L705	OH	DIFFERENTIAL RESOLVE
ERH-10-DUS-04/B924	NS	SYNCHRO RECEIVER
ERH-8-XZ-07/F555	NS	SYNCHRO
ERH10DUS03B595	NS	SYNCHRO RECEIVER
ERH10DUS04F554	NS	SYNCHRO RECEIVER
ERH8XZ03L736	NS	SYNCHRO
ERH8XZ07L896A	NS	SYNCHRO
ERH8XZ07L930A	NS	SYNCHRO
F310-0091	NS	CAPACITOR
GG-18-A1	SV	SYNCHRO ASSY
GG-18-A2	SV	SYNCHRO ASSY
HA1-4741-2	SV	IC
HA2-2640-2	SV	I.C.
835-0313-020	SV	I.C.
HSI-3182-8	SV	IC
INCLINOMETER	NS	FOR ALL ADI / FDI
INCLINOMETER	NS	WE MFG FOR SIMULATOR
INCLINOMETER	NS	SKIDBALL
JANTX2N4859	SV	TRANSISTOR
JG1052AC03	SV	ALTITUDE ALERT IND
JG1052AC03	SV	ALTITUDE ALERT IND
JG1052AC03	SV	ALTITUDE ALERT IND
JG1208AA02	SV	LOAD SELECT IND
JG298A5	SV	PRESSURE RATION IND
JG298A5	SV	PRESSURE RATION IND
JG298A5	SV	PRESSURE RATIO IND
JG298A5	SV	PRESSURE RATIO IND
JG298H4	SV	E.P.R. IND
JG603C2	SV	FUEL QTY IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
JG603C2	SV	FUEL QTY.IND.
JG603C3	SV	FUEL QTY IND
JG603C3	OH	FUEL QTY. IND.
JG603C3	OH	FUEL QTY IND
JG603C4	SV	FUEL QUANTITY IND
JG603C4	SV	FUEL QTY IND
JG603C44	SV	FUEL QUANTITY IND
JG603C44	SV	FUEL QUANTITY IND
JG603C44	SV	FUEL QUANTITY IND
JG613C45	SV	TOTAL FUEL QTY IND
JG908A17	OH	RAT/EPR IND
JG908A17	SV	RAT/EPR IND
JG908A18	SV	RAT/EPR INDICATOR
JG908A18	SV	TEMP/E.P.R. IND.
JG908A58	SV	RAT/EPR INDICATOR
JG908A58	OH	E.P.R. IND
JG908A1	SV	RAT/EPR INDICATOR
JG908A1	OH	E.P.R. IND
JG908A3	SV	RAT/EPR INDICATOR
JG908A3	OH	E.P.R. IND
JG908A19	SV	RAT/EPR INDICATOR
JG908A19	SV	E.P.R. IND
JG908A21	SV	RAT/EPR INDICATOR
JG908A21	SV	E.P.R. IND
JG908A25	SV	RAT/EPR INDICATOR
JG908A25	SV	E.P.R. IND
LIBB-E32	SV	POSITION INDICATOR
LIBBE32	SV	POSITION INDICATOR
M9071-76	OH	GLIDESLOPE FLAG
M9071-97	OH	GLIDESLOPE FLAG
M907146	OH	RUNWAY FLAG
M9073-25	OH	GLIDESLOPE POINTER
M907325	OH	GLIDESLOPE POINTER
MAP-LIGHT-MOD-ASSY	SV	18 MO WARRANTY
MML-034	OH	METER MOVEMENT
MOLYKOTE-TYPE-GN	SV	METAL ASSY PASTE
MS16632-1025	NS	RING, RETAINING
OL-7153AS15TPL	NS	LAMP
OL6839BPE	NS	LAMP
P1C6050	NS	SEMICONDUCTOR DEVICE
PIC6050	NS	SEMICONDUCTOR DEVICE
PZ97V11PBG18P	NS	BEARING
R1062-12	NS	IC



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
RD240-117	NS	KNOB
RI062-12	NS	IC
RJR26FX202P	NS	VARIABLE RESISTOR
RN60C2001F	NS	RESISTOR
RN60C5620F	SV	RESISTOR
RSHX-110	SV	RELAY
RT12C2Y202	NS	POTENTIOMETER
S-1412	NS	DIAL
S-1816	NS	SCALE PLATE
S2223A	NS	DIAL
S3805A	NS	DIAL
S3805E	NS	DIAL
S5305B	NS	DIAL
SA9-19010	NS	RESISTOR
SA9-1910	NS	RESISTOR
SA9-9090	NS	RESISTRO
SEL-OC3B	SV	FUEL PRESSURE IND
SEL-OC3B	SV	FUEL PRESSURE IND.
SKID BALL	SV	FOR ALL ADI / FDI
SKIDBALL	SV	INCLINOMETER
SKIDBALL-SIMULATED	SV	INCLINOMETER, SIMU
SLIPBALL	SV	INCLINOMETER
SLIPBALL	SV	FOR ALL ADI / FDI
SLIPBALL	SV	INCLINOMETER
SN19400	NS	IC
SN24772J	NS	IC
SP327	SV	SURFACE POSIT TESTER
SR-O7B	SV	HYD ORESSURE IND
SR-O7B	SV	HYD PRESSURE IND
SR2-5SSX2K4011	NS	BEARING
ST8111	NS	MOTOR TACH GENERATOR
T3002409	SV	ANVIL ALIGNING TOOL
T429695	SV	SPANNER WRENCH
TDSH11HR1	NS	TRANSOLVER
TMS9980AJDL	SV	IC
X28VC256SI55	SV	IC
70-1898	SV	IC
Z850X60C01	SV	BEARING
Z850X6C01	SV	BEARING
149155-01-02	SV	INDICATOR
2592920-444	SV	INDICATOR
2592920-444	OH	INDICATOR
SRDL-OC7E	SV	INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
777-1825-001	SV	INDICATOR
7000466-906	SV	INDICATOR
63600-456-2	SV	INDICATOR
63600-271-1	SV	INDICAOR
61531-005-1	SV	INDICATOR
622-4938-027	SV	RADIO MAGNETIC INDICATOR
OPA544T	NS	IC
63600-271-1	SV	INDICATOR - EGT
393026-092	SV	INDICATOR
393026-092	OH	INDICATOR
393026-095	SV	PRECAL FUEL QTY IND
393026-095	OH	PRECAL FUEL QTY IND
622-4563-008	SV	INDICATOR
2083-10-1	SV	INDICATOR
2610-07-1	SV	INDICATOR
522-4114-008	SV	INDICATOR
1784460-655	SV	INDICATOR
622-4563-004	SV	INDICATOR
115099-6	SV	INDICATOR
115099-8	SV	INDICATOR
2047-01-1	SV	EPR INDICATOR
2048-01-1	SV	EPR INDICATOR
2050-01-1	SV	SERVOED ALTITUDE IND
2054-01-1	SV	ALTITUDE IND
2055-01-1	SV	SERVOED ALTITUDE IND
2057-01-1	SV	ALTITUDE IND
2057-02-1	SV	ALTITUDE IND
2061-11-1	SV	FLAP POSITION INDICA
2083-11-1	OH	MACH AIRSPEED IND
2083-11-1	SV	MACH AIRSPEED IND
2091-11-1	SV	EGT INDICATOR
113515	SV	HORIZONTAL SITUATION
114.029	SV	POSITION INDICATOR
114.035	SV	POSITION INDICATOR
114.062	SV	DC AMMETER
114.114	SV	IND
114.114-1	SV	IND
114.115	SV	IND
114.115-1	SV	IND
114.129	SV	POSITION INDICATOR
114.129-1	SV	POSITION INDICATOR
115.099-5	SV	HYDRAULIC PRESS IND
115.099-6	SV	BRAKE PRESSURE IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
115-099-6	OH	BRAKE PRESSURE IND
115.099-6	SV	BRAKE PRESSURE IND
115.099-5	OH	HYDRAULIC PRESS IND
115.099-7	SV	BRAKE PRESSURE IND
115.099-8	SV	BRAKE PRESSURE IND
115.099-9	SV	BRAKE PRESSURE IND
115.159	SV	TEMP INDICATOR
115.159-1	SV	TEMP INDICATOR
115.163	SV	TEMP INDICATOR
115.163-1	SV	TEMP INDICATOR
2061-12-1	SV	FLAP POSITION INDICA
10-61926-2	SV	FLAP POSITION INDICA
2061-12-1	OH	FLAP POSITION INDICA
10-61926-2	OH	FLAP POSITION INDICA
130502-5	SV	CABIN PRESS SLCTR
130502-6	SV	CABIN PRESS SLCTR
130590-1	SV	CABIN AIR PRESSURE
149150-01-01	SV	ADI
149150-01-02	SV	ADI
149155-01-01	SV	ADI
149155-01-02	SV	ADI
149270-01-01	SV	TAT / EPR LIMIT IND
149270-03-01	SV	TAT / EPR LIMIT IND
149270-04-01	SV	TAT / EPR LIMIT IND
149270-05-01	SV	TAT / EPR LIMIT IND
162BL501	SV	TAT INDICATOR
162BL502	SV	RAM AIR TEMP INDICAT
162BL503	SV	TEMP INDICATOR
162BL504	SV	DUCT TEMP IND
162BL505	SV	TEMP INDICATOR
162BL602	SV	OIL TEMP INDICATOR
162BL701	SV	FUEL TEMP INDICATOR
162BL701A	SV	TEMP INDICATOR
162BL702	SV	OIL TEMP INDICATOR
162BL703	SV	OIL TEMP INDICATOR
162BL704	SV	OIL TEMP INDICATOR
162BL704A	SV	OIL TEMP INDICATOR
162BL704C	SV	OIL TEMP INDICATOR
162BL704D	SV	OIL TEMP INDICATOR
162BL704F	SV	OIL TEMP INDICATOR
162BL704H	SV	OIL TEMP INDICATOR
162BL704K	SV	AUX HYD TEMP IND
162BL704L	SV	HYD TEMP INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
162BL704N	SV	OIL TEMP INDICATOR
162BL708	SV	CABIN TEMP INDICATOR
162BL709	SV	OIL TEMP INDICATOR
162BL709A	SV	OIL TEMP INDICATOR
162BL709B	SV	OIL TEMP INDICATOR
162BL710	SV	RAM AIR TEMP INDICAT
162BL711	SV	CABIN TEMP INDICATOR
162BL801	SV	FUEL TEMP INDICATOR
162BL802	SV	OIL TEMP INDICATOR
162BL802A	SV	OIL TEMP INDICATOR
162BL803	SV	OIL TEMP INDICATOR
162BL803A	SV	OIL TEMP INDICATOR
162BL804A	SV	OIL TEMP INDICATOR
162BL901	SV	TAT INDICATOR
162BL902	SV	TEMP INDICATOR
162BL903	SV	TEMP INDICATOR
162BL907	SV	TAT INDICATOR
1776001-154	SV	INDICATOR
1776001-354	SV	INDICATOR
176365-201	SV	HORIZON FLIGHT DIREC
176365-202	SV	HORIZON FLIGHT DIREC
176365-205	SV	HORIZON FLIGHT DIREC
176365-207	SV	HORIZON FLIGHT DIREC
176365-208	SV	HORIZON FLIGHT DIREC
622-5002-207	SV	RADIO MAGNETIC INDICATOR
622-5002-207	OH	RADIO MAGNETIC INDICATOR
622-5002-207	SV	RADIO MAGNETIC INDICATOR
622-5002-203	SV	RADIO MAGNETIC INDICATOR
622-5002-203	OH	RADIO MAGNETIC INDICATOR
622-5002-205	OH	RADIO MAGNETIC INDICATOR
622-5002-205	SV	RADIO MAGNETIC INDICATOR
622-4563-008	SV	INDICATOR
522-4529-004	SV	INDICATOR
JG1052BC01	SV	INDICATOR
SRDL-6D	SV	INDICATOR
482-5084-010	OH	METER MOVEMENT
229-2022-010	OH	SYNCHRO
772-5370-002	OH	INDICATOR
152BCL4B	OH	EGT INDICATOR
152BCL4	OH	INDICATOR
152BCL4D	OH	EGT INDICATOR
152BCL4D	SV	EGT INDICATOR
152BCL4B	SV	EGT INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
152BCL4	SV	INDICATOR
152BCL4F	SV	EGT INDICATOR
152BCL4F	OH	EGT INDICATOR
152BCL4G2	SV	EGT INDICATOR
152BCL4G2	OH	EGT INDICATOR
152BCL4J	SV	EGT INDICATOR
152BCL4J	OH	EGT INDICATOR
152BCL4P	SV	EGT INDICATOR
152BCL4P	OH	EGT INDICATOR
152BCL4S	SV	EGT INDICATOR
152BCL4S	OH	EGT INDICATOR
152BCL4W	SV	EGT INDICATOR
152BCL4W	OH	EGT INDICATOR
152BL702	SV	EGT INDICATOR
152BL702A	OH	EGT INDICATOR
152BL702D	SV	EGT INDICATOR
152BL702E	OH	EGT INDICATOR
152BCL4W	SV	EGT INDICATOR
152BCL4W	OH	EGT INDICATOR
152BL702	SV	EGT INDICATOR
152BL702A	SV	EGT INDICATOR
152BL702D	OH	EGT INDICATOR
152BL702E	SV	EGT INDICATOR
152BL705	OH	EGT INDICATOR
152BL705	SV	EGT INDICATOR
152BL705A	OH	EGT INDICATOR
152BL705A	SV	EGT INDICATOR
152BL705E	OH	EGT INDICATOR
152BL705E	SV	EGT INDICATOR
152BL705F	OH	EGT INDICATOR
152BL705F	SV	EGT INDICATOR
152BL705G	OH	EGT INDICATOR
152BL705G	SV	EGT INDICATOR
152BL705H	OH	EGT INDICATOR
152BL705H	SV	EGT INDICATOR
152BL705J	OH	EGT INDICATOR
152BL705J	SV	EGT INDICATOR
152BL705L	OH	EGT INDICATOR
152BL705L	SV	EGT INDICATOR
152BL705N	OH	EGT INDICATOR
152BL705N	SV	EGT INDICATOR
152BL705P	OH	EGT INDICATOR
152BL705P	SV	EGT INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
152BL705R	OH	EGT INDICATOR
152BL705R	OH	EGT INDICATOR
152BL705S	SV	EGT INDICATOR
152BL705S	OH	EGT INDICATOR
152BL706	OH	EGT INDICATOR
152BL708	SV	EGT INDICATOR
152BL708A	OH	EGT INDICATOR
152BL708H	OH	EGT INDICATOR
152BL709	SV	EGT INDICATOR
152BL801	OH	EGT INDICATOR
152BL801	SV	EGT INDICATOR
152BL801A	OH	EGT INDICATOR
152BL801A	SV	EGT INDICATOR
152BL801C	OH	EGT INDICATOR
152BL801C	SV	EGT INDICATOR
152BL801D	OH	EGT INDICATOR
152BL801D	SV	EGT INDICATOR
152BL801E	OH	EGT INDICATOR
152BL801E	SV	EGT INDICATOR
792-6357-001	SV	EGT INDICATOR
792-6357-001	OH	EGT INDICATOR
792-6357-002	SV	EGT INDICATOR
792-6357-002	OH	EGT INDICATOR
792-6357-007	SV	EGT INDICATOR
792-6357-007	OH	EGT INDICATOR
792-6357-008	SV	EGT INDICATOR
792-6357-008	OH	EGT INDICATOR
792-6357-011	SV	EGT INDICATOR
792-6357-011	OH	EGT INDICATOR
622-3672-001	SV	EGT INDICATOR
61531-005-1	OH	INDICATOR
61531-005-1	SV	INDICATOR
JG105BC01	SV	INDICATOR
622-4938-027	OH	INDICATOR
622-4938-027	SV	INDICATOR
2594624-906	OH	INDICATOR
2594624-906	SV	INDICATOR
393026-092	OH	INDICATOR
393026-092	SV	INDICATOR
4016341-906	OH	INDICATOR
4016341-906	SV	INDICATOR
520-3137-304	OH	INDICATOR
520-3137-304	SV	INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
3137LB63C	OH	INDICATOR
3137LB63C	SV	INDICATOR
4016341-903	OH	BAROMETRIC ALT IND
4016341-903	SV	BAROMETRIC ALT IND
4016341-905	OH	BAROMETRIC ALT IND
4016341-905	SV	BAROMETRIC ALT IND
522-2638-001	SV	INDICATOR
522-2638-001	OH	INDICATOR
11046-MD	SV	VIBRATOR MOTOR
11195	SV	REPLACEMENT HANDLE
11195-TL	SV	REPLACEMENT HANDLE
11319-3	SV	SWITCH
11661	SV	INSERT
118960-003	SV	IC
118961-002	SV	IC
118H	SV	POTENTIOMETER
119954-01	SV	TUBE FILTER
11A619	SV	END BELL ASSY
121275	SV	VARIABLE TRANSFORMER
1215813-1	SV	RESISTOR
12195-PS	SV	POWER SUPPLY
12227TR	SV	TRANSFORMER
1231438-1	SV	TRANSFORMER
1239751-1	SV	TRANSFORMER
12494-CH	SV	CHOKE
1249746-2	SV	TERMINAL
1255097-1	SV	COVER
1255106-1	SV	PIVOT
12677481	SV	LATCH
1256695-1	SV	SWITCH
1267748-1	SV	LATCH
1271567-1	SV	SHAFT
1274425-7	SV	POINTER
1274898-1	SV	GEAR
1275323-1	SV	GLASS
1276492	SV	JEWEL SCREW
1278401-1	SV	ROTOR
127978	SV	JEWEL
12810MD	SV	GEARHEAD MOTOR MAXON
1282167-1	SV	TRANSFORMER
1282372-1	SV	POTENTIOMETER
1287-223B	SV	SPRING, LEAF
1287419-1	SV	DECAL
1293028-1	SV	ROTOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1293542-1	SV	SLIP RING ASSY
1293564-1	SV	BRACKET
1293607-1	SV	TRANSFORMER
1293641-1	SV	BRUSH BLOCK ASSY
1293642-1	SV	BRUSH BLOCK ASSY
1294780-1	SV	ID PLATE
129522-2	SV	SHAFT
12B4A	SV	VACUUM TUBE
12BH121A-GR	SV	BATTERY HOLDER
12HPS-10	SV	POTENTIOMETER
12SL2GT	SV	VACUUM TUBE
12SK7	SV	VACUUM TUBE
12SL7GT	SV	VACUUM TUBE
JAN-CG-12SL7GT	SV	VACUUM TUBE
12SM4	SV	MICRO SWITCH
12SN7GTA	SV	VACUUM TUBE
12SX1-T	SV	SWITCH
12SX2-T	SV	MICRO SWITCH
1282167-1	SV	TRANSFORMER
1302827-1	SV	TRANSFORMER
6615-723-1766	SV	SEALING STRIP
1307094-1	SV	TRANSFORMER
1307876-1	SV	MICROSWITCH
1309425-1	SV	BOOT
131-3000	SV	CROCODILE CLIP
131297-01	SV	SEALING STRIP
140-0-0-502	SV	POTENTIOMETER
1400K72P001	SV	BEARING PLATE
14033-MG	SV	SMALL BAR MAGNET
149-115	SV	TUBE FILTER
149-120	SV	WINDOW, DIAL
152BCL	SV	HARDWARE KIT
154-7647	SV	MODULAR JACK
155-0001-001	SV	POTENTIOMETER
15549-001	SV	COVER
156-PDLE-13	SV	SHOCK, MOUNT
792-6357-002	SV	INDICATOR
792-6357-002	OH	INDICATOR
JG402A42	SV	INDICATOR
2594621-918	SV	INDICATOR
2594621-918	OH	INDICATOR
229-6026-030	OH	SYNCHRO
229-5022-010	OH	SYNCHRO



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
229-6026-030	OH	SYNCHRO
229-3017-018	OH	SYNCHRO
350-0083-010	OH	AMPLIFIER
350-0083-020	OH	AMPLIFIER
350-0083-020	OH	AMPLIFIER
4277-31-01	OH	SYNCHRO
R931-017	OH	SYNCHRO
TSH11F08A049	OH	SYNCHRO
7775-5580-001	OH	CASE ASSY
229-0216-000	OH	SYNCHRO
229-7031-010	OH	SYNCHRO
229-3047-016	OH	SYNCHRO
229-3047-016	OH	SYNCHRO
772-5370-001	OH	INDICATOR
229-0091-010	OH	SYNCHRO
229-0194-000	OH	SYNCHRO
229-5022-010	OH	SYNCHRO
2591411-444	SV	ATTITUDE DIRECT IND
2591411-444	SV	ATTITUDE DIRECT IND
40-618-11	OH	STABILISER TRIM
40-618-11	SV	STABILISER TRIM
9599-607-12118	OH	INDICATOR
9599-607-12118	SV	INDICATOR
40-618-8	OH	STABILISER TRIM
40-618-8	SV	STABILISER TRIM
154-7647	SV	MODULE JACK
155-0001-001	SV	POTENTIOMETER
155-0001-001	SV	POTENTIOMETER
15549-001	SV	COVER
1558/BPAJC	SV	L.C.
1558/BPAJC	SV	I.C
156-PDLE-13	SV	SHOCK MOUNT
157-1020-34-001	SV	KIT, PCB
157-1021-34-001	SV	POTENTIOMETER
157-21-502	SV	POTENTIOMETER
157-887V1	SV	BOARD
1571927-5	SV	SWITCH
15845-TL	SV	SOLDER STATION, LED
15846-TL	SV	HANDLE ASSY
15849-TL	SV	TIP, POINT
1585K33P001	SV	TERMINAL BOARD
1598K84P001	SV	CARD ASSY
15PA90-6W	SV	SWITCH



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
160-103109-001	SV	PWA-RTOM
160-103210-001	SV	PWA-RTOM
160-103336-001	SV	PWA-PWR/FAIL/DISTR
160-103478-005	SV	PWA-1MB/1MM
160-103478-005	SV	MEMORY BOARD
160-103509-001	SV	IOP-DEVICE INTERFACE
160-103526-001	SV	PWA-CPU/SGL/SLOT
160-103538-001	SV	PWA-MPCI
160-103554-001	SV	PWA-HSDI
160-103556-001	SV	COPPER FPU
160-103557-001	SV	COOPER FPU-B BOARD
160-103583-001	SV	PWA-CACHE/SELBUS
160-103583-001	SV	CSU
160-103612-001	SV	PWA-LP/FD CONT
160-103623-001	SV	PWA-UDP
160-103654-002	SV	MICRO SEQUENCER
160-103654-002	SV	MICRO SEQUENCER
160-103656-001	SV	PWA-CPU/IPU/1E2
160-103656-001	SV	IEU
160-103768-001	SV	PWA-8/LINE/CONT
1600607-1	SV	STATOR
160103J630C-F	SV	CAPACITOR
1602042-1	SV	SPRING
160561	SV	SHIP
1605961-1	SV	GLASS
160A604	SV	YELLOW, LIGHT INDI
160A604YELLOW	SV	LIGHT INDICATOR
161022-B	SV	MODULE V2, VIBRATOR
1613012-1	SV	FLAX LEAD
16171	SV	BASE, LAMP
16179	SV	PACKING
161J10	SV	TRANSFORMER
162-565W	SV	LAMP ASSY
162-570W	SV	LAMP ASSY, POINTER
1624T012S	SV	MOTOR
1631492-1	SV	BRACKET
1639-RG	SV	REGULATOR
164176-01	SV	BOARD ASSY
165440	SV	WEIGHT
16562TE	SV	MULTIMETER
166L25	SV	TRANSFORMER
166L28	SV	TANSFORMER
166L5	SV	POWER TRANSFORMER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
166L5	SV	POWER TRANSFORMER
622-5001-503	SV	INDICATOR
622-5001-503	OH	INDICATOR
393026-044	SV	INDICATOR
393026-044	OH	INDICATOR
393026-069	OH	INDICATOR
393026-069	SV	INDICATOR
393086-01236	OH	INDICATOR
114-029	OH	INDICATOR
114-029	SV	INDICATOR
264-1	OH	INDICATOR
264-1	SV	INDICATOR
36154-1AF25A1	OH	INDICATOR
36154-1AF25A1	SV	INDICATOR
772-5370-001	OH	INDICATOR
772-5370-001	SV	INDICATOR
155-0001-001	SV	POTENTIOMETER
15549-001	SV	COVER
1559C956	SV	HAND STAFF ASSY
157-21-502	SV	POTENTIOMETER
157-887V1	SV	BOARD ASSY
1571927-5	SV	SWITCH, DEDT MINI
15845-TL	SV	SOLDER, STATION, LED
15846-TL	SV	HANDLE ASSY
15849-TL	SV	TIP, POINT
1585K33P002	SV	TERMINAL BOARD
1598K84P001	SV	CARD ASSY
166L28	SV	TANSFORMER
166L5	SV	POWER TRANSFORMER
166L5	SV	POWER TRANSFORMER
1783867-11	SV	SERVO, AMPLIFER
1783867-11	OH	SERVO, AMPLIFER
G-515BA	SV	AMPLIEFIER, AUDIO
G-515BA	OH	AMPLIEFIER, AUDIO
JG7005A53	OH	RATE GYRO INDICATOR
JG7005A53	SV	RATE GYRO INDICATOR
777-1224-001	OH	FLIGHT DIRECTOR IND
777-1224-001	SV	FLIGHT DIRECTOR IND
772-5370-001	OH	INDICATOR COURSE
772-5370-001	SV	INDICATOR COURSE
622-6523-001	OH	CONTROL HEAD
622-6523-001	SV	CONTROL HEAD
622-6523-005	OH	CONTROL HEAD



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
622-6523-005	SV	CONTROL HEAD
522-4114-003	OH	RADAR INDICATOR
522-4114-003	SV	RADAR INDICATOR
65691-204-1	OH	N1 INDICATOR
65691-204-1	SV	N1 INDICATOR
622-5001-601	OH	N1 INDICATOR
622-5001-601	SV	N1 INDICATOR
622-5001-602	OH	N1 INDICATOR
622-5001-602	SV	N1 INDICATOR
522-2638-006	OH	H.S.I
522-2638-006	SV	H.S.I.
36140-1AJ25B1	OH	RADIO MAG IND
36140-1AJ25B1	SV	RADIO MAG IND
2592920-444	OH	RADIO MAG IND
2592920-444	SV	RADIO MAG IND
160-103565-001	SV	IEU
160-103768-001	SV	PWA-8/LINE/CONT
1600607-1	SV	STATOR
160103J630C-F	SV	CAPACITOR
1602042-1	SV	SPRING
160561	SV	SHIM
1605961-1	SV	GLASS
161022-B	SV	MODEL V2 VIBRATOR
16171	SV	BASE, LAMP
16179	SV	PACKING PREFORMED
161J10	SV	TRANSFORMER
162-408	SV	FRONT GASKET
162-565W	SV	LAMP ASSY
162-570W	SV	LAMP ASSY
1624T012S	SV	MOTOR
1631492-1	SV	BRACKET
1631492-1	SV	BRACKET
1639-RG	SV	LM342P12 REGULATOR
164176-01	SV	BOARD ASSY
165-10-1000	SV	CONNECTOR
165-11	SV	CONNECTOR
165-73-1001X	SV	CONNECTOR
165440	SV	WEIGHT
16562TE	SV	MULTIMETER
16179	SV	PACKING PREFORMED
161J10	SV	TRANSFORMER
162-408	SV	FRONT GASKET
162-565W	SV	LAMP ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
162-570W	SV	LAMP ASSY
1624T012S	SV	MOTOR
1631492-1	SV	BRACKET
1631492-1	SV	BRACKET
1639-RG	SV	LM342P12 REGULATOR
164176-01	SV	BOARD ASSY
165-10-1000	SV	CONNECTOR
16562TE	SV	CONNECTOR
166L25	SV	TRANSFORMER
166L28	SV	POWER TRANSFORMER
166L5	SV	POWER TRANSFORMER
166L5	SV	POWER TRANSFORMER
1672-10S	SV	FREZE SPRAY
16847-TL	SV	UTILITY BRSH, PLSTI
16848-TL	SV	UTLTU BRSH
168C9073P001	SV	CRANK ASSY
1699K35P001	SV	BRACKET
17-830	SV	SEALING STRAP
1700791	SV	SHIM
1700793	SV	GEAR SHAFT
1716405	SV	GEAR SHAFT
1717583	SV	SPRING WASHER
1717798	SV	SHAFT
1717T012S	SV	DC MOTOR
1717T012SR	SV	DC MOTOR
1718170	SV	DECAL
1718751	SV	MASK
1720042	SV	CAM
1720043	SV	SPACER
1720043	SV	SPACER
1720045	SV	GUIDE
1720046	SV	BRACKET
1720065-1	SV	CLAMP
1749374-1	SV	LEVEL SWITCH
175-16-006	SV	BOARD ASSY
175-16-006	SV	BOARD ASSY
175-26W603	SV	PLATE
1750217	SV	GASKET
1751053	SV	GEAR
1751055	SV	WHEEL
1751055	SV	WHEEL
1751295	SV	TERMINAL
1752806-10	SV	TERMINAL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1752807-2	SV	FLAG ASSY
1753859	SV	ANVIL
1754612-2	SV	RELAY
1755262	SV	POINTER
1755278	SV	GEAR
1755278	SV	GEAR
1755560	SV	DESIGNATION PLATE
1755576	SV	SPRING
1755577	SV	SHAFT
1755703	SV	GEAR
1755739	SV	MASK
1755745	SV	CLAMP
1758696-1	SV	METER MOVEMENT
1758696-2	SV	METER MOVEMENT
1765603-1	SV	RESISTOR
176B601-P1	SV	RING
1771281-1	SV	SPRINGS
1775140-1	SV	LEVEL SWITCH
1781190-1	SV	MOUNT
1781293-12	SV	NAMEPLATE
1751295	SV	TERMINAL
1781293-12	SV	NAMEPLATE
1781293-13	SV	NAMEPLATE
1781293-17	SV	NAMEPLATE
1781293-28	SV	NEMEPLATE
1781293-29	SV	NAMEPLATE
1782702	SV	LIGHT BLOCK
1782846	SV	WINDOW
1755739	SV	MASK
1758696-1	SV	METER MOVEMENT
1758696-2	SV	METER MOVEMENT
1771281-1	SV	SPRINGS
1775140-1	SV	LEVEL SWITCH
1781190-1	SV	MOUNT
1781293-12	SV	NAMEPLATE
1781293-13	SV	NAMEPLATE
1781293-17	SV	NAMEPLATE
1781293-28	SV	NAMEPLATE
1781293-29	SV	NAME PLATE
1782702	SV	LIGHTBLOCK
1782846	SV	WINDOW
1783067-1	SV	COUNTER WEIGHT
1783149	SV	NAMEPLATE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1784280	SV	LIGHT ASSY
1786941-1	SV	STUD
49-058-002M	SV	MODULE ASSY
30-0906-4	SV	RECOGNITION LIGHT
8DJ81LAA1	SV	INDICATOR
8DJ81LAA1	SV	INDICATOR
CM41005012	OH	SYNCHRO
229-7031-010	OH	SYNCHRO
8CDR-300-B-34A	OH	SYNCHRO
4039891-903	OH	AIRSPEED
4039891-903	SV	AIRSPEED
S906-40078-1	OH	LIGHT PANEL
335-101	OH	LIGHT PANEL
2594466-906	OH	MACH AIRSPEED
2594466-906	SV	MACH AIRSPEED
4005123-907	OH	ALTIMETER
4005123-907	SV	ALTIMETER
4056511-904	OH	DIMMING PANEL
4056511-904	SV	DIMMING PANEL
4034240-906	OH	VHF NAV CONTROL PANEL
4034240-906	SV	VHF NAV CONTROL PANEL
2047-02-1	OH	ENG PRESS RATIO IND
2047-02-1	SV	ENG PRESS RATIO IND
124-514-6	OH	EGT INDICATOR
124-514-6	OH	EGT INDICATOR
WL503RC	SV	CABIN RATE OF CLIMB IND
WL503RC	OH	CABIN RATE OF CLIMB IND
522782	SV	DICATOR-ENG VIBRAT
522782	OH	DICATOR-ENG VIBRAT
2592920-444	SV	DEVIATION INDICATOR
2592920-444	OH	DEVIATION INDICATOR
8DJ81WCW4	SV	INDICATOR
8DJ81WCW4	OH	INDICATOR
8DJ81WCW4U	SV	INDICATOR
8DJ81WCW4U	OH	INDICATOR
162BL403C	SV	TEMP ELEC RESISTANCE IND
162BL709C	OH	TEMP ELEC RESISTANCE IND
162BL708	SV	TEMP ELEC RESISTANCE IND
162BL708	OH	TEMP ELEC RESISTANCE IND
162BL709C	OH	TEMP ELEC RESISTANCE IND
162BL403C	SV	TEMP ELEC RESISTANCE IND
4043142-901	SV	DIAL
A2005841	NS	TORQUE POT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
009MBH02	NS	TORQUE POT
447610-1	SV	ENCODER SWITCH
4043116-1	NS	COUNTER
2186-000-1	NS	COUNTER
4039838-1	NS	MOTOR
433-673-1004-4060	NS	SWITCH
778-1448-001	NS	INCLINOMETER
3S2791G200R11	SV	ENCODER SWITCH
6X5GT	SV	VACUUM TUBE
100-19	NS	POT
609-8072-001	NS	POWER SUPPLY
10-61800-1504	NS	LIGHTPLATE
100-19	NS	POTENTIOMETER
1025700-13	NS	CIRCUIT CARD ASSY
124-833	NS	DC VOLTMETER
124-837	NS	AC AMMETER
149270-05-01	NS	TAT-EPR LIMIT INDICATOR, 60B00
609-8072-001	SV	POWER SUPPLY
10-61800-1504	SV	LIGHTPLATE
100-19	SV	POTENTIOMETER
1025700-13	SV	CIRCUIT CARD ASSY
124-833	SV	DC VOLTMETER
124-837	SV	AC AMMETER
149270-05-01	SV	TAT-EPR LIMIT INDICATOR, 60B00
157405-03-01	OH	TAT-ENG N1 LIMIT INDICATOR
157405-03-01	SV	TAT-ENG N1 LIMIT INDICATOR
1724T024S	SV	MOTOR
1778686-655	OH	COMPASS INDICATOR
1778686-655	SV	COMPASS INDICATOR
1784460-355	OH	GYROSYN COMPASS INDICATOR
1H5GT	NS	1H5GT, VACUUME TUBE (JAN-CH
200-007-005	OH	HYDRAULIC FLUID QTY INDICATC
200-3130	SV	SWITCH
206-001-003W	OH	FUEL QUANTITY INDICATOR
2070-03-1	OH	VERTICAL SPEED INDICATOR
684-113-9001	SV	SWITCH
2083-11-1	OH	MACH AIRSPEED
229-2050-010	OH	MOTOR TACHOMETER GENERAT
229-7031-010	SV	SYNCHRO TRANSOLVER
4255-15-01	SV	SYNCHRO TRANSOLVER
8CDR-300-B-34A	SV	SYNCHRO TRANSOLVER
CDSH-8-BQ-4/A013	SV	SYNCHRO TRANSOLVER
CM41005012	SV	SYNCHRO TRANSOLVER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2504524-1	SV	METER
241004-117	SV	METER
2556328-1	SV	METER
2579272	NS	TOGGLE SWITCH
2588371-901	SV	RADIO DIRECTION INDICATOR
2588371-901	OH	RADIO DIRECTION INDICATOR
2594620-905	OH	BAROMETRIC ALTITUDE INDICAT
2594620-905	SV	BAROMETRIC ALTITUDE INDICAT
2594624-912	OH	HORIZONTAL SITUATION INDICA
262-0441-010	OH	DISPLAY MODULE 4 DIGIT, A4122
280195	NS	BRUSH
281-0661-430	NS	KNOB
285T0017-103	SV	POWER SUPPLY MODULE ASSY
30-0906-4	OH	RECOGNITION LIGHT
311-711-1537-001	NS	SWITCH
311-711-1537-006	NS	SWITCH
393020-01789	OH	OIL QUANTITY INDICATOR
393026-03236	SV	FUEL QUANTITY INDICATOR
393026-042	OH	FUEL QUANTITY INDICATOR
393081-103	OH	FUEL QUANTITY TOTALIZER INDI
393090-107	OH	PRIMARY FUEL QTY INDICATOR
3S2791G200R11	SV	RELAY
40-300-1	OH	STATIC AIR TEMPERATURE INDIC
4034559-901	SV	DISTANCE BEARING INDICATOR
4034559-901	OH	DISTANCE BEARING INDICATOR
4034559-908	SV	DISTANCE BEARING INDICATOR
4034559-908	OH	DISTANCE BEARING INDICATOR
4039838-1	OH	MOTOR, SERVO
4039892-908	OH	BAROMETRIC ALTIMETER
4039893-902	OH	VERTICAL SPEED INDICATOR
4039893-903	OH	VERTICAL SPEED INDICATOR
4043116-1	OH	COUNTER ASSY (2186-000-1)
4003417-3	OH	SCREW ASSY
4043517-902	OH	INDICATOR
4043517-903	OH	FLAG INDICATOR
4053499	OH	FLAG
407857	OH	CONTROL PANEL , IND
433-673-1004-4060	OH	SWITCH ASSY, BCREFA0525,
447610-1	OH	ENCODER SWITCH
463405-052	OH	DIAL
48-60V5M1	OH	ATTITUDE DIRECTOR INDICATOR
482-5027-000	NS	METER MOVEMENT
482-5051-010	NS	SPEED FLAG



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
482-5053-010	NS	LOC FLAG
482-5058-010	NS	METER MOVEMENT/SPEED POIN
482-5068-010	NS	METER MOVEMENT
482-5083-020	NS	METER MOVEMENT
482-5083-060	NS	METER MOVEMENT
482-5084-010	NS	TO-FROM POINTER
482-5086-010	NS	METER MOVEMENT,
482-5087-010	NS	NAV FLAG
482-5088-010	NS	SOLENOID
482-5096-010	NS	METER MOVEMENT
482-5096-040	NS	METER COMPUTER
482-5111-010	NS	DATA SOURCE ACTUATOR
482-5115-010	NS	HEADING FLAG
520-3117-303	OH	RADIO MAGNETIC INDICATOR
522-2782-004	OH	COURSE INDICATOR
522-3120-004	OH	INSTRUMENT AMPLIFIER
522-3122-012	OH	FLIGHT DIRECTOR INDICATOR
522-3138-007	OH	COURSE INDICATOR
522-3877-001	OH	FLIGHT DIRECTOR INDICATOR
522-4430-005	OH	FLIGHT DIRECTOR INDICATOR
522-4825-005	OH	RADIO ALTITUDE INDICATOR
554-8965-003	OH	BRACKET
55820-190-1	OH	LCD DISPLAY
55820-300-1	OH	LCD DISPLAY
5987	OH	VECUUME TUBE
609-8072-001	OH	POWER SUPPLY ASSY
60B00132-29	OH	N1 TACHOMETER INDICATOR
60B00302-11	OH	ENG PRESSURE RATIO INDICATC
622-4938-027	OH	RADIO MAGNETIC INDICATOR
622-5001-109	OH	RADIO DISTANCE MAGNETIC IND
622-5001-110	OH	RADIO DISTANCE MAGNETIC IND
622-5001-111	OH	RDMI-RADIO DISTANCE MAGNET
622-5001-504	OH	RADIO DISTANCE MAGNETIC IND
622-5001-601	OH	RADIO DISTANCE MAGNETIC IND
622-5048-344	OH	EFIS CONTROL PANEL
622-5048-361	OH	EFIS CONTROL PANEL
622-8001-001	OH	EFIS CONTROL PANEL
622-8001-002	OH	EFIS CONTROL PANEL, EFIC-701I
622-8001-003	OH	EFIS CONTROL PANEL (EFIC-701I
622-8001-350	OH	EFIS CONTROL PANEL
622-8001-352	OH	EFIS CONTROL PANEL
622-8001-370	OH	EFIS CONTROL PANEL
64891-002-4	OH	CONTROL SURFACE POSITION IN



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
65-52822-3	OH	INDICATOR
6841008625	OH	POTENTIOMETER
69-60730-1	OH	PC ASSY, MASTER CAUTION & V/
6X5GT	OH	VACUUM TUBE
700662A	OH	LOAD CONTROLLER GENERATOR
736913	OH	SLIP RING ASSY
754-0301-001	OH	LIGHTPLATE
772-5005-005	OH	FLIGHT DIRECTOR INDICATOR
777-1083-001	OH	HORIZONTAL SITUATION INDICATOR
778-1448-001	OH	INCLINOMETER ASSY
787-6045-001	OH	SURFACE POSITION INDICATOR
8107305ADP5	OH	BRUSH
837-0007-010	OH	SWITCH, MATRIX
837-2001-020	OH	ROTARY SWITCH
88000-4102	OH	CLOCK
8DJ125LXX5	SV	FUEL FLOW USED RATE INDICATOR
8DJ162LXL2	SV	N1 TACHOMETER INDICATOR
8DJ162LZL2	SV	N2 TACHOMETER INDICATOR
8DJ176LZD2	SV	ENGINE FAN SPEED INDICATOR
8DJ176WAZ2	SV	ENGINE FAN SPEED INDICATOR
8DJ81LWT4	SV	TACHOMETER INDICATOR
8DJ81LXH2	SV	TACHOMETER INDICATOR
8DJ81LXP2	SV	TACHOMETER INDICATOR
9-102	SV	FUEL USED INDICATOR
9-116-02	SV	FUEL USED INDICATOR
9599-607-12118	SV	HEIGHT INDICATOR
974-1082-020	SV	RELAY
A2005841	OH	TORQUE POT
AA1752807-1	OH	METER MOVEMENT
B118-244	OH	FUEL QUANTITY INDICATOR
B1800-81103	OH	ALTITUDE INDICATOR
BG6227998SBA	OH	SKID BALL, (Ball Slip inclinometer)
D434-36-001	OH	FLIGHT MODE ANNUNCIATOR
GMT4190-020	OH	ELECTRONIC CLOCK
JG298A5	OH	PRESSURE RATIO INDICATOR
JG603C44	OH	FUEL QUANTITY INDICATOR
LIBB-E32	OH	POSITION INDICATOR
S906-40078-1	OH	PILOT CALL PANEL
SR-O7K	OH	HYDRAULIC BRAKE PRESSURE INDICATOR
TMS9980AJDL	SV	IC
10-61926-2	OH	INDICATOR
10-61926-2	SV	INDICATOR
40-302-3	OH	INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
40-302-3	SV	INDICATOR
40-302-4	SV	INDICATOR
40-302-3	OH	INDICATOR
40-618-8	SV	INDICATOR
40-618-8	OH	INDICATOR
285T0021-19	SV	INDICATOR
285T0021-19	OH	INDICATOR
836-7035-005	NS	LIGHTPLATE
393026-01838	NS	INDICATOR
393026-01838	SV	INDICATOR
285T0557-1	OH	INDICATOR
285T0557-1	SV	INDICATOR
65806-002-1	SV	INDICATOR
65806-002-1	OH	INDICATOR
6040-232665	OH	ROTOR INDICATOR
AF-33-600-22565	OH	ROTOR INDICATOR
JG403B4	OH	INDICATOR
JG403B4	SV	INDICATOR
622-5001-003	SV	INDICATOR
622-5001-003	OH	INDICATOR
3511-180-43191	OH	DC MOTOR
915F212-6	SV	GENERATOR CONTROL
915F212-6	OH	GENERATOR CONTROL
915F212-6	SV	GENERATOR CONTROL
972C487-1	SV	PLATE MODIFICATION
U-396031	SV	TORQUE POT
U396031	SV	TORQUE POT
301-0163-001	SV	TORQUE POT
U-310217-1	SV	TORQUE POT
WCS218-5	NS	SWITCH
WCS218-6	NS	SWITCH
381-1730-010	SV	POT
300-955	SV	POT
2590624-921	SV	INDICATOR
2590624-921	OH	INDICATOR
772-5370-002	SV	INDICATOR
772-5370-001	SV	INDICATOR
772-5370-001	OH	INDICATOR
162BL704D	OH	OIL TEMPERATURE INDICATOR
162BL704D	SV	OIL TEMPERATURE INDICATOR
65806-002-1	OH	ELECTROINC CLOCK
65806-002-1	SV	ELECTRONIC CLOCK
285T0017-103	OH	MODULE, POWER SUPPLY
285T0017-103	SV	MODULE, POWER SUPPLY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
285T0017-104	OH	MODULE, POWER SUPPLY
285T0017-104	SV	MODULE, POWER SUPPLY
WCS223-2	NS	SWITCH
WCS223-022	NS	KNOB
90-02233	NS	SWITCH
285T0017-104	NS	POWER SUPPLY
285T0017-104	NS	POWER SUPPLY
WCS223-1	NS	SWITCH
WCS223-3	NS	SWITCH
31-2911-7	SV	CAPACITOR
792-1053-002	NS	COUNTER
792-1053-001	NS	COUNTER
4053499-901	NS	FLAG ASSY
160-103768-001	NS	PART
PWA-8-Line/cont	NS	PART
2045-06-1	SV	INDICATOR
2045-06-1	OH	INDICATOR
GMT4200	OH	INDICATOR
GMT4200	SV	INDICATOR
8DJ225WAD2	OH	INDICATOR
8DJ225WAD2	SV	INDICATOR
393080-118	OH	INDICATOR
393080-118	SV	INDICATOR
69-37307-112	SV	INDICATOR
69-37317-64	OH	INDICATOR
69-37317-64	SV	INDICATOR
200-002-002	OH	INDICATOR
200-002-002	SV	INDICATOR
200-002-001	OH	INDICATOR
200-002-001	SV	INDICATOR
30-0906-101	OH	LIGHT ASSY
30-0906-101	SV	LIGHT ASSY
30-0906-104	OH	LIGHT ASSY
30-0906-104	SV	LIGHT ASSY
30-0906-105	OH	LIGHT ASSY
30-0906-105	SV	LIGHT ASSY
WL203EED3	OH	FUEL FLOW/USED INDIC
WL203EED3	SV	FUEL FLOW/USED INDIC
182936	OH	INDICATOR OXYGEN PRE
182936	SV	INDICATOR OXYGEN PRE
10-60735-1	OH	INDICATOR OXYGEN PRE
1122-19LW	SV	INDICATOR OXYGEN PRE
1122-19LW	OH	INDICATOR OXYGEN PRE
241010-121	NS	FLAG ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
A2005841	NS	TORQUER POT
A1179402	NS	TORQUER POT
009MBH02	NS	TORQUER POT
192-2060-030	NS	WEDGE, LTG
482-5152-010	NS	METER MOVEMENT
482-5144-010	NS	METER MOVEMENT
482-5151-010	NS	METER MOVEMENT
482-5143-010	NS	WEDGE, LTG
482-5148-010	NS	METER MOVEMENT
482-5147-030	NS	METER MOVEMENT
482-5146-010	NS	METER MOVEMENT
482-5149-010	NS	LOC PTR, METER MOVEMENT
797-2482-004	NS	PITCH AND ROLL CMD BOARD (A
618-3577-002	NS	PITCH AND ROLL ATTITUDE BOA
797-2484-001	NS	RUNWAY BOARD
526-0349-010	NS	TRANSFORMER, POWER
1249226	NS	TRANSFORMER, POWER
526-0348-010	NS	TRANSFORMER, POWER
124P262	NS	TRANSFORMER, POWER
609-3175-001	NS	SCALE, GLIDESCOPE
609-3187-001	NS	SCALE, SPEED
609-3533-001	NS	TAPE DRUM ASSY
792-1529-001	NS	GEAR SPUR
609-3678-001	NS	TAPE ASSY
fc	NS	ROLLER
792-1509-001	NS	GEARSHAFT, SPUR
792-1508-001	NS	ROLLER
792-1506-001	NS	MASK
792-1533-001	NS	SHAFT
797-7770-002	NS	TAPE, ALTITUDE
UM23A	NS	TORQUER POT
941942-3	NS	COUNTER
772-5370-001	SV	COURSE INDICATOR
772-5370-001	OH	COURSE INDICATOR
30-0837-9	SV	STROBE LIGHT
30-0837-9	OH	STROBE LIGHT
285T0112-4	OH	AUTOBRIGHT SENSOR
285T0112-4	OH	AUTOBRIGHT SENSOR
285T0112-4	SV	AUTOBRIGHT SENSOR
DNM100030	OH	MODULE ASSY. LCD
DNM100-030	SV	MODULE ASSY. LCD
S182-10809-4	NS	MODULE ASSY. LCD
S182-10809-41	NS	MODULE ASSY. LCD



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
DNM10003006	NS	MODULE ASSY. LCD
DNM-100-030-06	NS	MODULE ASSY. LCD
CND500-099	NS	MODULE ASSY. LCD
1783875-5	SV	INDICTOR
2067048-2402	SV	INDICTOR
172754-2104	SV	INDICTOR
7-362A	SV	INDICTOR
1780607-53	SV	INDICTOR
2388146-903	SV	INDICTOR
178607-53	SV	INDICTOR
1783875-5	SV	INDICTOR
60B40044-16	SV	INDICTOR
2067048-2402	SV	INDICTOR
2504060-2	SV	RELAY
2504061	SV	BRUSH BLOCK
2504072-1	SV	ROTOR
2504094-14	SV	COIL
2504124-203	SV	THYRISTOR
2504386-3	SV	FLAG
2504447	SV	BRUSH
2504462-1	SV	SPRING
2504482-1	SV	LIGHT BLOCK
2504524-1	SV	METER
2504533-232	SV	I.C.
2504533-245	SV	I.C.
2504905	SV	INCLINOMETER
2504909-251	SV	ZENER DIODE
251011-901	SV	CENTER DIAL
251192-901	SV	VERIABLE RESISTOR
2516224	SV	SKIRT
2519149	SV	SPACER
2519164-1	SV	PANEL BEZEL
2519270-2	SV	PC BOARD
139988-01	SV	POTENTIOMETER
2519394-2	SV	POST
2553663-8	SV	BRUSH BLOCK
2553765	SV	BRUSH BLOCK
2554676	SV	SPRING
2554738	SV	TRANSISTOR HOLDER
2555350	SV	SHAFT
2555440	SV	LEVEL SWITCH
2555483	SV	GEAR
2556209	SV	KNOB



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2556238	SV	LAMP HOLDER
2556265	SV	MOD PLATE
2556523	SV	SHAFT
2556744-1	SV	SWITCH GUARD
2575317	SV	TRANSISTOR
2575319-4	SV	GASKET
2579442-7	SV	CUSHION
2579603	SV	INDICATOR, POWER
2579765-1	SV	GEAR
2580794	SV	BRACKET
2580877	SV	MONITOR ASSY
2580935-1	SV	BRACKET
2581381-3	SV	COVER
2581479-101	SV	POINTER
2581492	SV	GEAR
2582419	SV	FRAME ASSY
2582875-102	SV	GYRO CONNECTOR PLATE
2582922	SV	LEAD ASSY
2582978-1	SV	PRINTED CABLE
2582978-2	SV	PRINTED CABLE
2582978-3	SV	PRINTED CABLE
25885565	SV	BEARING ASSY HOLDER
2585566	SV	ROTOR
2586894	SV	FRAME
2588428-3	SV	SPHERE
2588867	SV	POWER SUPPLY
259-2893-030	SV	SWITCH
2591149	SV	GUIDE
2591613-902	SV	LOC AMPLIFIER
2592668	SV	BRUSH BLOCK
2594085-901	SV	POWER SUPPLY
2594665	SV	GEAR
2594676	SV	COIL
2594737	SV	COIL
2594850-903	SV	MODULE
25F1140	SV	RED LAMP
25TTS08	SV	CONNECTOR
25Z6GT	SV	VACCUUM TUBE
26-20SSKGD	SV	CONNECTOR
26-361	SV	LOW PROFILE HEAT
2650K76P001	SV	SPRING
265641	SV	CONTACT ASSY
265642	SV	RING



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
266-7112-060	SV	LENS, PB, ILLUM WHITE
266-7566-010	SV	SWITCH PUSH
266493-001	SV	GASKET
267826	SV	RELAY
26902-1	SV	FILTER
26C6	SV	VACCUM TUBE
26ET9-T	SV	SWITCH, TOGGLE
26SF18	SV	RELAY
26V08RCT4PS0K	SV	TRANSOLVER
27-181	SV	POWER PLUG
27-32260-0010	SV	FILTER
275-4	SV	GOMMET
276-1537	SV	D-SUB CONNECT
2774W14G700	SV	COUNTER ASSY
2774W30G716	SV	DIAL
27995A521	SV	CABOLT, DRILL BIT
2793557-1	SV	ACTUATOR, SWITCH
27C010-2	SV	EPROM
280-3778-010	SV	DECAL
280-3778-050	SV	STICKER MOD
280-3778-100	SV	STICKER MOD
280-3778-100	SV	STICKER MOD
28005-03	SV	LIGHT PALTE
280195	SV	BRUSH
4041393-412	NS	IC
SCL4700-J7-MSP	NS	IC
H6C0049A	NS	IC
2P780-8943	SV	CAPACITOR
2SB463	SV	TRANSISTOR
2SC281	SV	TRANSISTOR
2SD205	SV	TRANSISTOR
2TL150-3D	SV	SWITCH
30-07-G	SV	RELAY, HERMETICALLY SEALED
300-192-2K	SV	VARIABLE RESISTOR
300-955	SV	POTENTIOMETER
300250-001	SV	SHAFT
30050M-109	SV	LIGHT, IND. AMB
3005P-M18-103	SV	RESISTOR
3006P1-102	SV	POTENTIOMETER
301-0091-001	SV	SYNCHRO
30585A65	SV	DRILL BITS & RODS
305954	SV	BEARING
306-1342-000	SV	TERMINAL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
306-2474-110	SV	TERMINAL
306-706-1002-002	SV	PILOT CALL PANEL
309-1557-000	SV	BEARING
309-1967-020	SV	BEARING
30900	SV	FILTER
30YY2312	SV	SWITCH, PUSHBUTTON
31-2511-1	SV	ID PLATE
31-2691-1	SV	MOUNTING PLATE
31-2835-1	SV	GASKET
31-3485-1	NS	SPACER
311-711-1537-006	NS	SWITCH, PUSHBUTTON
3116E2041S	NS	CONNECTOR
3116W15P001	SV	DIAL
3119W95P001	SV	DIAL
3120W34P001	SV	DIAL
3130W67P001	SV	DIAL
3132W73P001	SV	SCALEDIAL
3142W24G703	SV	DIFFUSER
314397-02	SV	UNIT WHEEL
315004	NS	FUSE
31CN205	NS	POTENTIOMETER
31CX505	SV	POTENTIOMETER
32-3040	SV	TERMINAL
320-0021-006	SV	MOUNTING KIT
3200-1087	SV	POTENTIOMETER
3200-2311	SV	POTENTIOMETER
3200-557	SV	POTENTIOMETER
32050-1002	SV	SHAFT
32076-35351	SV	CONNECTOR
321070	SV	CAP
321073	SV	TUBE
322400B00	SV	ANODIZE, BLK
322505B00	SV	ANODIZE TO-5
70-22322	NS	KNOB
522-3120-005	OH	INSTR. AMPLIFIER
522-3120-005	SV	INSTR. AMPLIFIER
262-1302-040	NS	DISPLAY ASSY
262-1302-010	NS	DISPLAY ASSY
CR70018-3	NS	DISPLAY ASSY
CR70018-2	NS	DISPLAY ASSY
200394-003	NS	MOTOR
70516-0003	NS	CIRCUIT INTEGRATED
3250I-1-102	SV	TRIMPOT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
327425	SV	SHAFT
327426	SV	GEAR CLUSTER
328003	SV	SHAFT
328008-1	SV	SHAFT
32D5494	SV	CAPACITORS
32PL	SV	CAPACITORS
33-149	SV	AA NICKEL BATTERY
33-25732-0080	SV	GEAR
330226-2	SV	HEATER
330796	SV	GASKET
330813	SV	COVER
329WT09-102	SV	VARIABLE RESISTOR
334338	SV	SWITCH
334740-1	SV	POT
336244	SV	NAME PLATE
3396W51G701	SV	BOARS ASSY
33JR117-1	NS	CONNECTOR
3437634	NS	BEARINGS
34BSX21COBORAV11G18	NS	BEARINGS
34BSX23ORA	NS	BEARINGS
34BSX52C20IRO11	NS	BEARINGS
772-5005-001	SV	FLIGHT DIRECTOR IND
772-5005-005	SV	FLIGHT DIRECTOR IND
772-5005-009	SV	FLIGHT DIRECTOR IND
772-5005-009	OH	FLIGHT DIRECTOR IND
35-21	SV	SHIM
350-0083-002	SV	IC AMPLIFIER
350-0103-010	SV	IC ERROR AMPLIFIER
350-0116-030	SV	IC AMPLIFIER
350-0142-010	SV	IC MONITOR
350-3070-030	SV	IC
350-9055-010	SV	IC
350-9077-010	SV	IC AUU WARN OUTPUT
3500S-447-022	SV	POTENTIOMETER
350364	SV	PART
350156	SV	CAP ASSU
351-2017-010	SV	IC
351-2017-010	SV	IC
35115	SV	SPLICE
350-0083-020	SV	IC AMPLIFIER
350-0103-010	SV	IC ERROR AMPLIFIER
35312	SV	DISPENSER
3540S-1-202L	SV	POTENTIOMETER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
3540S-1-501	SV	POTENTIOMETER
358104-1	SV	END CAP
35AMP	SV	FUSE
360-13	SV	PIVOT
361-1739E070A05	SV	"O" RING
363004-54-8	SV	PIN
37-3-2125	SV	PLATE
37-6-2113-2	SV	INSULATOR
37-6-5002	SV	INSULATOR
37-6-5005	SV	WASHER
372-2255-020	SV	ELECT CONTACT
372-2501-090	SV	CONTACT
372086	SV	INSULATOR
372117	SV	SEAL WASHER
3738W10G703	SV	FLAG & FRAME ASSY
3782-24-02	SV	MINI GRABBER LEADS
3782-24-2	SV	MINI GRABBER LEADS
38-204	SV	TRIMPOT
380-3356-060	SV	RESISTOR
381878	SV	TERMINAL POST ASSY
382-0082-010	SV	POTENTIOMETER
382550	SV	DECAL, FULL
382981	SV	DECAL
3830K75P001	SV	GASKET
3830K75P003	SV	GASKET
3830K80PP01	SV	GASKET
383156	SV	END PLATE
383177	SV	GEAR BOX
4005683	SV	TAPE
4007977-8	SV	LENS-AMBER
4007986-902	SV	BEZEL
400H	SV	AC VACUM
401-0778-006	SV	MASK
4010927	SV	PIN
4010969-902	SV	MODULE
4012287	SV	TRANSFORMER
E-384	SV	TRANSFORMER
4012343	SV	DECAL
4012352-901	SV	PUSH BUTTON
4012978-13	SV	PLATE
4015723-23	SV	ID PLATE
4015723-26	SV	ID PLATE
4015723-30	SV	ID PLATE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4015723-7	SV	ID PLATE
4015725-4	SV	ID PLATE
4016902-901	SV	MODULE FLAG
4018175-19	SV	ID PLATE
4018175-20	NS	ID PLATE
4018175-3	NS	PLATE
4018175-3	SV	PLATE
4018175-4	SV	ID PLATE
4018606-901	SV	MODULE
4034924	SV	SPRING
4034989-1	SV	POINTER
4034989-2	SV	POINTER
4037210-11	SV	BEARING
4037210-21	SV	BEARING
4037210-22	SV	BEARING
4037210-23	SV	BEARING
4037210-24	SV	BEARING
4038097	SV	GASKET
4039590-13	SV	DECAL
4039594	SV	GLASS
4039817-902	SV	SENTRI AMP
4039K70P001	SV	GUARD
404-112	SV	SWITCH GARD
4041412-622	SV	IC
4043126-901	SV	CCA, A/D/A
4043142-901	SV	DIAL
4050319-43	SV	IC
4051524-120	SV	ID PLATE
4051524-121	SV	ID PLATE
4051577-205	SV	PLATE
4051577-211	SV	ID PLATE
4051577-217	SV	NAME PLATE
4061836	SV	BUSHING
4065516-367	SV	ID PLATE
1753029-1	SV	BOOT
FTC307401	SV	TRANSFORMER
015-2027-000	SV	BRUSH
0-25-3SS	SV	BALL
0164-3	SV	LOCK WASHER
0164-4	SV	LOCK WASHER
0164-5	SV	LOCK WASHER
0164-7	SV	LOCK WASHER
035149	SV	SCREW



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
0411-29	SV	SCREW
0444-130	SV	SCREW
0492-3	SV	RING, RETANING
MS16633-2009	SV	RING, RETAINING
0495-3	NS	SPRING PIN
44370	SV	UNKNOWN
495013	SV	UNKNOWN
35-21	SV	SHIM
350-0083-002	SV	IC AMPLIFIER
350-0103-010	SV	IC ERROR AMPLIFIER
350-0116-030	SV	IC AMPLIFIER
350-0142-010	SV	IC MONITOR
350-3070-030	SV	IC
350-9055-010	SV	IC
350-9077-010	SV	IC AUU WARN OUTPUT
3500S-447-022	SV	POTENTIOMETER
350364	SV	PART
350156	SV	CAP ASSU
351-2017-010	SV	IC
351-2017-010	SV	IC
35115	SV	SPLICE
350-0083-020	SV	IC AMPLIFIER
350-0103-010	SV	IC ERROR AMPLIFIER
35312	SV	DISPENSER
3540S-1-202L	SV	POTENTIOMETER
3540S-1-501	SV	POTENTIOMETER
358104-1	SV	END CAP
35AMP	SV	FUSE
360-13	SV	PIVOT
361-1739E070A05	NE	"O" RING
363004-54-8	NE	PIN
37-3-2125	SV	PLATE
37-6-2113-2	SV	INSULATOR
37-6-5002	SV	INSULATOR
37-6-5005	SV	WASHER
372-2255-020	SV	ELECT CONTACT
372-2501-090	SV	CONTACT
372086	SV	INSULATOR
372117	NE	SEAL WASHER
3738W10G703	SV	FLAG & FRAME ASSY
3782-24-02	NE	MINI GRABBER LEADS
3782-24-2	NE	MINI GRABBER LEADS
38-204	SV	TRIMPOT



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
380-3356-060	SV	RESISTOR
381878	NE	TERMINAL POST ASSY
382-0082-010	SV	POTENTIOMETER
382550	SV	DECAL, FULL
382981	SV	DECAL
3830K75P001	NE	GASKET
3830K75P003	NE	GASKET
3830K80PP01	NE	GASKET
383156	SV	END PLATE
383177	SV	GEAR BOX
4005683	SV	TAPE
4007977-8	SV	LENS-AMBER
4007986-902	SV	BEZEL
400H	NS	AC VACUM
401-0778-006	SV	MASK
4010090	SV	SLIDER
4010927	SV	PIN
4010969-902	SV	MODULE
4012287	SV	TRANSFORMER
E-384	SV	TRANSFORMER
4012343	SV	DECAL
4012352-901	SV	PUSH BUTTON
4012978-13	SV	PLATE
4015723-23	SV	ID PLATE
4015723-26	SV	ID PLATE
4015723-30	SV	ID PLATE
4015723-7	SV	ID PLATE
4015725-4	SV	ID PLATE
4016902-901	SV	MODULE FLAG
4018175-19	SV	ID PLATE
4018175-20	NS	ID PLATE
4018175-3	NS	PLATE
4018175-3	NS	PLATE
4018175-4	NS	ID PLATE
4018606-901	SV	MODULE
4034924	SV	SPRING
4034989-1	SV	POINTER
4034989-2	SV	POINTER
4037210-11	SV	BEARING
4037210-21	SV	BEARING
4037210-22	SV	BEARING
4037210-23	SV	BEARING
4037210-24	SV	BEARING



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4038097	SV	GASKET
4039590-13	SV	DECAL
4039594	SV	GLASS
4039817-902	SV	SENTRI AMP
4039K70P001	SV	GUARD
404-112	SV	SWITCH GARD
4041412-622	SV	IC
4043126-901	SV	CCA, A/D/A
4043142-901	SV	DIAL
4050319-43	SV	IC
4051524-120	SV	ID PLATE
4051524-121	SV	ID PLATE
4051577-205	SV	PLATE
4051577-211	SV	ID PLATE
4051577-217	SV	NAME PLATE
4061836	SV	BUSHING
4062225-101	SV	ID PLATE
4065516-367	SV	ID PLATE
1753029-1	SV	BOOT
15549-001	SV	COVER
156PDLE13	SV	SHOCK MOUNT
1585K33P002	SV	TERMINAL BOARD
1598K84P001	SV	CARD ASSY
1600607-1	SV	STATOR
1602042-1	SV	SPRING
160561	SV	SHIM
1631492-1	SV	BRACKET
1613012-1	SV	FLEX LEAD
495013	SV	PART
44370	SV	PART
NC111K	SV	PART
015-2027-000	SV	BRUSH
BB-195-1316	SV	BRUSH
0411-29	SV	SCREW
0-25-3SS	SV	BALL
0-25-3SS	SV	BALL
0444-130	SV	SCREW
0444-224	SV	SCREW
0492-3	SV	RING, RETAINING
MS16633-2009	SV	RING, RETAINING
0495-3	SV	SPRING PIN
2953	SV	TRANSFORMER
07187-603999	SV	TRANSFORMER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
07187-603999	SV	TRANSFORMER
08sm2606-6	SV	SERVO MOTOR
M7798	SV	TRANSFORMER
841-011-002	SV	TRANSFORMER
OB2WA	SV	VACUUM TUBE
0B2WA	SV	VACUUM TUBE
JAN-OB2WA	SV	VACUUM TUBE
JRP-OB2WA	SV	VACUUM TUBE
OA2WA	SV	VACUUM TUBE
GB-0A2WA	SV	VACUUM TUBE
JAN-0A2WA	SV	VACUUM TUBE
0770-3	SV	WASHER
MS15795-802	SV	WASHER
104547	SV	COIL ASSY
1000364	SV	TERMINAL
10-117911-183	SV	CONNECTOR
BAC-10-60479-115	SV	CONNECTOR
10023325-101	SV	DIAL
10023329-101	SV	DIAL
10023331-101	SV	DIAL
7246	SV	POT
100K POT	SV	POT
267004-024	NS	METER MOVEMENT
520465	NS	METER MOVEMENT
M9070-30	NS	METER MOVEMENT
A4I222	NS	DISPLAY MODULE
A4I222	NS	DISPLAY MODULE
GMT4190-020	OH	CLOCK, ELECTORNIC
GMT4150	SV	CLOCK, ELECTORNIC
GMT4150	OH	CLOCK, ELECTORNIC
GMT4150	OH	CLOCK, ELECTORNIC
GMT4190-054P1	SV	FILTER, CARD
4043115-3	SV	KNOB
4043115-1	SV	KNOB
4043115-1	SV	GEARS
37621132	SV	INSULATOR
350-9075-010	NS	IC MONITOR
814187	NS	TRANSFORMER
101594	NS	SHAFT ASSY
8096K76G700	NS	COIL
3621K70G700	NS	FLAG
266-5031-010	SV	LENS ,PB ILLUM WHITE
10M-150-AJ-7B	SV	MOTOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
19808A5	SV	MOTOR
1208549-1	SV	SPRING
118-120-154	SV	PLATE
117334	SV	CONTACT ASSY
11237	SV	LAMP
110207	SV	CAP
109772	SV	RESISTOR SPOOL
108H	SV	KNOB, SWITCH
10630060-35	NS	CONNECTOR
1230497-1	SV	AMPLIFIER ASSY
MHX-4160	NS	RELAY
1223299-1	SV	HOUSING
1208555-1	SV	SCREW
778-1397-001	SV	BUSHING
778-1397-001	SV	BUSHING
1268625-2	SV	SPRING
1282834-P1	SV	LUCKNUT
1282372-1	SV	POT
12684	SV	SCREW
4141772P059	SV	GLASS
4141928G003	SV	DISC ASSY
4142159G003	SV	ARMATURE
4145566P031	SV	SPRING
4145566P066	SV	SPRING
4145642G125	NS	POINTER
4145642G188	SV	POINTER
4145811P001	SV	CONNECTOR
4149327P008	SV	SCREW
4149327P001	NE	SCREW
4149327P011	NE	SCREW
4149392P011	NS	SCREW
4149399G004	SV	JEWEL
42-27-11-012	NS	CAM
42-27-11-011	NS	CAM
4149463P003	SV	GROUND CLIP
4149471P015	NE	BEARING
4152030P002	SV	TERMINAL
4152232G010	SV	DISK
417572	SV	STRAP
41LK015	SV	TRANSFOMER
42-100-13-05	NS	GASKET
42-64-13-201	SV	MASK
42-191	SV	POS PRE-SENS PC BOARD



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
42-27-04-011	SV	DUMMY CASING
42-27-04-014	SV	HUB SCREW WRENCH
42-27-04-015	SV	FRONT HUB NUT WRENCH
42-27-11-011	SV	CAM
42-27-12-022	SV	KNOB
42-31-11-025	SV	TRACK
42-31-12-018	NS	WASHER
42-43-12-29	SV	KBRAKE
42-43-13-229	SV	SLIP RING ASSY
42-43-13-84	NE	GASKET
42-44-04-010	SV	ADJUSTMENT SUPPORT
42-55-13-14	SV	BRUSH BLOCK
42-64-13-004	NS	NAME PLATE
42-89-13-48	SV	DRUM
42-91-13-05	SV	LABEL LABEL
42-91-13-201	SV	MASK
3830W13P001	NS	GASKET
3830W75P001	NS	GASKET
383156	NS	END PLATE
383177	SV	GEAR BOX ASSY
383229	NE	TUBE, EVACUATING
383269	SV	GEAR BOX ASSY
383283	SV	SWITCH PLATE
383713	NS	GASKET
383908	NE	RING, FRICTION
383909	SV	KNOB
3857-TL	SV	HOMOSTATS
3881K78G700	SV	GEAR & SHAFT
3881K78G701	SV	GEAR & SHAFT
388530	SV	DECAL BIAS
3888K77P001	SV	GEAR
3894W17P001	SV	GEAR
3895K75P004	SV	GEAR
3895K75P005	SV	GEAR
39-00-0041	SV	PIN, HEADERS & WIRE
3991159	SV	GASKET
391162	SV	CONTACT ASSY
39199-2	SV	CAPACITOR
397052	SV	GEAR BOX
397455	SV	FACE PLATE
397804	SV	AMPLIFIER
397833-1	SV	SHAFT AND WIPER
397849-01235	SV	TRANSFORMER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
39K10	SV	REACTOR
3A177	SV	FILTER
3AB21	SV	CONVERTER, DC-DC
3AB25	SV	CONVERTER, DC-DC
3C5A2	SV	RESISTOR
3FS-448	SV	TRANSFORMER
3LV78	SV	AC ADAPTER
3M TYPE 79	SV	TAPE, GLASS CLOTH
3M-2307-2	SV	TAPE
3N170	SV	TRANSISTOR
3S2791G200R11	SV	RELAY
3S2791G200V9SD	SV	RELAY
3SM	SV	BULB
3SX1-T	SV	SWITCH
3U974	SV	SOLUTION TANK DISPENS
3V4	SV	TUVE
3V484	SV	FIXTURE
4-330808-9	SV	SOCKET SRPING
4-470-10564-16	SV	LIGHT ASSY
40-618-5	OH	STABILIZER TRIM
40-618-5	SV	STABILIZER TRIM
4000011	SV	PACKING
4000136	SV	TRANFORMER
4000138-1	SV	INCLINOMETER
4000281-903	SV	MODULE
4000354-901	SV	AMPLIFIER
4000983	SV	BRACKET
4001474-1	SV	GASKET
4001844	SV	TRANFORMER
4002375-1	SV	INDICATOR
4002735-901	SV	MASK
4002746	SV	GEAR
4002844-3	SV	TERMINAL
4003492-902	SV	MODULE
4003825	SV	TRANFORMER
42540	SV	SURFACE CURING
4272K70P001	SV	HOOK
4277-03-01	SV	SYNCHRO
42802300	SV	MOTOR-TACH GENERATOR
229-2007-000	SV	MOTOR-TACH GENERATOR
42802301	SV	MOTOR-TACH GENERATOR
42802302	SV	MOTOR-TACH GENERATOR
6229-67-02	SV	MOTOR-TACH GENERATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
665-55-113-1	SV	MOTOR-TACH GENERATOR
ST10017-4	SV	MOTOR-TACH GENERATOR
U-216187	SV	MOTOR-TACH GENERATOR
42802300	SV	MOTOR-TACH GENERATOR
428506-17	SV	POTENTIOMETER
428518-6	SV	POTENTIOMETER
428518-8	SV	POTENTIOMETER
428527-7	SV	POTENTIOMETER
4287-7	SV	LENS
42955A18	SV	CARBIDE
4302F3-5V	SV	AMBER DIFFUSED
432936	SV	BOLT
433-100-005	SV	GARD SWITCH
433232	SV	TRANSFORMER
433391-4	SV	CAPACITOR
433391-5	SV	CAPACITOR
433924-4	SV	RESISTANCE WINDING
433924-7	SV	RESISTANCE WINDING
434-674-1031-2001	SV	LIGHT ASSY INDICAOTR
434336-11	SV	CARD ASSY
434683-1	SV	SWITCH PLATE ASSY
435H10	SV	DIODE
436481-3	SV	CASE ASSY
436931	SV	SPUR GEAR
436998	SV	BEARINGS PLATE
437467-2	SV	WIPER ASSY
4381W10P001	SV	HUB
439-5276-000	SV	WIRE
439300	SV	SPACER
44-1055	SV	SHIELD
441-R328	SV	FUSE HOLDER
441173-3	SV	ROTOR
442469	SV	PC BOARD
442587	SV	PC BOARD
454381	SV	PC BOARD
482-5098-000	NS	GS POINTER
482-5098-010	NS	GS POINTER
482-5100-010	NS	SPEED POINTER
482-5102-010	NS	GS FLAG
482-5099-010	NS	R/T POINTER
M9073-25	NS	GLIDESLOPE FLAG
M9076-25	NS	GLIDESLOPE FLAG
M9073-27	SN	SPEED CONTROL POINTER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
M9071-76	NS	GLIDESLOPE FLAG
484-5102-010	NS	FLAG
482-5098-010	NS	FLAG
482-5100-020	NS	POINTR
482-5100-010	NS	RT POINTER
797-7616-001	NS	COMMAND BOARD
778-1455-001	NS	MASK
778-1306-001	NS	SCALE, SPEED
778-1307-001	NS	SCALE, GS
1822-369LW	SV	VIBRAT MONITOR INDICATOR
10-62067-1	SV	VIBRAT MONITOR INDICATOR
1822-369LW	OH	VIBRAT MONITOR INDICATOR
10-62067-1	OH	VIBRAT MONITOR INDICATOR
522782	OH	VIBRAT MONITOR INDICATOR
2580011	NS	DIAL
2580952	NS	GEAR CLUSER
2557020	NS	PLATE
2557019	NS	NUT
2557017	NS	TERMINAL BARD
25567441	SV	SWITCH GARD
2556177	NS	GEAR CLUSTER
2556175	NS	GEAR CLUSTER
2556168	NS	BRAKET
2579765-1	SV	GEAR
2579442-1	SV	BOLT
2580258	SV	DIAL
2580011	NS	DIAL
1778673	NS	FLAG
1752807-2	NS	FLAG ASSY
1775140-1	SV	LEVEL SWITCH
176B601-P1	SV	RING
175-21W-154-3	NS	DIAL
175-26W603	SV	PLATE
175-21W-154-4	NS	PLATE
147C161P001	SV	PICKOFF ASSY
1307876-1	SV	MICRO SWITCH
139288-01	SV	ID PLATE
1383842	NS	CLIP
13518	NS	WASHER
135	SV	SPRING
1298705-	SV	NAME PLATE
1295162P002	SV	NUT
1293542-3	SV	SLIP RING ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1293542-2	SV	SLIP RING ASSY
125K7	SV	VACUUM TUBE
12SK7	SV	VACUUM TUBE
442-040-009	NS	DIAL ASSY
4016460-1	NS	SYNCHRO
442-040-002	SV	DIAL
4012287	SV	TRANSFORMER
E-384	SV	TRANSFORMER
4001844	SV	TRANSFORMER
3v4	SV	TUBE
4003825	SV	TRANSFORMER
46-982-1	SV	SWITCH ASSY
461905-4	SV	RESISTOR
463322-00116	SV	CONNECTOR
463395	SV	PLATE
463404-02237	SV	LIGHTINGASSY
463405-01235	SV	DIAL, SCALE
463405-01508	SV	DIAL, SCALE
463432	SV	LIGHT SHIELD
463548-001	SV	RING, LIGHTING
463683	SV	CONNECTOR
463694J	SV	TRANSFORMER
463700	SV	TRANSFORMER
463704	SV	PC BOARD
463712	SV	GEAR ASSY
463750	SV	WASHER
463750-1	SV	WAHSER
463751	SV	POST
463751-1	SV	SPACER
463760	SV	PLATE IDENTIFICATION
463763	NS	PIN COTTER
463777-03235	NS	GEAR ASSY
463803-03335	SV	TRANSFORMER
463817-714	SV	DIODE
792-6091-001	OH	H.S.I.
792-6091-001	SV	H.S.I.
772-5006-005	OH	H.S.I.
772-5006-005	OH	H.S.I.
772-5006-005	OH	H.S.I.
801EED6	SV	PLACARD
800EED6	SV	PLACARD
CMP505	SV	PANEL
AC30-0003-3	OH	AUTOBRAKE SELECT SWITCH



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
AC30-0003-3	OH	AUTOBRAKE SELECT SWITCH
454866-22	SV	CLUTCH ASSY
454866-19	SV	CLUTCH ASSY
454866-17	SV	CLUTCH ASSY
454381	SV	P.C. BOARD
454973-6	NS	GEAR ASSY
454974-6	SV	GEARSHAFT
452656	SV	STRIP
452574-2	SV	ROTOR
452571	SV	ROTOR
452525	SV	PIN
S233T100-546	SV	LIGHTPANEL
451778	SV	REACTOR
266-7035-070	NS	LENS
851-35277-107	NS	LENS, PUSHBUTTON
266-7035-090	NS	LENS
851-35277-109	NS	SWITCH, LENS
439444-4	SV	ID PLATE
439300	NS	SPACER
437467-2	SV	WIPER ASSY
436998	NS	BEARING PLATE
434336-7	NS	CARD ASSY
4043198	NS	SPACER
4043196	NS	SHAFT
2503594-55	NS	WHASHER, FAT
4043195	NS	GEAR
234597-649	NS	SPRING
4043199	NS	SPACER
2500148-19	NS	SETSCREW
482-0066-050	NS	FLAG POINTER
482-0066-050	NS	FLAG POINTER
482-0066-030	NS	FLAG MOVMENT SOLENOID
482-0066-010	NS	FLAG MOVMENT SOLENOID
482-0066-030	NS	FLAG MOVMENT SOLENOID
482-0066-010	NS	FLAG MOVMENT SOLENOID
642-3997-012	NS	BOARD CIRCUIT
642-3997-012	NS	BOARD CIRCUIT
642-4584-005	NS	CIRCUIT CARD ASSY
642-4584-005	NS	CIRCUIT CARD ASSY
642-4000-003	NS	POWER SUPPLY
622-5739-002	NS	ENCODER
642-4589-003	NS	CARD ASSY
642-4592-006	NS	CARD ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
522-4114-012	OH	RADIO ALTITUDE INDICATOR
522-4114-012	SV	RADIO ALTITUDE INDICATOR
262-2848-160	SV	LIGHT, INDICATOR. AMB
30050M-109	SV	LIGHT, INDICATOR. AMB
665-000176-2	NS	SWITCH ASSY
4041990-1	NS	SYNCHRO REOLVER
CSH-8-E-1	NS	SYNCHRO REOLVER
2186-000-1	NS	COUNTER
2186-0001	NS	COUNTER
4043116-1	NS	COUNTER
4043116-1	NS	COUNTER
MS51957-2	NS	SCREW
2500480-38	NS	SCREW
4043142-901	NS	DIAL
4043142	NS	DIAL
4043173-904	NS	BEZEL
4043173-901	NS	BEZEL
4043173-905	NS	BEZEL
4045190-405	NS	MICROCIRCUIT
4045190-403	NS	MICROCIRCUIT
4045190-406	NS	MICROCIRCUIT
4045190-404	NS	MICROCIRCUIT
RSA2366-1	NS	SOLENOID, ROTARY
531295-966	NS	MECHANISM ASSY
182936	OH	H.S.I.
182936	SV	H.S.I.
DM74126N	SV	IC
DM8094N	SV	IC
351-7728-010	SV	IC
906-50037-110	SV	DIODE
BAS78	SV	DIODE
DM74LS30N	SV	IC
ECG4017B	SV	IC
4017B	SV	IC
70509-0001	SV	IC
351-1112-012	SV	IC
IRF730B	SV	IC
4034801-608	SV	IC
L1A2361	SV	CLOCK DRIVER
6900W11P004	SV	CLOCK DRIVER
351-8776-020	SV	IC
7802801EA	SV	IC



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
SG1526BJ/883B	SV	IC
SI4559EY	SV	MOSFET
TL082BCP	SV	IC
192-2071-010	SV	WEDGE LIGHTING
1867901-1	SV	BRACKET, LEVEL ASSY
1916114-1	SV	PIN
1916114-2	SV	PIN
1931249-1	SV	MAST-INDICATOR
192-2015-010	SV	GLASS
19-1611-01	SV	POINTER
187174-001	SV	PIVOT
1931290-1	SV	BLOCK LIGHTING
1931410-1	SV	PLATE LIGHTING
1931416-1	SV	RING-FUDUCIAL
19315-729685-2	SV	CLIP
192-2003-010	SV	LIGHT WEDGE
192-2010-010	SV	WEDGE LIGHTING
1886563-1	SV	BRAKET
65691-301-1	OH	EPR INDICATOR
65691-301-1	SV	EPR INDICATOR
65691-301-1	OH	EPR INDICATOR
SR-07B	OH	HYD PRESSURE IND
SR-07B	SV	HYD PRESSURE IND
393026-047	OH	INDICATOR
393026-047	SV	INDICATOR
393026-048	OH	FUEL QTY INDICATOR
393026-048	SV	FUEL QTY INDICATOR
307AAK	SV	IC
DG307AAK/883	SV	IC
4039142-407	SV	IC
1040	SV	ARBOR
463405-01840	SV	DIAL, SCALE
736377	SV	KNOB
500539-004	SV	DIAL PLATE
393026-047	OH	FUEL QTY INDICATOR
393026-047	SV	FUEL QTY INDICATOR
WL203EED8	OH	INDICATOR
WL203EED8	SV	INDICATOR
9-116-02	OH	FUEL USED IND
9-116-02	SV	FUEL USED IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
8DJ125LXF4	OH	FLOWMETER INDICATOR
8DJ125LXF4	SV	FLOWMETER INDICATOR
8DJ339WAF1	OH	STANDBY ENG IND
8DJ339WAF1	SV	STANDBY ENG IND
622-5390-001	OH	VHF COMM FRES PANEL
622-5390-001	SV	VHF COMM FRES PANEL
622-6831-001	OH	VHF COMM PANEL
622-6831-001	SV	VHF COMM PANEL
393026-036	OH	FUEL QTY INDICATOR
393026-036	SV	FUEL QTY INDICATOR
2061-14-1	OH	FLAP POSITION IND
2061-14-1	SV	FLAP POSITION IND
10-61926-4	OH	FLAP POSITION IND
10-61926-4	SV	FLAP POSITION IND
2061-13-1	OH	FLAP POSITION IND
2061-13-1	SV	FLAP POSITION IND
10-61926-3	OH	FLAP POSITION IND
10-61926-3	SV	FLAP POSITION IND
522-3487-002	OH	FLIGHT DIRECTOR INDICATOR
522-3487-002	SV	FLIGHT DIRECTOR INDICATOR
329B-7C	OH	FLIGHT DIRECTOR INDICATOR
329B-7C	SV	FLIGHT DIRECTOR INDICATOR
522-3667-001	OH	FLIGHT DIRECTOR INDICATOR
522-3667-001	SV	FLIGHT DIRECTOR INDICATOR
329B-7G	OH	FLIGHT DIRECTOR INDICATOR
329B-7G	SV	FLIGHT DIRECTOR INDICATOR
522-3700-004	OH	FLIGHT DIRECTOR INDICATOR
522-3700-004	SV	FLIGHT DIRECTOR INDICATOR
329B-8A	OH	FLIGHT DIRECTOR INDICATOR
329B-8A	SV	FLIGHT DIRECTOR INDICATOR
5036964-01	OH	FLIGHT DIRECTOR INDICATOR
5036964-01	SV	FLIGHT DIRECTOR INDICATOR
JG403B3	OH	FUEL QTY INDICATOR
JG403B3	SV	FUEL QTY INDICATOR
10-3065-258	OH	FUEL QTY INDICATOR
10-3065-258	SV	FUEL QTY INDICATOR
JG403B1	OH	FUEL QTY INDICATOR
JG403B1	SV	FUEL QTY INDICATOR
10-3065-256	OH	FUEL QTY INDICATOR
10-3065-256	SV	FUEL QTY INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
610BL24B	OH	TEMPERATURE IND
610BL24B	SV	TEMPERATURE IND
SEDL-OC9A	OH	DUAL DUCT PRESS IND
SEDL-OC9A	SV	DUAL DUCT PRESS IND
S231T245-2	OH	DUAL DUCT PRESS IND
S231T245-2	SV	DUAL DUCT PRESS IND
SR-04E	OH	DUAL DUCT PRESS IND
SR-04E	SV	DUAL DUCT PRESS IND
SR-04E	OH	OIL PRESS IND
SR-04E	SV	OIL PRESS IND
SEDL-OC9A	OH	DUAL DUCT PRESS IND
SEDL-OC9A	SV	DUAL DUCT PRESS IND
393026-03335	OH	FUEL QTY INDICATOR
393026-03335	SV	FUEL QTY INDICATOR
10-60520-27	OH	FUEL QTY INDICATOR
10-60520-27	SV	FUEL QTY INDICATOR
M9071-106	NS	HDG FLAG
482-5117-010	NS	HDG FLAG
2555440	SV	LEVEL SWITCH
2553765	SV	BRUSH BLOCK
2555483	SV	GEAR
2501538-2	NS	DC MOTOR
21107A-CY-04/D134	NS	DC MOTOR
21107A-CY-04/D425	NS	DC MOTOR
947283-3	NS	SYNCHRO
4000313-1	NS	MAG WHEEL IND
4017822-1	NS	MAG WHEEL IND
2594625-903	SV	RDDMI
2594625-903	OH	RDDMI
100925-3	NS	MAG WHEEL IND
1783636-27	NS	CONNECTOR
482-5051-010	NS	SPEED FLAG
MODEL 9833	NS	SPEED FLAG
196734-901	NS	GLIDE SLOPE
482-5002-000	NS	GLIDE SLOPE
MODEL 9880	NS	GLIDE SLOPE
196734	NS	GLIDE SLOPE
196978-901	NS	GLIDE SLOPE
482-5017-000	NS	GLIDE SLOPE
MODEL 9880	NS	GLIDE SLOPE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
482-5013-000	NS	VOR-LOC FLAG
M9071-50	NS	VOR-LOC FLAG
1996581-1	NS	SWITCH BLOCK
2781630-1	NS	BOARD, DIODE MOUNTING
3585-02CN	NS	COIL, HELICAL
2781627-1	NS	COMPONENT ASSY
6SX1H58	NS	SWITCH , PUSH
1975214-2	NS	ROTARY SWITCH
1980959-1	NS	CLAMP
1996561-1	NS	CLAMP
1975194-1	NS	CLUTCH ASSY
1975244-1	NS	SPUR GEAR
1967696-1	NS	CLUTCH , MAGNETIC
CK5020-10A1	NS	MOTOR, CONTROL
1928818-4	NS	MOTOR, CONTROL
772-5005-006	OH	FLIGHT DIRECTOR
772-5005-006	SV	FLIGHT DIRECTOR
772-5005-005	OH	FLIGHT DIRECTOR
772-5005-005	SV	FLIGHT DIRECTOR
622-5002-701	OH	FLIGHT DIRECTOR
622-5002-701	SV	FLIGHT DIRECTOR
1903585-3	SV	RADIO DISTANCE MAGNETIC IND
1903585-3	OH	RADIO DISTANCE MAGNETIC IND
622-6831-002	OH	VHF COMM PANEL
622-6831-002	SV	VHF COMM PANEL
8DJ81WAG2	OH	TACHOMETER INDICATOR
8DJ81WAG2	SV	TACHOMETER INDICATOR
152BL801E	OH	EGT INDICATOR
152BL801E	SV	EGT INDICATOR
162BL802	OH	OIL TEMPERATURE IND
162BL802	SV	OIL TEMPERATURE IND
501-1228-02	OH	EMERGENCY POWER SUPPLY
501-1228-02	SV	EMERGENCY POWER SUPPLY
393080-118	OH	TOTAL FUEL/V-REF IND
393080-118	SV	TOTAL FUEL/V-REF IND
GMT4190-053P2	NS	CARD PROCESSING
GMT4190-052P2	NS	CARD POWER SUPPLY
GMT4190-054P1	NS	CARD FILTER
116371	NS	CARD PROCESSING
GMT4190-053P2	NS	CARD PROCESSING



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
GMT4190-052P2	NS	CARD POWER SUPPLY
GMT4190-054P1	NS	CARD FILTER
116371	NS	CARD PROCESSING
2504468-3	NS	INDICATOR, LOC
2504468-2	NS	INDICATOR, RWY
2556535-901	NS	INCLINOMETER
2556535	NS	INCLINOMETER
393026-01837	OH	FUEL QUANTITY INDICTOR
393026-01837	SV	FUEL QUANTITY INDICTOR
393026-01838	OH	FUEL QUANTITY INDICTOR
393026-01838	SV	FUEL QUANTITY INDICTOR
393026-01840	OH	FUEL QUANTITY INDICTOR
393026-01840	SV	FUEL QUANTITY INDICTOR
393026-002	OH	FUEL QUANTITY INDICTOR
393026-002	SV	FUEL QUANTITY INDICTOR
393026-01880	OH	FUEL QUANTITY INDICTOR
393026-01880	SV	FUEL QUANTITY INDICTOR
393026-03235	OH	FUEL QUANTITY INDICTOR
393026-03235	SV	FUEL QUANTITY INDICTOR
393026-03236	OH	FUEL QUANTITY INDICTOR
393026-03236	SV	FUEL QUANTITY INDICTOR
393026-03335	OH	FUEL QUANTITY INDICTOR
393026-03335	SV	FUEL QUANTITY INDICTOR
393026-037	OH	FUEL QUANTITY INDICTOR
393206-037	SV	FUEL QUANTITY INDICTOR
393026-069	OH	FUEL QUANTITY INDICTOR
393026-069	SV	FUEL QUANTITY INDICTOR
393026-077	OH	PRECAL FUEL QTY IND
393026-077	SV	PRECAL FUEL QTY IND
393026-078	OH	FUEL QUANTITY INDICTOR
393026-078	SV	FUEL QUANTITY INDICTOR
393080-103	OH	FUEL QUANTITY INDICTOR
393080-103	SV	FUEL QUANTITY INDICTOR
10-61371-3	OH	FUEL QUANTITY INDICTOR
10-61371-3	SV	FUEL QUANTITY INDICTOR
393084-04359	OH	OIL QTY IND
393084-04359	SV	OIL QTY IND
10-60722-5	OH	OIL QTY IND
10-60722-5	SV	OIL QTY IND
393086-01236	OH	OIL QTY IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
393086-01236	SV	OIL QTY IND
10-60520-5	OH	OIL QTY IND
10-60520-5	SV	OIL QTY IND
393086-01508	OH	OIL QTY IND
393086-01508	SV	OIL QTY IND
10-60520-23	OH	OIL QTY IND
10-60520-23	SV	OIL QTY IND
69B46116-11	OH	MOD ASSY, DC METERS
69B46116-11	SV	MOD ASSY, DC METERS
2594621-917	OH	AIRSPD/MACH INDICATOR
2594621-917	SV	AIRSPD/MACH INDICATOR
4004255-901	OH	ATTITUDE DIRECTOR IND
4004255-901	SV	ATTITUDE DIRECTOR IND
8DJ81WAG2	OH	TACHOMETER INDICATOR
152BL801E	OH	EGT INDICATOR
162BL802	OH	OIL TEMPERATURE INDICATOR
393080-118	OH	TOTAL FUEL/V-REF IND
8DJ81WAG2	SV	TACHOMETER INDICATOR
152BL801E	SV	EGT INDICATOR
162BL802	SV	OIL TEMPERATURE INDICATOR
393080-118	SV	TOTAL FUEL/V-REF IND
2854292178	SV	LIGHT PANEL
GCC11-13P4	NS	ENCODER
3499134	NS	ENCODER
778-1306-001	SV	SCALE, SPEED
778-1306-001	NS	SCALE, SPEED
50YY29101	NS	ROTARY SWITCH
259-2900-150	NS	ROTARY SWITCH
50YY29101	SV	ROTARY SWITCH
259-2900-150	SV	ROTARY SWITCH
609-3175-002	NS	SCALE GLIDESLOPE
11-0368-25NF	NS	EXIT LIGHT COVER
10-60991-49	NS	EXIT LIGHT COVER
22800B3	SV	RESISTOR
989995-1	SV	DIAL
1765603-1	SV	RESISTOR
1215813-1	SV	RESISTOR
1804181-2	SV	RESISTOR
351-8766-011	SV	MICROCIRCUIT
2594625-903	NS	RMI INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
40-60V5M1	OH	ADI
40-60V5M1	SV	ADI
2594624-912	SV	H.S.I.
64878-000-1	SV	DUAL PRESS EMG IND
65691-204-1	SV	N1 INDICATOR
2594625-903	OH	RMI INDICATOR
40-60V5M1	OH	ADI
2594624-912	OH	H.S.I.
64878-000-1	OH	DUAL PRESS EMG IND
65691-204-1	OH	N1 INDICATOR
DNM100-082	SV	MODULE LCD
61YY11002-7	NS	ENCODER
H4281N1	SV	ANNUNCIATOR
2501463-14	SV	ANNUNCIATOR
900-12597-4	NS	ENCODER
900-12376-1	NS	MODULE LCD
900-12376-1	NS	MODULE LCD
797-2482-001	NS	PCB ASSY
618-3577-002	NS	ATTITUDE BOARD
797-2484-003	NS	CCA, RUNWAY (A5)
763-5909-001	NS	TRANSFORMER
526-0348-010	NS	TRANSFORMER
TF5T03ZZ	NS	TRANSFORMER
797-2486-003	NS	POWER SUPPLY
629-8391-001	NS	POWER SUPPLY
609-3291-001	NS	MASK
609-3189-001	NS	SCALE GS
482-5150-010	NS	METER MOVEMENT
482-5145-020	NS	METER MOVEMENT
482-5148-010	NS	METER MOVEMENT
609-4192-004	NS	CASE ASSY
482-5152-010	NS	METER MOVEMENT
482-5144-010	NS	METER MOVEMENT
482-5143-010	NS	METER MOVEMENT
482-5147-030	NS	METER MOVEMENT
482-5151-010	NS	METER MOVEMENT
797-2482-001	NS	PCB ASSY
618-3577-002	NS	ATTITUDE BOARD
797-2484-003	NS	PCB ASSY
763-5909-001	NS	TRANSFORMER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
526-0348-010	NS	TRANSFORMER
TF5T03ZZ	NS	TRANSFORMER
797-2486-003	NS	POWER SUPPLY
629-8391-001	NS	POWER SUPPLY
609-3291-001	NS	MASK
609-3189-001	NS	SCALE GS
482-5150-010	NS	METER MOVEMENT
482-5145-020	NS	METER MOVEMENT
482-5148-010	NS	METER MOVEMENT
609-4192-004	NS	CASE ASSY
482-5152-010	NS	METER MOVEMENT
482-5144-010	NS	METER MOVEMENT
482-5143-010	NS	METER MOVEMENT
482-5147-030	NS	METER MOVEMENT
482-5151-010	NS	METER MOVEMENT
772-5370-003	OH	COURSE INDICATOR
772-5370-003	SV	COURSE INDICATOR
772-5370-005	OH	COURSE INDICATOR
772-5370-005	SV	COURSE INDICATOR
772-5431-001	OH	FLIGHT DIRECTOR IND
772-5431-001	SV	FLIGHT DIRECTOR IND
772-8797-001	SV	SPRING HELICAL
772-8797-001	SV	SPRING HELICAL
775-5034-001	NS	GEAR
775-5034-001	NS	GEAR
775-5739-002	NS	TAPE ROLLER ASSY
775-5739-002	NS	TAPE ROLLER ASSY
622-3371-001	NS	TRANSMITER
618-3577-004	NS	PC BOARD
618-3577-005	NS	PC BOARD
382-0028-010	NS	VARIABLE RESISTOR
55FL1-109	NS	VARIABLE RESISTOR
1020-553	NS	VARIABLE RESISTOR
659-8322-001	NS	CASE ASSY
659-8315-001	NS	CASE ASSY
659-8320-001	NS	CASE ASSY
5906-10097-101	NS	PANEL ASSY
285U0038-32	NS	PCB ASSY
285U0040-18	NS	PCB ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
900-12597-4	NS	ENCODER
61YY11002-7	NS	ENCODER
285U0039-14	NS	PLATE ASSY
285U0051-3	NS	PLATE ASSY
55FL1-109	NS	VARIABLE RESISTOR
1020-553	NS	VARIABLE RESISTOR
659-8322-001	NS	CASE ASSY
659-8315-001	NS	CASE ASSY
659-8320-001	NS	CASE ASSY
5906-10097-101	NS	PANEL ASSY
285U0038-32	NS	PCB ASSY
285U0040-18	NS	PCB ASSY
900-12597-4	NS	ENCODER
61YY11002-7	NS	ENCODER
285U0039-14	NS	PLATE ASSY
285U0051-3	NS	PLATE ASSY
522-4363-007	OH	RADIO ALTITUDE IND
522-4363-007	SV	RADIO ALTITUDE IND
339H-1B	OH	RADIO ALTITUDE IND
339H-1B	SV	RADIO ALTITUDE IND
522-4363-004	OH	RADIO ALTITUDE IND
522-4363-004	SV	RADIO ALTITUDE IND
4028193-901	SV	POWER SUPPLY
7822031	SV	PLATE
782276-1	SV	STATOR
779-3516-001	SV	GEAR
778-1346-001	SV	COMMAND BAR
778-1344-001	SV	COMMAND BAR
7834K73P010	SV	SPACER
7834K72P043	SV	SPACER
7762W10P001	SV	SOCKET
F611-1	OH	FLAP POSITION IND
F611-1	SV	FLAP POSITION IND
10-0067-9	OH	EMERGENCY EXIT LIGHT
10-0067-9	SV	EMERGENCY EXIT LIGHT
10-60091-101	OH	EMERGENCY EXIT LIGHT
10-60091-101	SV	EMERGENCY EXIT LIGHT
55806-270-1	NS	LCD DISPLAY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
DND100-271	NS	LCD DISPLAY
A1123973	NS	CONNECTOR FLEX
55806-740-1	NS	BEZEL
622-6830-001	OH	ADF FREQUENCY PANEL
622-6830-001	SV	ADF FREQUENCY PANEL
100-003-182-001	NS	DISPLAY
100-003-182-001	NS	DISPLAY
2594621-913	SV	MACH AIRSPEED
2594621-913	OH	MACH AIRSPEED
4057800-901	SV	MACH AIRSPEED
4057800-901	OH	MACH AIRSPEED
2045-06-1	SV	MACH AIRSPEED
2045-06-1	OH	MACH AIRSPEED
95F212-4	OH	GENERATOR CONTROL
95F212-4	SV	GENERATOR CONTROL
4005123-907	OH	ALTIMETER
4005123-907	SV	ALTIMETER
482-5101-010	NS	METER FLAG "RUNWAY"
241010-130	NS	METER FLAG "RUNWAY"
8DJ164LWV2	OH	FUEL FLOW IND
8DJ164LWV2	SV	FUEL FLOW IND
2067635-0706	OH	ALTIMETER INDICATOR
2067635-0706	SV	ALTIMETER INDICATOR
1NA-51A	OH	ALTIMETER INDICATOR
1NA-51A	SV	ALTIMETER INDICATOR
2594620-915	OH	BAROMET ALTITUDE IND
2594620-915	SV	BAROMET ALTITUDE IND
255302-5	OH	DIRECTIONAL GYRO
229-0245-00	NS	SYNCHRO RECEIVER
229-0245-000	NS	SYNCHRO RECEIVER
2400-3	SV	SWITCH
797-3567-005	NS	DME BOARD
621-1523-001	NS	BOARD ASSY
JG298A4	SV	PRESSURE RATION IND
JG298A4	OH	PRESSURE RATION IND
55806-964-2	NS	BOARD
55806-982-03	NS	BOARD
55806-973-4	NS	BOARD



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
55806-992-1	NS	PCB POWER SUPPLY
55806-911-1	NS	BOARD
50YY23566	NS	SWITCH
8YY23955	NS	SWITCH
57351-307-1	NS	SWITCH
646-8257-001	NS	CIRCUIT, CARD
646-5179-005	NS	CIRCUIT, CARD ASSY
837-2001-07	NS	SWITCH ROTARY
4003734-901	OH	RMI
4003734-901	SV	RMI
RH-551C	OH	RMI
RH-551C	SV	RMI
JG141A2	OH	FUEL QTY INDICATOR
JG141A2	SV	FUEL QTY INDICATOR
4002001-1	SV	INDICATOR, FLAG
4000440-1	NS	MONITOR
4000440-901	SV	MONITOR. MODULE
4000440-901	SV	MONITOR. MODULE
18-36480A01	SV	SINE/COSINE POT
4016460-1	NS	MONITOR. MODULE
ERH-10-DUS-04/B924	NS	SYNCHRO RECEIVER
SR2ARHH5P24	SV	BEARINGS
15DO22A016	SV	BEARINGS
APE4190-014	SV	CLOCK
APE4190-014	OH	CLOCK
6107W14P003	NS	RELAY
6900W12P006	NS	IC
2341W26P002	NS	CLAMP
147C161P001	NS	PICKOFF ASSY
147C161P001	SV	PICKOFF ASSY
TPIC2406NE	NS	IC
2406NE	NS	IC
835-0127-010	NS	IC
TPIC2406NE	SV	IC
2406NE	SV	IC
835-0127-010	SV	IC
2590795	SV	BRACKET
2590795	NS	BRACKET



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
265642	SV	RING
265642	NS	RING
265641	SV	CONTACT ASSY
265641	NS	CONTACT ASSY
2650K76P001	SV	SPRING
2650K76P001	NS	SPRING
2526GT	NE	VACUUM TUBE
25Z6GT	NS	VACUUM TUBE
2591149	SV	GUIDE
2591149	NS	GUIDE
500-5-62	NE	POTENTIOMETER
500562	NS	POTENTIOMETER
2593263	SV	GEAR
2593263	NS	GEAR
482-5107-020	NS	METER MOVEMENT
215010-054	NS	METER MOVEMENT
482-5084-010	NE	METER MOVEMENT
252005-005	NS	METER MOVEMENT
252005-012	NS	METER MOVEMENT
482-5107-020	SV	METER MOVEMENT
215010-054	SV	METER MOVEMENT
482-5084-010	SV	METER MOVEMENT
252005-005	SV	METER MOVEMENT
252005-012	SV	METER MOVEMENT
285T0017-104	SV	POWER SUPPLY
285T0017-104	OH	POWER SUPPLY
625946-10	OH	PACK TEM CONTROLLER
625946-10	SV	PACK TEM CONTROLLER
777-1397-004	OH	H.S.I.
777-1397-004	SV	H.S.I.
777-1397-001	SV	H.S.I.
777-1397-001	OH	H.S.I.
JG402A3	OH	FUEL QUANTITY IND
JG402A3	SV	FUEL QUANTITY IND
JG402A53	OH	FUEL QUANTITY IND
JG402A53	SV	FUEL QUANTITY IND
JG402A2	OH	FUEL QUANTITY IND
JG402A2	SV	FUEL QUANTITY IND



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
3SBC5004K1	NS	RELAY
185-007-0031	NS	RELAY
M39016/9-006L	NS	RELAY
40-617-1069U	NS	RELAY
W260-F4A-M11	NS	RELAY
BACR13CD2	NS	RELAY
3SBC5004K1	SV	RELAY
185-007-0031	SV	RELAY
M39016/9-006L	SV	RELAY
40-617-1069U	SV	RELAY
W260-F4A-M11	SV	RELAY
BACR13CD2	SV	RELAY
EFD2C12-18	NS	RELAY
BACR13CD2	SV	RELAY
3SAH1326A2	NS	RELAY
BACR13CE2	NS	RELAY
3SAH1157A2	NS	RELAY
3SAH1326A2	SV	RELAY
BACR13CE2	SV	RELAY
3SAH1157A2	SV	RELAY
B353-18	OH	FUEL QTY INDICATOR
B353-18	SV	FUEL QTY INDICATOR
55821-265-1	SV	MOTOR
HI-8010J-65	SV	IC
8DJ81LYV4	OH	N2 TACHOMETER
8DJ81LYV4	SV	N2 TACHOMETER
8DJ81LYV4-U	OH	N2 TACHOMETER
8DJ81LYV4-U	SV	N2 TACHOMETER
8DJ81LWM2	OH	TACHOMETER
8DJ81LWM2	SV	TACHOMETER
8DJ81LWM2-2	OH	TACHOMETER
8DJ81LWM2-	SV	TACHOMETER
8DJ81LWR4	OH	TACHOMETER
8DJ81LWR4	SV	TACHOMETER
8DJ81LYT2	OH	N1 TACHOMETER
8DJ81LYT2	SV	N1 TACHOMETER
8DJ81LWN2	OH	TACHOMETER
8DJ81LWN2	SV	TACHOMETER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
8DJ81LAA4	OH	TACHOMETER
8DJ81LAA4	SV	TACHOMETER
285U0048-16	SV	FRAME
285U0048-10	SV	FRAME ASSY
285U0050-1	SV	COVER
285U0038-33	SV	BOARD ASSY
S906-10097-101	SV	FACE PLATE
285U0039-15	SV	BOARD ASSY
285U0040-19	SV	BOARD ASSY
900-12597-4	SV	SWITCH
61YY11002-7	SV	SWITCH
285U0048-16	NS	FRAME
285U0048-10	NS	FRAME ASSY
285U0050-1	NS	COVER
285U0038-33	NS	BOARD ASSY
S906-10097-101	NS	FACE PLATE
285U0039-15	NS	BOARD ASSY
285U0040-19	NS	BOARD ASSY
900-12597-4	NS	SWITCH
61YY1102-7	NS	SWITCH
522-3877-001	OH	FLIGHT DIRECTOR
522-3877-001	SV	FLIGHT DIRECTOR
522-3875-001	OH	COURSE INDICATOR
522-3875-001	SV	COURSE INDICATOR
124910-0336	NE	COURSE INDICATOR
AC30-0003-245	SV	COURSE INDICATOR
2061-13-1	SV	FLAP POSITION IND
10-61926-3	OH	FLAP POSITION IND
10-61926-3	SV	FLAP POSITION IND
2061-13-1	OH	FLAP POSITION IND
18-1299-5-2	OH	FLAP POSITION IND
18-1299-5-2	SV	FLAP POSITION IND
2594620-915	SV	BAROMET ALTITUDE IND
255302-5	OH	DIRECTIONAL GYRO
229-0245-00	SV	SYNCHRO RECEIVER
229-0245-000	SV	SYNCHRO RECEIVER
2400-3	NE	SWITCH
797-3567-005	SV	DME BOARD
621-1523-001	SV	BOARD ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
JG298A4	SV	PRESSURE RATION IND
JG298A4	OH	PRESSURE RATION IND
55806-964-2	SV	BOARD
55806-982-03	SV	BOARD
55806-973-4	SV	BOARD
55806-992-1	SV	PCB POWER SUPPLY
55806-911-1	SV	BOARD
50YY23566	SV	SWITCH
8YY23955	SV	SWITCH
57351-307-1	SV	SWITCH
646-8257-001	SV	CIRCUIT, CARD
646-5179-005	SV	CIRCUIT, CARD ASSY
837-2001-07	SV	SWITCH ROTARY
4003734-901	OH	RMI
4003734-901	SV	RMI
RH-551C	OH	RMI
RH-551C	SV	RMI
JG141A2	OH	FUEL QTY INDICATOR
JG141A2	SV	FUEL QTY INDICATOR
4002001-1	SV	INDICATOR, FLAG
4000440-1	SV	MONITOR
4000440-901	SV	MONITOR. MODULE
4000440-901	SV	MONITOR. MODULE
18-36480A01	NS	SINE/COSINE POT
4016460-1	SV	MONITOR. MODULE
ERH-10-DUS-04/B924	SV	SYNCHRO RECEIVER
SR2ARHH5P24	NS	BEARINGS
15DO22A016	NS	BEARINGS
APE4190-014	SV	CLOCK
APE4190-014	OH	CLOCK
6107W14P003	SV	RELAY
6900W12P006	SV	IC
2341W26P002	SV	CLAMP
2501538-2	SV	Motor, DC
21107ACY04D134	SV	MOTOR, DC
2501538-2	NS	Motor, DC
21107ACY04D134	NS	MOTOR, DC
618-3577-003	NS	CCA, PITCH & ROLL
618-3577-003	SV	CCA, PITCH & ROLL
H17-2	NS	METER
H17-2	SV	CCA, PITCH & ROLL
2501569-2	NS	METER
2501569-2	SV	CCA, PITCH & ROLL



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
260516	NS	OXIGEN PRESS IND
260516	SV	OXIGEN PRESS IND
69-37317-76	OH	MODULE ASSY
69-37317-76	SV	MODULE ASSY
393026-01838	OH	FUEL QTY INDICATOR
393026-01838	SV	FUEL QTY INDICATOR
393026-04510	OH	FUEL QTY INDICATOR
393026-04510	SV	FUEL QTY INDICATOR
791-2123-001	NE	GEAR ASSY
791-2123-001	NS	GEAR ASSY
797-3567-001	NS	DME BOARD
797-3567-001	SV	DME BOARD
797-3528-001	NS	CIRCUIT CARD ASSY
797-3528-001	SV	CIRCUIT CARD ASSY
2591781-901	NS	PITCH TRIM ASSY
2591781-902	NS	PITCH TRIM ASSY
2501366-1	NS	SWITCH ALT
6ET1-T-F	NS	SWITCH
6ET1-T	NS	SWITCH
2591781-901	SV	PITCH TRIM ASSY
2591781-902	SV	PITCH TRIM ASSY
2501366-1	SV	SWITCH ALT
6ET1-T-F	SV	SWITCH
6ET1-T	SV	SWITCH
501-1228-04	OH	EMERGENCY POWER SUPPLY
501-1228-04	SV	EMERGENCY POWER SUPPLY
63540-040-1	OH	DIGITAL RMI/ADF INDICATOR
63540-040-1	SV	DIGITAL RMI/ADF INDICATOR
2600-03-1	OH	CHRONOMETER, DIG ELECT
2600-03-1	SV	CHRONOMETER, DIG ELECT
285U0040-18	SV	BOARD ASSY
501153-001	SV	COVER GLASS
500980-002	SV	WEDGE GLASS
200821-001	SV	FLANGE SCREENED
100432-01-05	SV	FLANGE ASSY
100875-01-01	SV	BOARD ASSY
100518-01-03	SV	BOARD ASSY
501153-001	NS	COVER GLASS
500980-002	NS	WEDGE GLASS
200821-001	NS	FLANGE SCREENED
100432-01-05	NS	FLANGE ASSY
100875-01-01	NS	BOARD ASSY
100518-01-03	NS	BOARD ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
501153-001	OH	COVER GLASS
500980-002	OH	WEDGE GLASS
200821-001	OH	FLANGE SCREENED
100432-01-05	OH	FLANGE ASSY
100875-01-01	OH	BOARD ASSY
100518-01-03	OH	BOARD ASSY
21649	SV	MICROSWITCH
512-0013	SV	MICROSWITCH
WCS223-022	SV	KNOB
WCS223-022	SV	KNOB
482-5101-030	SV	LOC METER MOVEMENT
482-5076-020	SV	GYRO METER MOVEMENT
482-5096-040	SV	COMPUTER METER
482-5144-060	SV	G.S. FLAG
192-2055-030	SV	WEDGE
779-3290-003	SV	BOARD ASSY
482-5101-030	NS	LOC METER MOVEMENT
482-5076-020	NS	GYRO METER MOVEMENT
482-5096-040	NS	COMPUTER METER
482-5144-060	NS	G.S. FLAG
192-2055-030	NS	WEDGE
779-3290-003	NS	BOARD ASSY
010-050	NS	COMPUTER METER
778-1466-004	SV	CASE ASSY
778-1466-004	SV	CASE ASSY
11188-0005	NE	RESISTOR
4040440-1	SV	SWITCH
4068496-901	SV	ACT ASSY
4045639-902	SV	SWITCH ASSY
4045639-902	SV	SWITCH ASSY
4034279-9	SV	INDICATOR
DS11009	SV	INDICATOR
4034279-5	SV	INDICATOR
DS11005	SV	INDICATOR
4040440-1	NS	SWITCH
4068496-901	NS	ACT ASSY
4045639-902	NS	SWITCH ASSY
4045639-902	NS	SWITCH ASSY
4034279-9	NS	INDICATOR
DS11009	NS	INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4034279-5	NS	INDICATOR
DS11005	NS	INDICATOR
4034279-12	SV	INDICATOR
DS11026	SV	INDICATOR
4034279-13	SV	INDICATOR
DS11027	SV	INDICATOR
4034279-15	SV	INDICATOR
DS11029	SV	INDICATOR
4034279-7	SV	INDICATOR
DS11007	SV	INDICATOR
4034279-14	SV	INDICATOR
DS11028	SV	INDICATOR
4034279-16	SV	INDICATOR
DS11030	SV	INDICATOR
4034279-17	SV	INDICATOR
DS11031	SV	INDICATOR
4034279-12	NS	INDICATOR
DS11026	NS	INDICATOR
4034279-13	NS	INDICATOR
DS11027	NS	INDICATOR
4034279-15	NS	INDICATOR
DS11029	NS	INDICATOR
4034279-7	NS	INDICATOR
DS11007	NS	INDICATOR
4034279-14	NS	INDICATOR
DS11028	NS	INDICATOR
4034279-16	NS	INDICATOR
DS11030	NS	INDICATOR
4034279-17	NS	INDICATOR
DS11031	NS	INDICATOR
4045665-901	SV	SERVO MECHANISM ASSY COUR
4045637-901	SV	IAS/MACH
4045661-901	SV	HDG ASSY
4045666-901	SV	SERVO MECH ASSY
4068570-901	SV	CCA-DISPLAY INTERF
4068568-901	SV	CCA-MODE CONTROL
4045665-901	NS	SERVO MECHANISM ASSY COUR
4045637-901	NS	IAS/MACH
4045661-901	NS	HDG ASSY
4045666-901	NS	SERVO MECH ASSY
4068570-901	NS	CCA-DISPLAY INTERF
4068568-901	NS	CCA-MODE CONTROL
4145811-8	NS	RECEPTACLE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
4149463P3	NS	GROUND CLIP
4149463P003	NS	GROUND CLIP
948F458-1	SV	GENERATOR CONTROL UNIT
948F458-5	SV	GENERATOR CONTROL UNIT
948F458-1	OH	GENERATOR CONTROL UNIT
948F458-5	OH	GENERATOR CONTROL UNIT
1293564-1	NS	BRACKET
12B4A	NS	VACUUM TUBE
1293542-2	NS	SLIPRING
1293542-3	NS	SLIPRING
1293607-1	NS	TRANSFORMER
1293641-1	NS	BRUSH BLOCK ASSY
1293642-1	NS	BRUSH BLOCK ASSY
1295162P002	NS	NUT
129522-2	NS	SHAFT
1298705-	NS	NAME PLATE
125M4	NS	VACUUM TUBE
125N7GTA	NS	VACUUM TUBE
125K7	NS	VACUUM TUBE
125L7GT	NS	VACUUM TUBE
6615-723-1766	SV	SEAL STRIP
1309425-1	NS	BOOT
135	NS	SPRING
13518	NS	WAHSER
1383842	NS	CLIP
139288-01	NS	ID PLATE
147C161P001	NS	PICK OFF ASSY
1720043	NS	SPACER
1720042	NS	CAM
1720045	NS	GUIDE
1720046	NS	BRACKET
1749374-1	NS	LEVEL SWITCH
175-16-006	NS	BOARD ASSY
175-21W-154-4	NS	DIAL
175-26W603	NS	PLATE
175-21W-154-3	NS	DIAL
1751053	NS	GEAR
1751055	NS	WHEEL
1751295	NS	TERMINAL
1781190-1	NS	MOUNT
18019	NS	SNAP RING
1786941-1	NS	STUD
1782702	NS	LIGHT BLOCK



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1786942-1	NS	WASHER SPLIT
180	NS	SWITCH
1752807-2	NS	FLAG ASSY
463738-052	NS	GEAR ASSY
1758696-2	NS	METER MOVEMENT
1778673	NS	FLAG
1758696-1	NS	METER MOVEMENT
176B601-P1	NS	RING
1755576	NS	SPRING
1755739	NS	MASK
1755278	NS	GEAR
1754637-18	NS	SCREW
1755577	NS	SHAFT
1775140-1	NS	LEVEL SWITCH
59510023	NS	NAME PLATE
1783149	NS	NAME PLATE
2048-01-1	NS	IND
207-0-03-013	NS	ID PLATE
210520	NS	INFO PLATE
210523	NS	ID PLATE
2504228	NS	NAME PLATE
2955K71P001	NS	DECAL
2503447	NS	ID PLATE
2504340	NS	NAME PLATE
4015724-25	NS	NAME PLATE
469871-101	NS	NAME PLATE
2504726	NS	NAME PLATE
469874-135	NS	NAME PLATE
500539-001	NS	NAME PLATE
6050KA8P001	NS	NAME PLATE
635-2287-000	NS	ID PLATE
767-0532-000	NS	ID PLATE
609-7998-000	NS	NAME PLATE
6602-NP	NS	NAME PLATE
6681K87P001	NS	ID PLATE
6684K73P001	NS	NAME PLATE
N562B33	NS	NAME PLATE
D-125A	NS	DECAL
M581401	NS	ID PLATE
NP176090	NS	NAME PLATE
NP204766	NS	NAME PLATE
NP204802	NS	NAME PLATE
NP204997	NS	ID PLATE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
NP209235	NS	NAME PLATE
NP210005	NS	NAME PLATE
NP222998	NS	NAME PLATE
NP223944	NS	NAME PLATE
NP224182P13	NS	NAME PLATE
NP227655	NS	NAME PLATE
NP227734	NS	NAME PLATE
NP227839	NS	NAME PLATE
59510023	NS	NAME PLATE
NP216232	NS	NAME PLATE
204997	NS	ID PLATE
209235	NS	NAME PLATE
223944	NS	NAME PLATE
224182P13	NS	NAME PLATE
227655	NS	NAME PLATE
227734	NS	NAME PLATE
227839	NS	NAME PLATE
2594620-902	SV	BAROMET ALTITDUDE IND
2594620-904	SV	BAROMET ALTITDUDE IND
2594620-905	SV	BAROMET ALTITDUDE IND
2594620-909	SV	BAROMET ALTITDUDE IND
2594620-912	SV	BAROMET ALTITDUDE IND
2594620-914	SV	BAROMET ALTITDUDE IND
2594620-915	SV	BAROMET ALTITDUDE IND
2594620-902	OH	BAROMET ALTITDUDE IND
2594620-904	OH	BAROMET ALTITDUDE IND
2594620-905	OH	BAROMET ALTITDUDE IND
2594620-909	OH	BAROMET ALTITDUDE IND
2594620-912	OH	BAROMET ALTITDUDE IND
2594620-914	OH	BAROMET ALTITDUDE IND
2594620-915	OH	BAROMET ALTITDUDE IND
2610-10-1	OH	CHRONOMETER, DIFITAL ELECTF
2610-10-1	SV	CHRONOMETER, DIFITAL ELECTF
482-5058-010	NS	SPEED CONTROL POINTER
800903-02	NS	METER MOVEMENT
6682K21P001	NS	ID PLATE
182-2-1004X	NS	CONNECTOR
1860699-1	NS	BOOT
1816634-1	NS	NO DESCRIPTION
1836045-1	NS	NO DESCRIPTION
1816607-1	NS	STATOR
2503530	NS	AMPLIFIER
1813789-1	NS	CLAMP



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1816602-1	NS	RING ASSY
248944	NS	SPEED CONTROL POINTER
MODEL 9980 TYPE 15	NS	SPEED CONTROL POINTER
2082064-2	NS	METER MOVEMENT
5696A29P001	NS	ID PLATE
22674	NS	AMPLIFIER
4321	NS	AMPLIFIER
837-0029-010	OH	SWITCH, PUSH
837-0029-010	SV	SWITCH, PUSH
837-0029-010	NS	SWITCH, PUSH
2587567	SV	GYROSYN COMPASS IND
2587567	OH	GYROSYN COMPASS IND
130590-2	SV	CABIN AIR PRESS IND
130590-2	OH	CABIN AIR PRESS IND
130590-1	SV	CABIN AIR PRESS IND
130590-1	OH	CABIN AIR PRESS IND
482-5058-010	SV	SPEED CONTROL POINTER
800903-02	SV	METER MOVEMENT
6682K21P001	SV	ID PLATE
182-2-1004X	SV	CONNECTOR
1860699-1	SV	BOOT
1816634-1	SV	NO DESCRIPTION
1836045-1	SV	NO DESCRIPTION
1816607-1	SV	STATOR
2503530	SV	AMPLIFIER
1813789-1	SV	CLAMP
1816602-1	SV	RING ASSY
192-2003-010	SV	LIGHT WEDGE
1886563-1	SV	BRACKET
19315-729685-2	SV	CLIP
1931416-1	SV	RING FIDUCIAL
1931410-1	SV	PLATE LIGHTING
1931290-1	SV	BLOCK LIGHTING
19-1611-01	SV	POINTER
187174-001	SV	PIVOT
192-2015-010	SV	GLASS
1931269-1	SV	
1916114-2	SV	PIN
1916114-1	SV	PIN
1867901-1	SV	BRACKET, LEVEL ASSY
192-2071-010	SV	WEDGE LIGHTING
192-2003-010	NS	LIGHT WEDGE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1886563-1	NS	BRACKET
19315-729685-2	NS	CLIP
1931416-1	NS	RING FIDUCIAL
1931410-1	NS	PLATE LIGHTING
1931290-1	NS	BLOCK LIGHTING
19-1611-01	NS	POINTER
187174-001	NS	PIVOT
192-2015-010	NS	GLASS
1931269-1	NS	
1916114-2	NS	PIN
1916114-1	NS	PIN
1867901-1	NS	BRACKET, LEVEL ASSY
192-2071-010	NS	WEDGE LIGHTING
222A7-153-2	SV	POINTER ASSY
482-5046-000	SV	GYRO FLAG
19GE331AL40	SV	GEAR
1990336-1	SV	DIAL
1988993-1	SV	DIAL
1986462-1	SV	DIAL
1988992-1	SV	DIAL
1988991-1	SV	DIAL
1988990-1	SV	DIAL
1986462-1	SV	DIAL
1963470-1	SV	POINTER
1963467-5	SV	SHIM
1963467-4	SV	SHIM
1963467-3	SV	SHIM
1963467-2	SV	SHIM
1957435-2	SV	RETAINER
202010-129	SV	GYRO FLAG
248730	SV	GYRO FLAG
222A7-153-2	NS	POINTER ASSY
482-5046-000	NS	GYRO FLAG
19GE331AL40	NS	GEAR
1990336-1	NS	DIAL
1988993-1	NS	DIAL
1986462-1	NS	DIAL
1988992-1	NS	DIAL
1988991-1	NS	DIAL
1988990-1	NS	DIAL
1986462-1	NS	DIAL
1963470-1	NS	POINTER



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
1963467-5	NS	SHIM
1963467-4	NS	SHIM
1963467-3	NS	SHIM
1963467-2	NS	SHIM
1957435-2	NS	RETAINER
202010-129	NS	GYRO FLAG
248730	NS	GYRO FLAG
SA21-55K	SV	RESISTOR
1H5GT	SV	VACUUM TUBE
200-5010-000	SV	BUMPER, BLACK
2000075-1	SV	DIAL
768-7453-001	SV	TAPE
200875-2	SV	STATOR
203221	SV	CONTACT SLEVE
6148K10P105	SV	RESISTOR
JANCHS1H5GT/G	SV	VACUUM TUBE
JANCHR1H5GT/G	SV	VACUUM TUBE
VT223	SV	VACUUM TUBE
SA21-55K	NS	RESISTOR
1H5GT	NS	VACUUM TUBE
200-5010-000	NS	BUMPER, BLACK
2000075-1	NS	DIAL
768-7453-001	NS	TAPE
200875-2	NS	STATOR
203221	NS	CONTACT SLEVE
6148K10P105	NS	RESISTOR
JANCHS1H5GT/G	NS	VACUUM TUBE
JANCHR1H5GT/G	NS	VACUUM TUBE
VT223	NS	VACUUM TUBE
206558	SV	SCREW
233931	SV	DIAL SHIELD
228606	SV	NUT
230967	SV	ANVILL
228599	SV	PIN
228591	SV	SEAT
Z1Z7768-1	SV	
21124	SV	SCREW
229-0086-000	SV	CAP
2345K77P002	SV	MOUNTING CLAMP
2341K88P001	SV	CLAMP
230-0234-000	SV	COIL
2307K93P031	SV	CHOKE



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
2307K90P079	SV	CHOCKE COIL
230069	SV	EYELET ASSY
230002	SV	SEAT
2338K24P001	SV	CLAMP
MP-206-28A	SV	COIL
206558	NS	SCREW
233931	NS	DIAL SHIELD
228606	NS	NUT
230967	NS	ANVILL
228599	NS	PIN
228591	NS	SEAT
Z1Z7768-1	NS	
21124	NS	SCREW
229-0086-000	NS	CAP
2345K77P002	NS	MOUNTING CLAMP
2341K88P001	NS	CLAMP
230-0234-000	NS	COIL
2307K93P031	NS	CHOKE
2307K90P079	NS	CHOCKE COIL
230069	NS	EYELET ASSY
230002	NS	SEAT
2338K24P001	NS	CLAMP
MP-206-28A	NS	COIL
248640	SV	RIVET
2345K77P004	SV	MOUNTING CLAMP
244842	NS	INSULATOR
240-0284-000	NS	COIL, RF
240L1H	NS	
241235	NS	LATCH
244839	NS	HAIR PIN ASSY
248639	NS	WASHER
2473K10P050	NS	COUNTER WEIGHT
2501525	NS	TRANSFORMER
240-0285-000	NS	COIL
482-5058-010	NS	SPD CONTROL POINTER
2500-28	NS	CHOKE
248944	NS	SPD CONTROL POINTER
MP-206-28B	NS	COIL, RF
12398B	NS	COIL, RF
MP-206-29B	NS	COIL
12399B	NS	COIL
248640	NS	RIVET
2345K77P004	NS	MOUNTING CLAMP



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
244842	SV	INSULATOR
240-0284-000	SV	COIL, RF
240L1H	SV	
241235	SV	LATCH
244839	SV	HAIR PIN ASSY
248639	SV	WASHER
2473K10P050	SV	COUNTER WEIGHT
2501525	SV	TRANSFORMER
240-0285-000	SV	COIL
482-5058-010	SV	SPD CONTROL POINTER
2500-28	SV	CHOKE
248944	SV	SPD CONTROL POINTER
MP-206-28B	SV	COIL, RF
12398B	SV	COIL, RF
MP-206-29B	SV	COIL
12399B	SV	COIL
482-5107-010	NS	METER MOVEMENT
1783636-27	NS	CONNECTOR
2504058	NS	REACTOR
2504054	NS	TRANSFORMER
2503270-2	NS	STATOR
215010-040	NS	METER MOVEMENT
1783636-22	NS	
C-785	NS	TRANSFORMER
2504061	NS	BRUSH BLOCK
2504386-3	NS	FLAG
2504553-1	NS	COUPLING
2504582	NS	TRANSFORMER
2519149	NS	SPACER
2519164-4	SV	BOARD ASSY
2519270-2	SV	PC BOARD
2519772	SV	POST
2519773	SV	SCREW
2519775	SV	SPACER
2553663-8	SV	BRUSH BLOCK
2500072	SV	TRANSFORMER
13434	SV	PC BOARD
2553765	SV	BRUSH BLOCK
F1660-1	SV	BRUSH BLOCK
500100	SV	BRUSH BLOCK
482-5117-010	SV	HDG FLAG
M9071-106	SV	HDG FLAG
2555634-67	SV	SCREW



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
482-5107-010	SV	METER MOVEMENT
1783636-27	SV	CONNECTOR
2504058	SV	REACTOR
2504054	SV	TRANSFORMER
2503270-2	SV	STATOR
215010-040	SV	METER MOVEMENT
1783636-22	SV	
C-785	SV	TRANSFORMER
2504061	SV	BRUSH BLOCK
2504386-3	SV	FLAG
2504553-1	SV	COUPLING
2504582	SV	TRANSFORMER
2519149	SV	SPACER
2519164-4	NS	BOARD ASSY
2519270-2	NS	PC BOARD
2519772	NS	POST
2519773	NS	SCREW
2519775	NS	SPACER
2553663-8	NS	BRUSH BLOCK
2500072	NS	TRANSFORMER
13434	NS	PC BOARD
2553765	NS	BRUSH BLOCK
F1660-1	NS	BRUSH BLOCK
500100	NS	BRUSH BLOCK
482-5117-010	NS	HDG FLAG
M9071-106	NS	HDG FLAG
2555634-67	NS	SCREW
2555440	SV	LEVEL SWITCH
2555634-901	SV	SCREW
2555483	SV	GEAR
2555440	NS	LEVEL SWITCH
2555634-901	NS	SCREW
2555483	NS	GEAR
482-5133-020	SV	METER MOVEMENT
M9076-68	NS	METER MOVEMENT
JG603C42	OH	FUEL QTY IND
JG603C42	SV	FUL QTY IND
30-0837-21	SV	STROBE LIGHT
30-0837-21	SV	STROBE LIGHT
777-2830-004	SV	SWITCH ASSY
618-4474-001	SV	MOUNTING PLATE
777-2845-001	SV	INSULATOR
836-2387-010	SV	LAMP ASSY



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
D1400-6A1	SV	PANEL FASTENER
618-4476-002	SV	PLATE FRONT-GREY
618-4476-001	SV	PLATE FRONT-BLACK
618-4478-001	SV	PLATE SPACER
618-4478-002	SV	PLATE SPACER
792-0881-001	SV	FLAG INDICATOR
266-6981-670	SV	LENS, SWITCH
690813A1-66	SV	LENS, SWITCH
690813A1-65	SV	LENS, SWITCH
266-6981-660	SV	LENS, SWITCH
690813A1-64	SV	LENS, SWITCH
266-6981-660	SV	LENS, SWITCH
690813A1-30	SV	LENS, SWITCH
690813A1-55	SV	LENS, SWITCH
266-6981-300	SV	LENS, SWITCH
266-6981-560	SV	LENS, SWITCH
690813A1-49	SV	LENS, SWITCH
690813A1-48	SV	LENS, SWITCH
690813A1-53	SV	LENS, SWITCH
690813A1-59	SV	LENS, SWITCH
266-6981-500	SV	LENS, SWITCH
266-6981-489	SV	LENS, SWITCH
266-6981-540	SV	LENS, SWITCH
266-6981-600	SV	LENS, SWITCH
690813A1-17	SV	LENS, SWITCH
266-6981-170	SV	LENS, SWITCH
777-2884-001	SV	SLEEVE, BLOCK
618-4486-001	SV	COVER CONTROL
618-4473-001	SV	COVER
690813A1-53	SV	LENS, SWITCH
266-6981-540	SV	LENS, SWITCH
778-0504-001	SV	GUARD
JG603C42	OH	FUEL QTY IND
JG603C42	SV	FUL QTY IND
30-0837-21	OH	STROBE LIGHT
30-0837-21	SV	STROBE LIGHT
777-2830-004	NS	SWITCH ASSY
618-4474-001	NS	MOUNTING PLATE
777-2845-001	NS	INSULATOR
836-2387-010	NS	LAMP ASSY
D1400-6A1	NS	PANEL FASTENER
618-4476-002	NS	PLATE FRONT-GREY
618-4476-001	NS	PLATE FRONT-BLACK



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
618-4478-001	NS	PLATE SPACER
618-4478-002	NS	PLATE SPACER
792-0881-001	NS	FLAG INDICATOR
266-6981-670	NS	LENS, SWITCH
690813A1-66	NS	LENS, SWITCH
690813A1-65	NS	LENS, SWITCH
266-6981-660	NS	LENS, SWITCH
690813A1-64	NS	LENS, SWITCH
266-6981-660	NS	LENS, SWITCH
690813A1-30	NS	LENS, SWITCH
690813A1-55	NS	LENS, SWITCH
266-6981-300	NS	LENS, SWITCH
266-6981-560	NS	LENS, SWITCH
690813A1-49	NS	LENS, SWITCH
690813A1-48	NS	LENS, SWITCH
690813A1-53	NS	LENS, SWITCH
690813A1-59	NS	LENS, SWITCH
266-6981-500	NS	LENS, SWITCH
266-6981-489	NS	LENS, SWITCH
266-6981-540	NS	LENS, SWITCH
266-6981-600	NS	LENS, SWITCH
690813A1-17	NS	LENS, SWITCH
266-6981-170	NS	LENS, SWITCH
777-2884-001	NS	SLEEVE, BLOCK
618-4486-001	NS	COVER CONTROL
618-4473-001	NS	COVER
690813A1-53	NS	LENS, SWITCH
266-6981-540	NS	LENS, SWITCH
778-0504-001	NS	GUARD
553-6588-004	SV	MOUNT PLATE
553-6588-004	NS	MOUNT PLATE



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

0143-37

0143-37

S-1H5GT)
OR (60B00237-11)

OR,

OR
OR
TOR
22



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

CATOR

CATOR

2

TER



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

DR

ICATOR
ICATOR
IC INDICATOR
ICATOR
ICATOR

D, (S242T404-311)
D)

JD

ALVE IND

R DRIVE

TOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

FOR

INDICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

3)
RD



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

ICATOR
ICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

0143-37

0143-37

S-1H5GT)
OR (60B00237-11)

OR,



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

OR
OR
TOR
22

CATOR

DATOR

2



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

TER

DR

ICATOR
ICATOR
IC INDICATOR
ICATOR
ICATOR

D, (S242T404-311)
D)

JD



B&G Instruments, Inc
Tel:305-871-4445

Part Number	Condition	Description
ALVE IND		
R DRIVE		
TOR		
TOR		
INDICATOR		



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

3)
RD



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

ICATOR
ICATOR



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

SE

SE



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description



B&G Instruments, Inc
Tel:305-871-4445

Part Number

Condition

Description

RONIC
RONIC